

Systems Design

Document role

- This file owns the active subsystem baseline and cross-system modeling context for the build.
- Use this file to describe what the current system is, how the major subsystems fit together, and which assumptions are still active.
- Keep the final 48V house/alternator architecture, shutdown order, and control-path lock in `docs/core/ELECTRICAL_48V_ARCHITECTURE.md`.
- Keep exact conductor, fuse, layout, and install-level detail in `docs/implementation/`.
- Keep decision/risk/open-question state in `docs/core/TRACKING.md` rather than letting this file become the live issue tracker.

Electrical and energy

Goals

- Deliver workday reliability with reserve margin
- Keep wiring safe, labeled, and serviceable

Electrical doc links

- Canonical 48V architecture and alternator-control baseline: [ELECTRICAL_48V_ARCHITECTURE](#)
- Implementation topology (components, fuses, holders, gauges): [ELECTRICAL_overview_diagram](#)
- Fuse IDs, locations, housing methods, spares, and BOM mapping: [ELECTRICAL_fuse_schedule](#)
- Voltage architecture trade study (12V vs 48V): [ELECTRICAL_12V_vs_48V_trade_study](#)
- Alternator architecture trade study history (research archive only; final decisions moved to the canonical 48V architecture doc): [ELECTRICAL_48V_dual_alternator_trade_study](#)
- Canonical roof-solar architecture, geometry, electrical proof, and release gates: [SOLAR_configuration_matrix](#)
- Electrical decisions, risks, and unresolved items: [TRACKING](#)

Planning snapshot (base model as-of 2026-08-10)

- Battery bank: 3x 48V 100Ah LiFeP04 from BOM row 3 (15.36 kWh nominal at 51.2V battery nominal).
- House architecture: 48V core with Orion-Tr Smart 48V->12V charging/step-down feeding a shared battery-backed 12V junction.
- Inverter/charger: Victron MultiPlus-II 48/3000/35-50 , DC/inverter mode live-tested with no observed errors.
- Charge sources in current BOM: solar MPPT, dedicated 48V secondary alternator path (Mechman + WS500 + APM-48 migration baseline), shore AC charger path.
- Monitoring and protection: Cerbo GX, SmartShunt, battery temp sensing, Class T primary fuse + branch fusing.
- AC protection chain is purchased/locked for Phase 1 (shore source/adapters -> portable EMS -> shore cord -> L5-30 inlet -> single 6-way AC DIN enclosure -> 30A AC-in breaker -> MultiPlus -> 30A AC-out main -> two 20A GFCI branches). AC-in/MultiPlus charging has passed a short limited-current live test; AC-out branch/GFCI commissioning remains pending.
- Current build phase: the electrical module, Galley/cooler support, water tank, and returned Bench extrusion are owner-reported hard-mounted; the Orion/ 12V path is operational. Owner reports the pump, fridge, KUS sender, three independent USB-PD branches, and both first-in-chain GFCIs are wired/routed; labels, protection, polarity/continuity, LINE/LOAD/PE, configuration, and functional tests remain open. Battery 1 completed the corrected isolated charge cycle, Battery 2 reached absorption, and Battery 3 remains pending before rest/ <=0.1V matching and parallel-bank commissioning. The final walnut install has a mid-September 2026 target. Roof work has selected Starlink and 600W Arch Pro solar architectures but remains template, contact, structural, route, and all-up-weight gated before cuts, panel purchase, or adhesive work.

Physical integration snapshot (2026-08-05)

- Electrical module, Galley/cooler support, and returned Bench extrusion are positively hard-mounted and tied together; owner reports the integrated assembly is extremely stiff. Final mobile restraint is now localized to positive capture/strapping for the 3x 48V batteries, the separate 12V battery, and the ICECO cooler plus final terminal/cable protection.
- Driver-rear shore inlet and exterior-to-module feed are installed. One accessible, enclosed, conductor/gauge-rated L/N/PE splice into the locked AC-input breaker path remains before dead checks and energization.
- Three 48V battery branch harnesses are physically complete and landed at the positive/negative battery-side busbars. Battery 1 completed its corrected cycle, Battery 2 reached absorption, and Battery 3 is pending; all three still require a recorded rested-voltage match within 0.1V before they are paralleled.
- 12V buffer branch remains 4 AWG : battery + -> F-11 100A ANL -> SW-12V-BATT -> fuse-panel main + ; battery - -> fuse-panel main - . Orion output uses 6 AWG to the same junction through F-07 60A/80V on output positive. Because both sources meet at the fuse-panel main stud, SW-12V-BATT isolates only the buffer battery; it does **not** de-energize the fuse panel while the Orion remains enabled.

- The ICECO appliance lead is switched and landed on 12V-02 through a 15A fuse. Its 16 AWG pigtail is acceptable downstream of that branch protection, but the exposed positive switch tabs must be individually insulated and the switch temporarily hard-mounted before normal powered work.
- The replacement KUS FLS-U under-ring/gasket/hardware is installed and the sender circuit is owner-reported wired. Verify KUS black to upper DATA and KUS pink/the owner's red extension to lower GND in one numbered Tank column, then configure/prove the 240-33 ohm reading before closeout.
- Three separate 12 AWG / 15A USB-PD routes are owner-reported (1x Desk, 2x Galley); identify and label the third fuse-panel slot in the physical panel rather than inferring it from the old two-station map. Desk and Galley first-in-chain GFCl are owner-reported wired on separate breakers; any downstream receptacles stay on the corresponding GFCl LOAD side with continuous PE and whole-chain testing.
- Orion input protection is one verified 40A MEGA (58VDC minimum under the locked 56.8V charge ceiling; Victron CIP138040020 40A/80V is the replacement fallback) in Lynx Slot 4 feeding the existing 6 AWG pair directly. The 6 AWG input is overkill but already installed and safely protected by 40A; no separate inline or DIN input fuse holder is used. This is an explicit practical deviation from Victron's 20A external-protection table to eliminate redundant connection stacks. Purchased 30A/58V MIDI and FKS/ATO stock remains unused. Keep 6 AWG and F-07 60A/80V on the Orion 30A 12V output.

Commissioning snapshot (2026-08-02)

- Owner confirmed 55.5V at the 48V bus and at the MultiPlus after pre-charge/energization.
- MultiPlus switch I brought inverter mode online; inverter light illuminated, slight hum was observed, and no error lights were reported.
- SmartShunt and Orion-Tr Smart are visible in VictronConnect. SmartShunt red fused Vbatt+ lead should remain battery-side if SOC continuity while the main disconnect is open is desired; the parasitic draw is negligible for normal short storage windows.
- Cerbo GX is powered from the 48V system through a small inline fused feed and uses VE.Bus /RJ45 to the MultiPlus; its Wi-Fi access point/remote-console workflow is active.
- AC input source type should be labeled Shore power , not generic Grid , for the mobile source-current-limited workflow.
- Household-outlet shore test used a reduced MultiPlus input-current limit (10A first test / 12A maximum policy on a 15A circuit). Observed values were about 1294W shore input and about 54.3V x 21.6A (~1173W) battery charge in bulk.
- MultiPlus battery charge profile has been owner-verified by supervised one-battery live behavior: settings were redone, the charger entered bulk, then quickly transitioned to absorption because the battery was already at/near 100% , as planned. Current target remains absorption/charge voltage 56.8V , float 54.0V , short absorption dwell, equalization off, charger current within the connected-battery limit, and source-current limit set for the actual shore outlet. The Dumfume manual's 58.4V value is documented, but because the same value is also listed as charge-limit/over-charge protection voltage, it is not the active routine target. Leave DVCC disabled unless a documented BMS/GX control path is added. No separate second-battery charge test is required just to close the charger-programming gate; AC-out/GFCl and alternator commissioning remain separate gates.
- Overnight Battery 2 checkpoint (2026-08-02/03): still in bulk in the upper 54V range and progressing normally toward the 56.8V absorption target; this is not an abnormal state by itself. Battery 3 remains the final isolated-charge member.
- Owner-reported 12V checkpoint (2026-08-02): the Orion charges the buffer battery and the camper 12V system is operating correctly. The prior implausible handheld-meter discrepancy is no longer reported as an active behavior; retain the normal rule that any independently confirmed bus voltage above the configured 14.20V absorption target is a stop condition.
- Normal shutdown/de-energize for the current bench system: MultiPlus 0 , turn off active 12V loads, disable the Orion through VictronConnect or its remote on/off, de-energize/unplug shore, wait briefly, then open SW-12V-BATT and the main 48V disconnect as required for the service scope. For startup, close SW-12V-BATT before enabling the Orion. Residual voltage on the Lynx/load side with disconnect open is expected from device capacitance but must be treated as live until metered near zero.

Modeling rules (procurement-first plus full-load)

- Primary active-procurement source of truth is bom/bom_estimated_items.csv ; returned/retired stable-ID history is in bom/bom_inactive_items.csv and is excluded from the active total.
- Load model is maintained in bom/load_model_wh.csv (model v5) and includes BOM-sourced installed loads, owner-supplied work electronics (kept out of BOM cost totals), and a conservative preliminary/future camper-audio listening profile. Audio is not near-term procurement.
- Legacy workbook WH model assumptions are retired and not used.
- Voltage convention: use 48V as architecture label, but use 51.2V nominal for battery Wh accounting.
- Run-length convention: measured physical layout lengths are cut-length source-of-truth; CAD values are planning references only.

Input reference (maintained)

Input	Current value	Source
Battery bank	3x Dumfume 51.2V 100Ah (1S3P; manual allows up to 1S4P). Per battery: charge voltage 58.4V +/-0.2V; recommended charge current 20A; max continuous charge 100A; recommended discharge 50A; max continuous discharge 200A; over-discharge protect/recover	bom/bom_estimated_items.csv row 3 + references/Dunfume_36V_48V_100Ah_Battery_-_User_Manual.pdf

	36.8V/43.2V; discharge overcurrent 600A; short-circuit 1800A; low-temp charge protection approx 41F-50F, recovery at 50F; high-temp protection 157F/140F.	
Inverter/charger	MultiPlus-II 48/3000/35-50	bom/bom_estimated_items.csv row 12
Alternator charging	Dedicated 48V secondary alternator path (Mechman + WS500 + APM-48) with Upfitter #3 -> WS500 brown ignition manual control and Lynx Slot 3 alternator branch fuse lock	bom/bom_estimated_items.csv rows 168-171, 176, 320 + docs/core/ELECTRICAL_48V_ARCHITECTURE.md
Obsolete pre-Mechman alternator charger/remote	Returned/obsolete; not part of primary layout, fuse planning, or commissioning	bom/bom_inactive_items.csv rows 18 and 26
Legacy single-12V upgrade path	Mechman 370A + Big 3 path is deprecated under the dual-48V migration baseline	bom/bom_inactive_items.csv rows 103 and 104
DC-DC charger	Orion-Tr Smart 48/12 30A (360W); 48V input is protected by F-05 40A MEGA (>=58VDC) in Lynx Slot 4 with no second inline fuse, and 12V output is separately protected by F-07 60A/80V	bom/bom_estimated_items.csv row 20
12V buffer battery	12V 100Ah LiFeP04 on shared 12V junction (F-11 + SW-12V-BATT)	bom/bom_estimated_items.csv rows 21, 124, and 125
Solar array posture	Final architecture is 6x BougeRV Arch Pro 100W SP003 = 600W: four modules direct-bonded to fiberglass per BougeRV's polyurethane adhesive-rib method and two fully supported on one removable track-side cassette. Final measured roof baseline is 138 x 63 in; the MaxxAir is laterally centered. Purchase waits on the 1:1 template, fan/Starlink survey, cassette design, and preliminary <=75 lb budget; bonding/travel wait on received-label, actual-weight, cassette-load, bond-coupon, and hot-operation gates.	bom/bom_estimated_items.csv row 24 + docs/studies/SOLAR_configuration_matrix.md
Solar controller	Retain the purchased SmartSolar MPPT 150/45; wire the Arch Pro array 3S2P. Per string: 97.2V Vmp, 113.4V Voc, 3.1A Imp, 3.2A Isc. Tolerance-aware cold Voc is 142.29V at -40F. Estimated hot/tolerance Vmp is 70.91V at +85C, about 9.11V above the 56.8V + 5V startup threshold before route drop; final measured drop and hot-roof commissioning remain gates.	bom/bom_estimated_items.csv row 25
Load profiles (BOM + owner-supplied office loads)	core_workday, winter_workday, minimal_idle_day	bom/load_model_wh.csv
Owner-supplied office assumptions	Laptop + 27 inch 1440p monitor + tablet/peripheral charging	bom/load_model_wh.csv rows marked Owner-Supplied

Modeled expected usage

Load totals below are from `bom/load_model_wh.csv` model v5 (BOM loads plus the purchased Ninja SP151 cooking appliance, owner-supplied office loads, and a conservative preliminary/future camper-audio profile).

Scenario	Daily energy	5-day workweek energy	7-day week energy	Dominant contributors
core_workday	3,915 Wh	19,575 Wh	27,405 Wh	Laptop, monitor, Starlink, cooking, inverter idle, conservative future-audio allowance
winter_workday	4,829 Wh	24,145 Wh	33,803 Wh	Laptop, monitor, Starlink, diesel heater, cooking, conservative future-audio allowance
minimal_idle_day	624 Wh	3,120 Wh	4,368 Wh	Fridge + always-on monitoring/detector loads

Capacity analysis (corrected battery bank)

Metric	Formula	Result
Nominal battery energy	51.2V x 100Ah x 3	15,360 Wh
Usable energy to 20% reserve floor	15,360 x 0.8	12,288 Wh
Core day depth of discharge	3,915 / 15,360	25.49% per day
Winter day depth of discharge	4,829 / 15,360	31.44% per day

Autonomy (no charging)

Scenario	Days (100% -> 20%)
core_workday	3.14
winter_workday	2.54
minimal_idle_day	19.69

Charging potential

All values are planning-level and should be replaced with measured charge logs after shakedown tests.

Solar charging (600W final architecture)

The 2026-08-10 final roof decision is 6x BougeRV Arch Pro 100W = 600W , 3S2P , on the purchased SmartSolar 150/45 . Four modules use direct fiberglass bonding; two use one compact track-side cassette. This replaces the stale 134 x 62 in CMPower/Lensun/Solbian decision set.

Use the existing 68% end-to-end planning factor until measured harvest exists. It may be optimistic for the four hot direct-bond modules and conservative for the two ventilated cassette modules.

600W at 68%	2 PSH day	4 PSH day	5 PSH day	Net vs core_workday at 4 PSH	Net vs winter_workday at 4 PSH
Final Arch Pro array	816 Wh	1,632 Wh	2,040 Wh	-2,283 Wh/day	-3,197 Wh/day

- Break-even is 9.60 PSH/day for core_workday and 11.84 PSH/day for winter_workday ; roof solar is supplemental charging, not guaranteed workday autonomy.
- Current roof-fit, mounting, electrical proof, and release gates: docs/studies/SOLAR_configuration_matrix.md .

Alternator charging (dedicated 48V secondary alternator path)

- Active migration baseline: Mechman dual-alternator kit + WS500 regulator + APM-48 protection module.
- Lynx Slot 3 alternator branch fuse (F-04) is locked at 200A/80V MEGA at the house-bank/Lynx end of the alternator positive run. Mechman's published 48V Elite curve reaches about 145.7A ; 125% is about 182A , making 200A the next standard fuse size while remaining within the installed 2/0 AWG conductor envelope. Mechman guidance requires the fuse within 12 in of the battery-bank connection; if final layout places the Lynx farther away, add a bank-end fuse holder rather than leaving the branch unfused at the bank end.
- The owner-confirmed PH-VAN harness combines regulator power and positive voltage sense on one short red lead. Land it on the alternator/load side of F-04 and protect it immediately with one compact in-line high-interrupt DC fuse assembly: Eaton/Bussmann HEB-AA (600V) holder plus Littelfuse KLKD015.T (15A , fast acting, 600VAC/DC) midget fuse. Use short 14 AWG pigtails and a sealed 14-to-16 AWG splice to the harness. This is one in-line holder in the loom; no DC fuse panel, DIN rail, or enclosure is added.
- Put the separate Wakespeed 500A/50mV shunt on the battery side of the hard-mounted Victron SmartShunt in the same common battery-negative path: battery negative combine -> Wakespeed shunt -> SmartShunt -> Lynx/system negative . Purple/current-sense-high faces battery negative; grey/current-sense-low faces the SmartShunt/Lynx system side. Configure Shunt at Battery . This preserves the SmartShunt-to-Lynx hard connection while keeping every battery current path through both shunts.
- Manual charge-enable/disable path is locked to Ford Upfitter Switch #3 feeding the WS500 brown ignition/enable wire through local inline fuse F-15 (3A , 12V control circuit).
- WS500 white Feature-In is reserved for future automatic fault-interlock work and is not required in Phase 1.
- Mechanical-only staged driving with the Mechman alternator installed but unwired/electrically disabled is owner/Mechman-confirmed acceptable after the idler/belt/noise check passes; this does not commission alternator charging.

- WS500 rough-in default is regulator near the truck-bed house electrical area so analog shunt/battery-sense wiring stays short; run the alternator-leg wiring forward in separate labeled looms from the 2/0 charge pair.
- Cable decision lock for this pass: reuse existing uncut 2/0 inventory for the alternator charge path (~20 ft one-way assumed), with dedicated equal-size negative run.
- Obsolete pre-Mechman alternator-charger hardware is returned/removed from active planning and should not appear in primary fuse/layout decisions.

Shore charging (MultiPlus-II charger path)

- Charger limit from model string: 35A ; Dufume manual lists charge voltage as 58.4V +/-0.2V but also lists charge-limit/over-charge protection at 58.4V , so current commissioning uses a lower routine target: 56.8V absorption/charge with 54.0V float. For the 3x bank, manual-backed current references are 60A recommended charge total and 300A max continuous charge total, so the MultiPlus 35A maximum is within battery-bank limits.
- Current first-live result: AC-in shore charging was proven at household-outlet limits with MultiPlus input limit reduced (10A first test; 12A policy ceiling on a 15A circuit). Reported Cerbo values were about 1294W from shore and about 54.3V x 21.6A into the battery bank in bulk.
- Supervised charge-profile verification: fixed LiFePO4 settings were redone and live behavior matched the plan on the first battery; charging entered bulk, then quickly transitioned to absorption because the battery was already at/near 100% . Earlier settled snapshot showed 56.8V on the MultiPlus/SmartShunt with 0A charge current, battery display about 55.8V , SmartShunt SOC set to 100% , and shore input current limit 12A on the household-source test.
- Current charger profile: 56.8V absorption/charge target, 54.0V float, 52.8V storage if available, equalization off, lithium temperature compensation behavior disabled/confirmed, minimum absorption time (1h in the observed 1-8h field), repeated absorption 0.25h , and charger current at or below the MultiPlus 35A limit; if charging one isolated battery, cap current at 20A .
- DVCC remains disabled in the current architecture because there is no documented BMS-to-GX control path.
- AC input current policy: label AC Input 1 as Shore power ; use 10A for first tests and 12A maximum on a normal 15A household circuit; use the actual pedestal/source rating for 20A / 30A sources.
- Ideal bulk-only recharge times at the current 56.8V commissioning target and 35A charger limit remain reference-only until measured charge logs replace them:
 - Replace one core_workday : 1.97h .
 - Replace one winter_workday : 2.43h .
 - Recharge full 3x bank from 20% to 100% : 6.18h .
- Recharge one isolated 48V 100Ah battery from 20% to 100% : about 3.61h at the single-battery 20A current cap.
- Real-world times are longer due to absorption taper near full charge, reduced household input-current limits, and any configured charge-current derate.

Operational implications and constraints

- Battery capacity now supports roughly 2.5-3.1 office-workdays without charging in the conservative future-audio model, depending on season and reserve policy; actual near-term office-only use may be better.
- At the selected 600W case and base 68% factor, 4 PSH still leaves 2,283Wh/day and 3,197Wh/day deficits for the modeled core and winter workdays. Roof solar is a charge-source reducer, not guaranteed workday autonomy.
- Shore charging can materially recover SOC in a single evening (~6.18h from 20% to 100% in bulk-ideal terms).
- Alternator recovery potential is expected to materially exceed the obsolete pre-Mechman charger path once the dedicated 48V alternator path is commissioned.
- Current execution risk is no longer charger-capacity-limited operation; it is migration/commissioning quality (fitment, regulation, protection, and measured thermal behavior).
- MultiPlus-II 48/3000 inverter continuous output (~2,400W) can be exceeded by simultaneous induction + Ninja SP151 air fryer/toaster oven + other AC loads, so high-draw AC loads need sequencing.
- Orion-Tr Smart 48->12V 30A charger (360W) is the continuous charging/feed ceiling into the shared 12V junction; buffer battery supports short transients, including audio bass peaks, but sustained overload still requires load budgeting.

Safety baseline

- Positive path sequence: battery -> Class T fuse (near source) -> disconnect -> Lynx Distributor -> fused branch feeds
- Negative path sequence: battery -> Wakespeed 500A/50mV shunt -> SmartShunt -> Lynx Distributor negative bus -> all load/charge returns on the system side of both shunts; do not separate the SmartShunt from the Lynx
- Dedicated alternator branch grounding rule set: run equal-or-larger dedicated negative cable from secondary alternator to house-bank return path and avoid sheet-metal return paths.
- MultiPlus mobile-installation protective earth is mandatory: external M6 PE lug -> 10 AWG green stranded copper (4 mm² Victron minimum) -> verified truck-chassis bond point. Bond the aluminum Hiatus shell separately into the same equipment-ground network; do not use shell/80/20 as the only PE conductor.
- Keep AC PE, AC neutral, and DC negatives distinct. Do not jumper MultiPlus case/PE to Lynx or 12V negative and do not add a fixed downstream neutral-ground bond; leave the MultiPlus internal ground relay enabled. Confirm Mechman case-ground behavior and verify no

- chassis path bypasses the SmartShunt before alternator commissioning.
- If the truck uses an RVC ground-sensor loop, route the upgraded ground path through the loop per vehicle requirements.
- Battery thermal strategy: insulated battery box, ducted warm-air branch, thermostat/relay enable logic
- Wiring practices: grommets, loom, glands, abrasion protection, and bend-radius validation
- Reference links from workbook notes:
 - https://youtu.be/dSYKabw_rgs?t=651
 - <https://www.diodeled.com/45-channel.html>

Electrical overview diagram (implementation)

- Full implementation-level topology diagram: `docs/implementation/ELECTRICAL_overview_diagram.md`
- Scope includes fuse IDs, fuse-holder/housing methods, branch wire-gauge selections, and documented sizing assumptions.

RF-003 Distribution Topology Decision (Lynx Locked)

Decision date: `2026-02-12`

Approved architecture for Phase 1:

- Victron Lynx Distributor M10 (`LYN060102010`) is the single distribution backbone.
- Current tracked unit price is `$211.65` (BOM row `6`).
- Current Lynx fused outputs in use (`4` total):
- Slot 1: MultiPlus-II `48/3000` (`F-02 125A`)
- Slot 2: SmartSolar `150/45` (`F-03 60A`)
- Slot 3: Dedicated `48V` alternator branch output (`F-04 200A/80V`)
- Slot 4 (`F-05`) feeds Orion-Tr Smart `48/12` through one `40A` MEGA body-marked at least `58VDC` ; standalone `F-06` is retired.
- `1x` Lynx Distributor covers the current four active branch outputs with no spare fused slot.
- If another fused `48V` branch is added later, add a second Lynx module or a separately engineered branch in that phase.

Implementation notes:

- Lynx Distributor includes the negative busbar, so a separate standalone negative bus is not required in the Lynx path.
- Lynx Distributor branch-fuse LEDs need a Lynx Shunt VE.Can or Lynx Smart BMS ; with SmartShunt -only monitoring, LED fuse indication is not active.
- Main Class T protection baseline is `3x` (one per battery-positive conductor) and is tracked in the fuse schedule/BOM.

Reference links:

- Lynx Distributor manual/specs: https://www.victronenergy.com/media/pg/Lynx_Distributor/en/introduction.html
- Lynx Distributor retail example: <https://www.invertersrus.com/product/victron-lynx-distributor/>

Fuse Determination Baseline (Lynx)

Objective: maintain a complete start-to-finish fuse schedule for the approved Lynx architecture.

Current detailed schedule (active reference):

- `docs/implementation/ELECTRICAL_fuse_schedule.md`

Scope covered:

- Main battery protection (`Class T`) quantity, rating, and placement.
- Lynx branch fuses for active outputs: MultiPlus, MPPT, dedicated alternator branch, and Orion input (`F-05 40A` , `>=58VDC` , in Slot 4); no standalone Orion input fuse.
- WS500 low-current fuse requirements and alternator-branch protection coordination.
- Any additional protective devices required by manufacturer manuals for both charge-source and load paths.

Method:

- Pull max current requirements and overcurrent guidance from each device manual.
- Confirm planned wire gauge/length/insulation assumptions for each run.
- Size each fuse to protect the conductor first while meeting equipment requirements.
- Build final fuse matrix with part numbers, quantities, and BOM row mapping.

Solar

- Final architecture: `6x` BougeRV Arch Pro `100W = 600W` , `3S2P` , on the purchased Victron `150/45` ; four direct-bond modules plus one removable two-module side cassette.

- Panel purchase waits on the survey/templates, cassette design, preliminary weight budget, and any required insurer/Hiatus acceptance; bonding/travel then remain blocked by the separate post-receipt gates in `docs/studies/SOLAR_configuration_matrix.md` .
- Hardwall popup wiring baseline for planning: no hidden in-wall solar run; use exterior-rated coiled jumper cable(s) from roof solar exit to a lower-shell weatherproof passthrough.
- BOM scope for that routing method is tracked in `bom/bom_estimated_items.csv` row 121 .
- Open points: exact passthrough location, branch connector/combiner method, cassette side/load path, and final moving-jumper route.
- Energy takeaway: the extra harvest from 800-910W candidates does not justify a 250V controller plus broad carrier/deck fabrication. Keep the 600W roof simple and rely on the dedicated 48V alternator and shore path for predictable recovery.

Electrical reference maintenance workflow

- Update trigger conditions:
 - Any change to battery, inverter/charger, DC-DC, or solar components in `bom/bom_estimated_items.csv` .
 - Any measured field data that materially changes duty-cycle assumptions.
 - Any change in appliance selection, owner-supplied office electronics, or expected duty cycle in `bom/load_model_wh.csv` .
- Update process:
 1. Update component rows and assumptions in `bom/load_model_wh.csv` .
 2. Recalculate scenario daily Wh totals in this file from that CSV.
 3. Recalculate autonomy at the active reserve floor (`usable Wh / daily Wh`).
 4. Recalculate charging tables with latest charge source ratings and assumptions.
 5. Record what changed in `docs/core/TRACKING.md` (decision/risk/open questions) and `logs/LOG.md` .
 6. Remove stale assumptions that are not backed by BOM rows or explicit owner-supplied load assumptions.
- Formula quick reference:

```
battery_nominal_wh = battery_voltage_v * battery_capacity_ah * battery_quantity
daily_wh = sum(component_wh_per_day) + conversion_loss_wh
autonomy_days = usable_battery_wh / daily_wh
solar_daily_wh = array_watts * effective_psh * solar_efficiency_factor
solar_efficiency_factor = nameplate_realization * thermal_factor * mppt_wiring_factor * orientation_factor *
soiling_shading_factor
alternator_daily_wh = dc_dc_output_watts * drive_hours
alternator_practical_w = (alternator Rated_a - vehicle_base_load_a) * alternator_voltage_v * conversion_efficiency
house_charge_current_a = alternator_practical_w / charge_voltage_v
shore_charge_power_w = charge_voltage * charger_current_a
bulk_charge_hours = energy_to_replace_wh / shore_charge_power_w
```

- Retired model note:
- `bom/load_model_wh.csv` v1 (workbook-derived chart), v2 (BOM-only), v3 (BOM plus owner-supplied office loads), and v4 (added preliminary/future camper audio) are superseded by model v5, which adds the purchased Ninja SP151 appliance load while retaining the audio allowance.

Camper audio

- Camper audio implementation owner: [CAMPER audio system](#). Status: preliminary/future-roadmap, not near-term procurement. Draft package is a DC-first 2.1 camper-only system: Samsung S11 Ultra tablet -> Kicker 46KMC2 marine media receiver -> Kicker CSC67 4 ohm speaker pair plus Kicker 49PTRTP10 powered down-firing 10 in subwoofer.
- Active BOM rows 189-193 track deferred/preliminary source unit, speaker pair, powered sub, 4 AWG sub power/fuse kit, RCA/speaker wiring, mounts, and install consumables. Inactive BOM row 101 preserves the deprecated sound-system placeholder.
- Electrical posture: KMC2 uses a 15A source/head-unit branch from the 12V fuse panel; PTRTP10 uses a separate 40A source fuse near the 12V source takeoff with 4 AWG positive and matching 4 AWG return to the 12V negative bus/main stud. Audio returns should not use shell/chassis as the normal current path.
- 12V headroom note: the selected audio system can theoretically peak around 55A at 12V (15A source unit + 40A powered sub branch), above the Orion 30A continuous 12V feed. The 12V buffer battery supports peaks and short loud sessions, but sustained high-volume use should be watched on the 12V battery voltage/SOC while other 12V loads are running.
- Physical placement default: KMC2 in the driver-side electrical/workstation/DC-shelf face; powered sub low in a dry driver-side toe-kick/step-box or dry bench volume near the 12V junction; speaker cutouts/pods wait for wall panel thickness, roof-down sweep, and furniture-service checks.

Communications

- Primary internet path: purchased Starlink Standard 4 X plus OEM mobility mount (\$405 owner-reported aggregate hardware total), with the purchased third-party DC converter and factory AC/inverter fallback. Current service is \$55/month ; exact plan name is not recorded, and the owner intends to move to an unlimited plan later.
- Secondary/fallback path: TBD (cellular path and carrier diversity not frozen)
- Moving-roof baseline: Starlink now uses one rugged shielded fixed-body RJ45 panel bulkhead feeding either the removable retractile roof jumper or a long outdoor shielded ground-deployment cable. Solar is not part of this interface and remains a later electrically/mechanically separate route. Full topology, current-source links, tooling notes, sizing gates, and acceptance tests live in [STARLINK SOLAR MOVING UMBILICAL](#).
- An exposed side-mounted energy chain is no longer the default: without a measured recess or trough its return bend projects or bunches outward when the roof closes, it does not make the midspan branch-proof, and it is harder to remove. A sleeve/service loop without a take-up mechanism is likewise only a hanging cable. Reopen either architecture only if physical measurements reveal a real inboard guide volume.
- Sheltered is not an assumed location. Use that term only if an existing rigid feature projects outward farther than the jumper and the jumper remains inside its contact shadow through the full roof stroke. No front guard or pouch is part of the current camper baseline.
- Starlink lead path is the purchased third-party Standard 4/4X Type-4-to-RJ45 pigtail pair, purchased shielded retractile Ethernet prototype, and purchased Neutrik NE8FDX-P6-W plus NE8MXR1-B-T0P-D panel/termination package. Neutrik publishes shielded Cat6A, PoE Type 4 Class 8 / 100W , >1000 mating cycles, and IP65 when correctly mated/capped. Procurement does not clear the OD/conductor, continuity/shield, heat/dropout, or full-roof-stroke gates. Preserve the complete factory Starlink cable as an unmodified direct recovery spare; the purchased Furnique coupler and 1 ft shielded jumper support optional panel-fed ground mode.
- Roof-mount lead is the purchased TRIO Gen 3 Standard Speedmount around the dish. Preserve both purchased attachment paths: removal-first magnets with VHB-backed roof discs after full-contact/cure proof, and the 75 mm through-hardware for an extrusion hard-mount fallback. The full framed dish remains removable and keeps the factory kickstand usable. Edge protection is not branch-proof; remove/stow or ground-deploy it for tight brush.
- An ordinary RJ45 ground cable is physically compatible with the panel for dry-weather deployment; wet service needs a compatible sealed cable-side carrier or purpose-built weather-sealed ground lead. The upper terminal interface keeps the Type-4 adapter's weatherproof gland. Scanstrut through-cable gland paths are withdrawn from the finished Starlink quick-disconnect design.
- Solar lead path remains sizing-gated on final panel/string cold Voc , Isc , route length, and roof travel. igus CF9-UL-60-04 is straight four-conductor chain cable rather than a retractile jumper and is removed from the lead moving-section BOM. Use a purpose-built two-conductor outdoor/wet/repeated-flex coil only after calculations. Open a correctly rated two-pole DC PV load-break before disconnecting matched-brand MC4 or other service connectors. IMO SI32-PEL64R-2 is the current lead rotary service isolator (32A , two-pole, 600VDC , lockable OFF, DC-PV class), but release still waits for the final array and cable selection.

Plumbing (if included in phase 1)

- Near-term baseline: complete the cold-water galley and one camper-side two-port propane hot-water service interface together. Build around tank, pump, accumulator, faucet/sink, BLUE pressurized cold-out, RED hot-return, drain/graywater path, and accessible service shutoffs. The HOTTAP itself mounts directly to the outside face of the rear box; there is no second water plate on the box.
- Interior layout and wet-spine draft owner: [INTERIOR furniture layout and galley](#). Current direction is a passenger-side lofted fridge/wet-spine exoskeleton: Iccco/fridge raised about 16 in , pump/accumulator relocated into the owner-measured 6 in gap between the cooler support and house batteries, rear fill/vent and one BLUE/RED hot-water service plate, graywater cassette, and no interior water-heater volume. The wet pack requires a nonconductive splash divider and drained leak path toward the bed floor, not reliance on the battery cases as water protection.
- Water capacity: purchased 36 gal wheel-well tank. Full water mass is about 300 lb before tank/brackets/plumbing; plan around roughly 320+ lb installed when full.
- Owner-confirmed pre-cut tank port geometry (2026-07-16): four molded ports on each end, with two visibly large and two smaller ports per end; no original obvious/open top port. Exact model and thread sizes remain unconfirmed. A new 60 mm / 2-3/8 in sender opening was subsequently cut; fill/vent assignments still require physical port/thread verification.
- Tank restraint posture (2026-08-02 owner report): the wheel-well tank is hard-mounted with two metal straps tightened into the truck-bed-wall plusnut locations and supported within the hard-mounted Galley structure. The wheel-well form factor lowers center of gravity and overturning moment. Confirm clean full thread engagement at the plusnuts, witness-mark the strap hardware, and recheck after the first loaded drive; any visibly cross-threaded or partially engaged location is a pre-drive rework item.
- Installed pump/accumulator state (2026-07-26 owner report): the purchased SHURflo 4008-101-A65 3.0 GPM pump, SEAFLO inline accumulator, tank, and interior PEX distribution operate under pressure. Use approximately 37 PSI accumulator precharge with the water side fully depressurized, based on the pump's nominal 40 PSI cut-in; the accumulator is not a regulator and the static system may begin near the pump's 55 PSI cutoff.
- Purchased galley fixture baseline: FORIOUS black pull-out faucet with soap dispenser plus Sarlai black 15 in x 15 in topmount sink with approx. 11 in x 13 in interior basin (BOM rows 207-208). The FORIOUS manual and product diagram confirm separate 3/8 in hot/cold supply-hose connections. The exact EFIELD two-pack of 1/2 in PEX-B barb x 3/8 in OD compression male adapters (ASIN B0C7QBNVG9) was purchased 2026-07-25 ; seat each faucet hose nut directly on the male compression seat with no PTFE tape.

- Current sink-layout implication: the chosen sink is topmount, so the flange can live on the counter while the bowl passes through a local frame opening; still verify actual cutout, faucet shank/nut/hose clearance, drain/graywater routing, and sink-zone rail/connector position before final cuts.
- Interior plumbing state (2026-08-03 owner report): all three passenger-rear camper pass-throughs—the gravity-fill hatch, direct BLUE cold-out, and RED hot-return—are physically installed; BLUE/RED are functioning. The BLUE source has the required accessible ball valve; the RED leg is intentionally unvalved because it is only the removable heater return to the sink hot inlet. The projecting HQMPC-style male QDs physically fit, and the owner-designed clicked-on travel caps latch and release correctly. The replacement KUS under-ring/gasket/hardware is installed and visually seated. Final water acceptance still requires sender electrical/Cerbo setup, fill/vent hose closeout, sink termination, and a dry pressure/dwell inspection after all disturbed joints are complete.
- Sender-mount resolution (2026-08-03 owner report): the failed first KUS/ FLS-U hardware has been removed and replaced with a new FLS-U ring, main gasket, and matched long screws. Keep top access and the sender visible through the next fill/pressure/dwell proof. The short screws with bonded metal/rubber sealing washers belong to KUS's separate gasket-mounting kit; the official FLS-U manual depicts its longer under-ring screws without transplanted loose rubber pieces. Clamp load and a clean gasket/sealing land—not donor washers—control acceptance.
- Hot-water decision posture (2026-08-01 , owner-confirmed installation): propane only. The purchased core package is one outdoor-use Joolca HOTTAP V2 Essentials, one Quick-Release HOTTAP Bracket, and one HOTTAP V2 Mount Cover. Mount it directly to a structurally backed exterior side face of the rear box with the purchased bracket and cover; it remains outside the cylinder compartment and no articulating arm or box-side water plate is used. The direct RAINPAL/HQMPC camper-port prototype passed physical installation and quick-disconnect operation; its projection is accepted with the owner-designed clicked-on travel caps. The installed stack uses one compact 304 stainless bulkhead per port (1/2 in FNPT rear, 3/4 in MGHT front) with a directly threaded metal male tap adapter that physically proved compatible with the Joolca female socket. Melnor 15409 is unavailable and remains only the visual/profile reference despite Joolca's documented Melnor QuickConnect compatibility. The acquired HQMPC two-set ASIN B07FHXLKH5 supplied the two installed female-GHT/male-QD adapters and passed owner-reported connection operation. The RAINPAL bulkheads are installed, and the owner-designed clicked-on travel caps operate correctly. GARDENA 39004-G is now only a fallback. Only BLUE stays behind an accessible source valve; RED is an unvalved removable-hose return to faucet hot. The QD3 key, 1/4 in reducer, rear 3/8 in hose-barb transition, and second QD ecosystem are rejected from the installed path. HOTTAP Essentials supplies one 5 m shower assembly split into 4 m and 1 m red female/female sections; preserve both for their intended hot-side duties and prefer a separate roughly 30 in BLUE-to-heater leader with Melnor 9MQC / 8MQC female sockets after fit testing. The 1 m red section remains a valid no-purchase cold-feed trial, not the preferred final hose. Joolca states that HOTTAP is recreational wash hardware, not a drinking/sanitary-water appliance. Source/fitting details and the complete inline count live in [INTERIOR furniture layout and galley](#).
- Rear propane package: the 2026-07-26 purchase includes the Flame King YSN10LB-ALM cylinder, CALPOSE gauge, and bracket/strap pack. The Safoner hatch provides a neat propane-hose pass-through through the rear box. The AWW stone mat is for the outdoor shower.
- HOTTAP mounting/operation: Joolca explicitly permits vehicle mounting. Through-bolt the purchased Quick-Release HOTTAP Bracket—previously documented as the vehicle quick plate—to proven structural backing on the exterior box side; do not ask the aluminum skin alone to carry road vibration. Keep the purchased HOTTAP V2 Mount Cover on for travel/dust protection and remove/open it as Joolca requires before operation. Disconnect LP and water for travel. Before first ignition, prove the actual exterior location against Joolca's published operating clearances and confirm that exhaust/heat do not impinge on the camper, box door, cylinder compartment vents, stored gear, or cover. Never burn the HOTTAP inside the cylinder box, even with its large door open.
- Freeze and winterization strategy (2026-08-01 owner-confirmed port routine): after every freezing-weather use, close LP and the BLUE source valve, shut down the HOTTAP, open the sink hot side to relieve pressure, disconnect and gravity-drain both Joolca hoses, and follow the HOTTAP manual's drain/storage procedure. With the heater hose removed and faucet hot side open, use only regulated low-pressure air through the RED quick-disconnect to clear the short hot-return line toward the sink; the removable hose is the RED-side disconnect, so no separate RED valve is required. Arrange the short PEX-to-bulkhead terminations without trapped low points, clean the male exterior plugs, and install the clicked-on travel caps. Use the pump and fully open BLUE outlet for normal tank emptying; the low south boss stays unopened or receives only a low-profile plug because an exposed valve would occupy the entry footpath. A removable upstream suction-flex connection remains the dead-pump gravity fallback. Emptying the tank does not winterize the strainer, pump, accumulator, fixture cartridges, QDs, or low loops.
- Gravity-fill vent hose correction: owner-measured vent nipple is about 10 mm OD on the main land and 11 mm OD at the largest barb/ridge. Specify 10 mm ID food-grade/potable tube, or 3/8 in ID as the common inch fallback; the previously ordered 1/2 in ID x 5/8 in OD tube is oversized.
- Current water-integration order: terminate/configure the installed KUS sender, finish fill/vent and sink terminations, then perform one complete dry pressure/dwell leak proof while the sender remains visible. The controlling fill geometry is continuous downhill fill-hose routing from the exterior hatch plus continuous vent rise without a trapped low loop.
- Tank-level electrical baseline: purchased KUS SSS/SSL 14.5 in , US 240-33 ohm , two-wire sender connects directly to one native Cerbo GX MK2 Tank-input column. On the front-panel legend, Tank columns are 1-4 left to right, upper row DATA , lower row GND : connect KUS black/signal to upper DATA and KUS pink/return—the owner's red extension—to lower GND . Use 1.0 mm² ferrules with >=10 mm pins for the 18 AWG extensions, or 10-11 mm untinned exposed stranded copper if only short ferrules are available. No separate 12V feed, fuse, analog gauge, VE.Direct cable, or GX Tank 140 is required.
- Current plumbing route (2026-08-01 installed-port baseline): draw from a low north-end port through the existing tank shutoff, full-flow 90 only if the real turn requires it, flex, strainer, pump, discharge flex, and accumulator. Mount the purchased SHURflo/SEAFLO pack in the

- measured 6 in cooler-to-battery gap on a thin vibration-isolated plate supported by extrusion; preserve strainer-bowl removal and point fittings/leak paths away from the batteries behind a nonconductive splash divider. The SEAFLO SFAT-075-125-01 accumulator has two 1/2 in MNPT pass-through ports; its supplied white swivels are flexible-hose barbs, not PEX-B. Use the purchased RecPro double-FIP hose on the pump side and one accepted YVSKM female-swivel PEX-B adapter on the outlet. After the accumulator, one 1/2 in PEX tee branches to faucet cold while the straight leg continues to an accessible BLUE service valve and compact direct-profile wall port. The installed BLUE path reuses the purchased UP120A5 after the valve and threads it directly into a 1/2 in FNPT / 3/4 in MGHT stainless bulkhead; the physically proven HQMPC female-GHT/male-QD adapter occupies the exterior GHT. The separate RED path uses the same compact bulkhead/QD hardware but omits the BLUE source valve; it is an unpressurized return when the heater hose is disconnected and runs directly to faucet hot. Do not replace the now-working stack with the previously considered Legend combination valve without a demonstrated service or depth benefit. Connect the BLUE hose with its valve closed, open BLUE only for use, then close BLUE and relieve pressure before disconnecting; RED has no separate valve. Prefer a separate approximately 30 in cold leader from BLUE to the heater and retain the supplied 4 m + 1 m red shower assembly; use the 1 m red section only as the no-purchase cold-feed trial. No QD3 key/reducer/barb stack, box-side plate, CPC jumper set, arm service loops, permanent splitter, electric heater branch, manifold, bypass, or concealed heater cubby remains in the lead prototype.
- Exterior-cut dependency update (2026-08-03): the driver-rear shore inlet and three passenger-rear water pass-throughs are installed. Remaining work is internal/system closeout—shore splice/dead checks, fill/vent hose completion, KUS termination/leak proof, sink termination, and final wet/AC acceptance—not additional convenience-driven shell cuts.

Cabinetry and structure

- Interior furniture/layout draft owner: [INTERIOR furniture layout and galley](#). Recommended planning direction is the office-first hybrid: passenger-side lofted Iceco/fridge on an extrusion exoskeleton, pump/accumulator below the fridge next to the 36 gal wheel-well tank, adjacent separated battery bench, driver-side electrical closet/workstation/DC shelf, diesel heater low in the driver-side utility zone, and clear center aisle/cabover movement.
- Driver-side workstation implementation draft: [INTERIOR driver side workstation](#). It captures the current best direction for a driver-side service-spine desk, stow-low monitor cassette/rising VESA spine, electrical-closet/DC-shelf interface, shallow storage, travel locks, cable management, heat/noise control, and roof-close acceptance tests.
- Aluminum extrusion strategy: the broad 15-series starter order is superseded. Default to 10-series prototype stock/hardware for furniture where practical; reserve larger extrusion for measured heavy/dynamic freestanding modules that prove they need the stiffness, such as the lofted fridge skeleton, electrical closet frame, monitor mast/spine, or battery bench structure if dry-fit proves the load path needs it.
- Current physical state (2026-08-02 owner report): electrical, Galley/cooler support, water tank, and the Bench extrusion bridge are hard-mounted and the integrated structure is very stiff. Build the battery restraint as a low extrusion perimeter/divider cage tied to anchored extrusion or through-bolted structural plywood, with individual over-case straps and no strap contact at terminals/displays. Restrain the ICECO at its foot-level tie points with a low-stretch cam strap to the support extrusion plus a lateral hard stop and soft wall bumper; do not crush the cooler case with ratchet tension.
- Panel strategy: living-facing furniture surfaces should use mechanically removable overlay panels over the frame; service zones stay exposed or quick-removable. Magnetic service covers are acceptable only for light non-structural panels and need locator/anti-shear features plus backup retention where loss would matter.
- Current furniture CAD and May 4 generated diagrams are reference-only after installed-shell layout changes; re-CAD block envelopes around the passenger-side lofted fridge/wet-spine, tank overlap, battery bench, driver-side electrical closet, and desk before final cut lists.
- Modular mounting baseline now includes T-slot/strut rails both exterior (recovery/tool mounts like shovel/Maxtrax) and interior (baskets/hooks/tie-down points); BOM rows 119 and 120 .
- Drawer hardware baseline includes 4x soft-close undermount slide kits for primary cabinetry drawers; BOM row 122 , but final lengths are deferred until fridge/tank/electrical module envelopes are verified.
- Desk concepts captured: fixed full-time work surface with possible auxiliary fold leaf; Lagun-style or pneumatic concepts should remain secondary unless the measured work envelope proves they are stable enough.
- Material ideas captured: phenolic/richlite top, sound treatment, panel anti-rattle tape, frosted/angled LED strips, smoke-grey acrylic shallow cubby covers.
- Monitor travel strategy concept: stow-low/face-down assisted deployment with structural bracing, hard stops, positive travel locks, cable drag chain, and a visible roof-safe state before pop-down.

HVAC and condensation

- Purchased heater baseline: LF Bros 5 kW / 12V / 10 L Split Pro , with supplied tank, external metering pump/filter, exhaust/muffler, combustion intake, T4S hardwired controller, wireless remote, harness, and mounting hardware. Detailed fit/cut owner: [INTERIOR driver side workstation](#).
- Heater install posture: horizontal/upright and low in the driver-side utility zone; preserve at least 10 cm / 4 in at the rear cabin-air inlet and an unrestricted front warm-air path. The underside exhaust, combustion-air intake, fuel inlet, and mounting studs must meet a sealed

- metal through-floor plate/turret directly below the heater. Do not pass exhaust through the plywood electrical backer or an interior electrical cavity.
- Truck-cut baseline: LF Bros demonstrates two 30 mm combustion holes plus four stud holes on a simple flat metal surface. Hiatus' layered floor and corrugated bed require the actual metal turret/plate template and an under-truck obstruction check to control the final cut; use the demonstration only as interface evidence, not as the final camper-floor cut pattern.
- Outside routing baseline: exhaust and muffler stay completely outside, fall slightly for condensate, use broad sweeps rather than a hard 90-degree turn at the heater, and remain separated/shielded from fuel, wiring, plastic, undercoating, openings, and the combustion intake. Intake and exhaust must not terminate in the same direction or where exhaust can be recirculated.
- Supplied tank/pump baseline: the pump does not enter the tank. Drill a centered 7-8 mm hole through the molded lower tank-outlet boss for the supplied pull-through bulkhead/nozzle; do not cut out the full apparent 3/4-1 in pad. Fuel order is tank -> filter -> pump -> heater ; pump outlet points toward the heater and upward about 45 degrees , with pump-to-heater distance within 2 m .
- Fuel-storage posture: do not leave the open plastic tank/fill/filter/pump in the battery/electrical/living bay. Preferred direction remains exterior mounting or sealed externally vented containment with spill control, with only a protected fuel line entering the heater zone. A larger narrow exterior tank remains optional later; the supplied 10 L tank and pump already cover commissioning hardware.
- Electrical/control baseline: the harness branches to heater, pump, T4S controller, and 12V +/- ; the pump is ECU-controlled and the wireless remote needs no wire or cut. Feed from fused 12V C-22 , never 48V , and preserve power throughout controller-commanded cooldown. Measure the final route before accepting the planned short-run 14 AWG / 15A branch; use 12 AWG if length or startup-voltage testing demands it.
- Ventilation: Maxxair fan included in current camper config
- Lighting split: Hiatus factory overhead LED+dimmer remains separate from the planned ambient/cabinet LED subsystem. Desired future interior-lighting design is 12V QuinLED/WLED analog PWM control on the dedicated lighting branch, with upper CCT white wash, lower RGBCT night/entry strip, and hardwired momentary buttons; install/procurement is deferred.
- Condensation controls and climate envelope limits: TBD

Safety

- Purpose: define a practical, build-ready safety baseline for the current architecture (48V 15.36kWh house bank, 12V distribution, 120VAC shore/inverter path, diesel cabin heat, and the selected exterior propane HOTTAP hot-water package).
- Priority order: prevent ignition and overcurrent faults, preserve safe shutdown paths, detect hazards early, and make isolation/service repeatable.
- Final install gate: before energizing or using propane in service, verify all items against manufacturer manuals and complete licensed inspection where required.

System-wide controls

- Keep one-line diagrams, fuse IDs, and conductor IDs synchronized across:
 - docs/implementation/ELECTRICAL_overview_diagram.md
 - docs/implementation/ELECTRICAL_fuse_schedule.md
 - docs/core/TRACKING.md
- Ensure all protection and isolation devices are physically accessible without disassembling fixed furniture.
- Keep gas components and AC/DC electrical components separated by design; no mixed service cavities without physical barriers and clear labeling.
- Label every branch and shutoff point so an operator can isolate faults quickly under stress.

48V battery system safety (primary)

- Main hazards: high fault current, sustained DC arc potential, short-circuit heating, incorrect polarity during service, and thermal stress events.
- Required architecture controls:
- Battery positive path stays: battery -> Class T fuse near source -> main disconnect -> Lynx bus; all active load/charge branches are protected by their Lynx fused outputs, including Orion input F-05 in Slot 4.
- Battery negative path stays: battery -> SmartShunt -> Lynx negative bus (all returns on load side of shunt).
- Use only voltage-appropriate overcurrent devices on house DC branches (58V / 80V class on 48V paths); do not substitute 32V automotive-only fuses on 48V circuits.
- Route the Orion input directly from Lynx Slot 4 through the existing 6 AWG pair after F-05 (40A MEGA, body-marked at least 58VDC); standalone F-06 is retired and no second input holder is installed.
- Keep all busbars/studs covered and insulated; use boot covers, strain relief, and abrasion protection on all near-bus runs.
- Manual alternator shutdown order stays: Upfitter #3 OFF first to disable the WS500 , then open the main 48V disconnect only after alternator charging is no longer active.
- Commissioning controls (first energization and after major rework):

1. Verify polarity and expected voltage at each segment before inserting branch fuses.
2. Confirm torque marks on all high-current terminals and re-check after initial thermal cycles.

3. Confirm the disconnect fully de-energizes downstream service zones as intended.

4. Validate no unintended parallel return paths bypassing shunt measurement.

- Service controls:
- Remove conductive jewelry, use insulated tools, and keep one-hand work practice on live-exposure checks.
- Never perform branch rewiring with battery disconnect closed unless the specific test requires energized state and a spotter is present.

12V distribution safety

- Main hazards: feeder overload from Orion output limits, hidden voltage drop causing heat at terminations, and unfused accessory additions.
- Required controls:
- Keep Orion output feeder fused at source (F-07) and avoid adding unfused taps between Orion and the shared 12V junction.
- Keep 12V buffer battery positive protected at source (F-11) and route service isolation through SW-12V-BATT downstream of F-11 .
- Keep SW-12V-BATT in its normal closed position during operation; use open position only for service isolation/diagnostics.
- In normal closed operation, Orion supports both active 12V loads and buffer-battery maintenance through the shared junction path.
- Do not open SW-12V-BATT as the normal way to stop charging. First turn off the fan/lights or other active loads, disable the Orion, confirm it reports off/not charging, and only then open the battery switch. Opening the battery switch while the Orion is enabled removes the battery but can leave the shared fuse-panel bus and loads powered from the Orion.
- Replace the Orion's always-on L-H jumper with a maintained SPST dry-contact switch between the remote L and H pins for routine local control; the official Victron sequence connects the destination battery before enabling the remote. Startup order is SW-12V-BATT closed first, Orion remote on second.
- In this baseline, the 12V fuse block is the shared junction device (main + stud combine point plus integrated negative bus return point).
- Do not solder-splice high-current 12V source conductors; use crimped lugs on rated stud terminals.
- Maintain branch-level fuse-to-conductor coordination per docs/implementation/ELECTRICAL_fuse_schedule.md .
- Keep always-on detector branch (12V-05) protected but never switch-controlled.
- Keep ambient/cabinet strip lighting on the dedicated DC branch (12V-11) so low-light use does not require inverter operation. Desired future path is 12V QuinLED/WLED analog PWM control, not the superseded 24V converter/MiBoxer worksheet; verify final fuse/conductor sizing once selected strip wattage and expansion channels are known.
- No additional 48V->12V converter is planned: the Orion plus 12V buffer battery is the active architecture. If measured sustained 12V demand later exceeds Orion headroom, engineer a new expansion line then rather than carrying inactive BOM row 118 as current procurement.

120VAC shore/inverter safety

- Main hazards: shock from miswired neutral/ground, ground-fault exposure at outlets, and overcurrent heating from undersized branch protection.
 - Required controls:
 - Keep shore path order: shore source/adapters -> portable EMS/surge protection -> shore cord -> shore inlet (L5-30) -> combined AC DIN enclosure (30A UL489 AC-in breaker/disconnect) -> MultiPlus AC-in.
 - Keep AC-out path order: MultiPlus AC-out-1 -> 10/3 feeder -> combined AC DIN enclosure (30A AC-out main + 20A / 20A branch breakers) -> GFCI receptacle on each active branch.
 - Keep AC-in hardware on a 30A / 10 AWG basis, and set MultiPlus input current limit to the actual source (15A , 20A , or 30A) whenever adapters are used.
 - Keep AC-out-2 as reserve-only in Phase 1 (labeled capped route; no energized branch hardware yet).
 - Preserve continuous equipment grounding and chassis bond through all AC paths.
 - Do not add a fixed downstream neutral-ground bond in branch wiring; neutral/ground behavior must follow MultiPlus transfer/bonding design.
 - Commissioning checks:
1. AC-in-only charger validation with AC-out loads disconnected for first battery charge.
 2. Receptacle polarity test on each outlet location.
 3. GFCI/RCD trip test at each protected branch.
 4. Verify AC-out-2 remains de-energized as a reserve-only capped route in Phase 1.

Propane safety (rear-box cylinder plus exterior Joolca HOTTAP V2)

- Main hazards: LP leakage or accumulation in the rear box, ignition near electrical equipment, CO exposure, road damage, and operating an outdoor-only appliance inside an enclosed box or living space.
- Cylinder/box controls:
- Keep the purchased Flame King YSN10LB-ALM upright and secured in the ventilated rear box with the valve accessible.
- Use the Safoner hatch as the propane-hose pass-through through the rear box.
- The rear-box LP path is cylinder -> CALPOSE gauge -> supplied QCC1 regulator/hose -> HOTTAP .
- HOTTAP operating/travel controls:

- Mount the purchased Quick-Release HOTTAP Bracket directly to proven structural backing on the exterior box side, use the purchased HOTTAP V2 Mount Cover for travel/dust protection, and prove the manual clearances in the installed operating position.
- Never fire the HOTTAP inside the propane box, camper, or any other enclosed space. Operate it only on its exterior mount with the cover clear and exhaust/combustion zone unobstructed.
- Connect the BLUE cold-out and RED hot-return hoses only while parked; disconnect, drain, cap, and stow them before travel. Preserve full freeze drainage of the heater, supplied hoses, exterior stubs, and service trunks.
- Leak-test every disturbed LP connection before operation and define recurring post-service/pre-trip test cadence. Do not use a flame for leak checking.
- Detection and ventilation controls:
- Keep an LP detector low in cabin, CO detector in breathing zone, and smoke detector high in cabin.
- Test detector alarm functions on a recurring schedule and replace by manufacturer expiration date.

Emergency shutdown baseline

1. Remove active high-draw loads (AC and gas appliances) if safe to do so.
2. Open the 48V main disconnect and remove shore input.
3. Close propane cylinder valve at the tank.
4. Ventilate cabin area and confirm detectors are active.
5. Use fire extinguisher only if contained/incipient and exit path is clear; otherwise evacuate and call emergency services.
6. Do not re-energize or reopen gas supply until fault root cause is identified and corrected.

Safety hold points before walls/panels are closed

- Complete and document high-current DC inspection (polarity, fuse value, terminal torque, insulation/boots).
- Complete AC verification (polarity, GFCI/RCD trip tests, branch labeling, ground continuity).
- Complete propane leak check and pressure-hold verification with all planned valves/fittings in final positions.
- Complete detector placement and functional alarm tests.
- Record evidence in `logs/LOG.md` and track unresolved items in `docs/core/TRACKING.md`.

Source artifacts

- `docs/legacy/SYSTEMS_workbook_build_notes_obsolete.md`
- `bom/load_model_wh.csv`