

MITS1 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0002

ADR CODE SMT SOURCE STATEMENT

```

0060 ;0 0 RS232 IN/OUT
0061 ;0 1 ONBOARD VDU/KBD 2MHZ
0062 ;1 0 " 4MHZ
0063 ;1 1 ONBOARD KBD,S100 VDU
>0005 0064 KBD EQU 5H ;ONBOARD KEYBOARD PORT
>0006 0065 RSHS EQU 6H ;RS232 HANDSHAKE (BIT 0)
>0007 0066 PRNTHS EQU 7H ;CENTRONICS HANDSHAKE (BIT 0)
0067 ;
0068 ;MEMORY ALLOCATION
0069 ;
>0003 0070 ; ORG 3H
0071 ;
>0003 0072 IOBYTE: DEFS 1 ;BYTE TO DEFINE I/O DEVICES
0073 ;
>0038 0074 ; ORG 38H
0075 ;
>0038 0076 RST7: DEFS 3H ;MONITOR RESTART ADDR
0077 ;
>0040 0078 ; ORG 40H
0079 ;
>0040 0080 CHBUFF: DEFS 1 ;KEYBOARD CHARACTER BUFFER
>0041 0081 CURPOS: DEFS 1 ;CURSOR POS FOR ONBOARD VDU
>0042 0082 CHCNT: DEFS 1 ; " " FOR BUFFIN(ALL VDUS)
>0043 0083 PRMP: DEFS 1 ;POS OF CURSOR WHEN BUFFIN CALL
>0044 0084 BUFAD: DEFS 2 ;ADDRESS OF INPUT BUFFER +1
>0046 0085 BUFPTR: DEFS 2 ;PTR TO NEXT BUFFERED CHAR
>0048 0086 TOPRAM: DEFS 2 ;LAST RAM ADDR+1
>0049 0087 PAR1: DEFS 2 ;1ST PARAMETER
>004A 0088 PAR2: DEFS 2 ;2ND PARAMETER
>004B 0089 NPARS: DEFS 1 ;# OF PARAMETERS READ
0090 ;
>004F 0091 BPTAB: DEFS NBP*3 ;BREAKPOINT TABLE 3 BYTES/ENTRY
>0050 0092 ISAV: DEFS 2 ;PSEUDO REGISTERS I
>0051 0093 AFSAV: DEFS 2 ;AF
>0052 0094 BCSAV: DEFS 2 ;BC
>0053 0095 DESAV: DEFS 2 ;DE
>0054 0096 HLSAV: DEFS 2 ;HL
>0055 0097 IXSAV: DEFS 2 ;IX
>0056 0098 IYSAV: DEFS 2 ;IY
>0057 0099 SPSAV: DEFS 2 ;SP
>0058 0100 PCSAV: DEFS 2 ;PC
>0059 0101 DISPAD: DEFS 2 ;DISPLAY ADDR
>005A 0102 NXTCH: DEFS 1 ;INPUT CHARACTER BUFFER
>005B 0103 PRNTSW: DEFS 1 ;SWITCH TO TURN PRINTER ON/OFF
0104 ;PRNTSW = 0 -> PRINTER OFF
0105 ;PRNTSW = FF -> PRINTER ON
>005C 0106 LOCKSW: DEFS 1 ;SWITCH TO PROVIDE ALPHA LOCK
0107 ;ON KEYBOARD
0108 ;LOCKSW = 0 -> NORMAL ASCII
0109 ;LOCKSW = FF -> UPPER CASE ONLY
>005E 0110 SRAM1: DEFS 1 ;BUFFER FOR SINGLE STEP
>005F 0111 SRAM2: DEFS 1 ;EXECUTION OF PROGRAM
>0060 0112 SRAM3: DEFS 1
>0061 0113 SRAM4: DEFS 1
>0062 0114 SRAM5: DEFS 1
>0063 0115 SRAM6: DEFS 1
>0064 0116 SRAM7: DEFS 1
>0065 0117 INBUFF: DEFS 1 ;DEFINE BUFFER SIZE

```