

```

TUSCAN Z MONITOR                                TCL Z80 ASSEMBLER PAGE 0003
ADR CODE      SIMT SOURCE STATEMENT

>0086          0118          DEFS      BUFSIZ          ;INPUT BUFFER
>00D6          0119 WORKE  EQU      $                ;END OF MONITOR WORKSPACE
              0120 ;
>0100          0121          ORG      100H
>0100          0122 MONSTK: DEFS      0                ;MONITOR STACK
              0123 ;
>F800          0124          ORG      MONORG          ;EPROM 4 ON TUSCAN
              0125 ;
F800 C303F8    0126 TRUMP:  JP      PON                ;DO POWER ON JUMP
              0127 ;
F803 310001    0128 PON:   LD      SP,MONSTK          ;SET UP STACK
F806 3EC3      0129       LD      A,JUMP              ;SET UP RE-ENTRY
F808 323800    0130       LD      (RST7),A            ;POINT
F80B 2199FC    0131       LD      HL,MONLP
F80E 223900    0132       LD      (RST7+1),HL
F811 DB04      0133       IN      A,(IOSEL)            ;SET UP IOBYTE TO
F813 320300    0134       LD      (IOBYTE),A          ;PRESET VALUE
F816 E630      0135       AND      30H                ;TEST VDU TYPE
F818 FE30      0136       CP      30H                ;MEMORY MAPPED?
F81A CC00D7    0137       CALL    Z,MMINIT            ;YES, INITIALIZE IT
F81D 0618      0138       LD      B,NBP*3              ;CLEAR BPT TABLE
F81F 214F00    0139       LD      HL,BPTAB            ;BY SETTING INACTIVE
F822 3EF8      0140       LD      A,MONPAG
F824 77        0141 CLR TAB: LD      (HL),A
F825 23        0142       INC      HL
F826 10FC      0143       DJNZ    CLR TAB
F828 0617      0144       LD      B,23                ;CLEAR REGISTERS
F82A AF        0145       XOR      A                  ;TO ZERO
F82B 77        0146 CLR REG: LD      (HL),A            ;ALSO DISPLAY PTR
F82C 23        0147       INC      HL                ;& NO CHAR READY
F82D 10FC      0148       DJNZ    CLR REG              ;& PRINTER OFF & NORMAL KBD
F82F 2F        0149       CPL                      ;SET PRINTER STROBE HIGH
F830 D307      0150       OUT     (PRINTST),A
F832 11A4FF    0151       LD      DE,SGNON            ;GIVE SIGN ON MESSAGE
F835 CDAFEA    0152       CALL    BUFFER
F838 2E00      0153       LD      L,00H                ;FIND END OF MEMORY
F83A 46        0154 TESTM:  LD      B,(HL)              ;SAVE MEMORY
F83B 97        0155       SUB      A                  ;TEST LOCATION
F83C 77        0156 TESTM1: LD      (HL),A
F83D BE        0157       CP      (HL)
F83E 2007      0158       JR      NZ,MERR              ;BAD LOCATION
F840 3C        0159       INC      A                  ;NEXT PATTERN
F841 20F9      0160       JR      NZ,TESTM1            ;TEST WITH IT
F843 70        0161       LD      (HL),B              ;RESTORE MEMORY
F844 24        0162       INC      H                  ;NEXT PAGE
F845 18F3      0163       JR      TESTM
F847 224800    0164 MERR:  LD      (TOPRAM),HL          ;SAVE MAX RAM ADDR
F84A 227500    0165       LD      (SPSAV),HL          ;SET DEFAULT SP AT TOP
F84D FF        0166       RST      38H                ;TRANSFER TO MONITOR LOOP
              0167 ;
              0168 ;I/O DRIVER ROUTINES FOLLOW
              0169 ;
              0170 ;CONST - SEE IF USER HAS TYPED A CHARACTER ON THE CONSOLE
              0171 ;INPUTS - NONE
              0172 ;OUTPUTS - A=CHARACTER IF CHARACTER READY
              0173 ; A=00H IF NO CHARACTER READY
              0174 ;DESTROYS - A,FLAGS
              0175 ;

```