

TUSCAN 2K MONITOR  
ADDR CODE

STMT SOURCE STATEMENT

TCL Z80 ASSEMBLER PAGE 0004

```

F84E CD62F8 0176 CONST: CALL ACONST ;ELSE GET STATUS
F851 C8 0177 RET Z ;NO
F852 CD8AF8 0178 CALL CONIN ;YES, READ CHAR
F855 FE13 0179 CP XOFF ; ^S?
F857 C0 0180 RET NZ ;FLAG READY (A=CHAR)
F858 CD8AF8 0181 CALL CONIN ;WAIT FOR NEXT CHAR
F85B FE03 0182 CP ETX ;WAS IT ^C?
F85D CA3800 0183 JP Z,RST7 ;YES, RESTART MONITOR
F860 AF 0184 XOR A ;ELSE IGNORE CHAR
F861 C9 0185 RET ;AND RESUME
0186 ;
F862 3A0300 0187 ACONST: LD A, (IOBYTE) ;SEE WHICH INPUT DEVICE
F865 E630 0188 AND 30H ;ONLY WANT CONSOLE BITS
F867 2819 0189 JR Z,RSST ;RS232, ELSE ONBOARD KBD
F869 E5 0190 PUSH HL
F86A C5 0191 PUSH BC
F86B 214000 0192 LD HL,CHBUFF ;PTR TO CHARACTER BUFFER
F86E DB05 0193 IN A, (KBD)
F870 47 0194 LD B,A
F871 AE 0195 XOR (HL) ;SAVE KEYBOARD DATA
F872 FC79F8 0196 CALL M,KEYP ;SEE IF STROBE CHANGED
F875 AF 0197 XOR A ;SEE WHICH WAY
F876 C1 0198 EXCONS: POP BC ;NO, NO NEW KEY
F877 E1 0199 POP HL
F878 C9 0200 RET
F879 78 0201 KEYP: LD A,B ;RESTORE DATA
F87A 70 0202 LD (HL),B ;STORE IT (& STROBE)
F87B B7 0203 OR A ;STROBE HIGH?
F87C F0 0204 RET P ;NO
F87D E1 0205 POP HL ;YES, STAY HERE
F87E F6FF 0206 KRDY: OR 0FFH ;SAY KEY READY
F880 18F4 0207 JR EXCONS
0208 ;
F882 DB00 0209 RSST: IN A, (RSS) ;GET RS232 STATUS
F884 E601 0210 AND 01H ;DAV?
F886 C8 0211 RET Z ;NO, RETURN ZERO
F887 F6FF 0212 OR 0FFH ;YES, RETURN FFH
F889 C9 0213 RET
0214 ;
0215 ;CONIN - GET CHARACTER FORM CONSOLE
0216 ;INPUTS - NONE
0217 ;OUTPUTS - A= CHARACTER (BIT 7 =0)
0218 ;DESTROYS - A, FLAGS
0219 ;
F88A 3A0300 0220 CONIN: LD A, (IOBYTE) ;SEE WHICH INPUT
F88D E630 0221 AND 30H ;ONLY WANT CONSOLE BITS
F88F 2828 0222 JR Z,RSIN ;RS232, ELSE USE ONBOARD KB.D
F891 3A4000 0223 LD A, (CHBUFF) ;CHAR READY?
F894 FE81 0224 CP 81H ;IE STROBE HIGH
F896 3005 0225 JR NC,GOTCH ;AND NOT NULL
F898 CD62F8 0226 KWAIT: CALL ACONST ;IF NOT WAIT FOR CHAR
F89B 28FB 0227 JR Z,KWAIT
F89D 3A4000 0228 GOTCH: LD A, (CHBUFF) ;GET CHAR
F8A0 E67F 0229 CASLOC: AND 7FH ;RESET BIT 7
F8A2 C5 0230 PUSH BC
F8A3 47 0231 LD B,A
F8A4 3E80 0232 LD A,80H ;SAVE CHAR
F8A6 324000 0233 LD (CHBUFF),A ;SIGNAL CHAR READ

```