

TUSCAN 2K MONITOR		TCL Z80 ASSEMBLER PAGE 0005	
ADDR	CODE	STMT	SOURCE STATEMENT
F8A9	3A7D00	0234	LD A, (LOCKSW) ;SEE IF ALPHA LOCK ON
F8AC	A7	0235	AND A
F8AD	78	0236	LD A,B ;RESTORE CHAR ETC
F8AE	C1	0237	POP BC
F8AF	C8	0238	RET Z ;LOCK OFF
F8B0	FE61	0239	UCMASK: CP 'A'+20H ;A..Z?
F8B2	D8	0240	RET C ;NO
F8B3	FE7B	0241	CP 'Z'+1+20H
F8B5	D0	0242	RET NC ;NO
F8B6	D620	0243	SUB 20H ;YES, CONVERT TO UC
F8B8	C9	0244	RET
		0245	;
F8B9	CD82F8	0246	RSIN: CALL RSST ;SEE IF READY
F8BC	28EB	0247	JR Z,RSIN ;WAIT
F8BE	DB01	0248	IN A, (RSDI) ;GET CHARACTER
F8C0	18DE	0249	JR CASLOCK ;CHECK FOR CASE LOCK
		0250	;
		0251	;TAPE - SR TO READ A BYTE FROM THE TAPE, FLAG ERRORS
		0252	; AND CHECK FOR AN ABORT (CONTROL C)
		0253	;INPUTS - NONE
		0254	;OUTPUTS- A=BYTE READ FROM TAPE IF NO ERROR OCCURED
		0255	PAR1=PAR1
		0256	A='?' IF AN ERROR OCCURED
		0257	PAR1='?'
		0258	PRINTS '?' ON CONSOLE IF AN ERROR OCCURS
		0259	*** ABORTS TO MONITOR IF CONTROL C IS TYPED ***
		0260	;DESTROYS-B, FLAGS
		0261	;
F8C2	CD4EF8	0262	TAPE: CALL CONST ;CHECK FOR ABORT
F8C5	CDD3F9	0263	CALL READER ;READ BYTE
F8C8	47	0264	LD B,A ;SAVE IT
F8C9	DB02	0265	IN A, (TAPES) ;GET UART STATUS
F8CB	E60E	0266	AND 0EH ;CHECK FOR ERRORS
F8CD	78	0267	LD A,B ;RESTORE BYTE
F8CE	C8	0268	RET Z ;NO ERRORS
F8CF	3E3F	0269	LD A, '?' ;FLAG ERROR
F8D1	324A00	0270	LD (PAR1),A ;TO CONSOLE TOO
		0271	;
		0272	;
		0273	;CONOUT - OUTPUT CHARACTER TO USERS CONSOLE
		0274	;INPUTS - A= CHARACTER
		0275	;OUTPUTS - NONE
		0276	;DESTROYS - X'
		0277	;
F8D4	D9	0278	CONOUT: EXX
F8D5	F5	0279	PUSH AF
F8D6	FE09	0280	CP TAB ;TAB?
F8D8	200C	0281	JR NZ, DISCH ;NO
F8DA	3E20	0282	TABON: LD A, SPAC ;SPACE INSTEAD
F8DC	CDECF8	0283	CALL CHOUT ;SEND
F8DE	3A4200	0284	LD A, (CHCNT) ;GET CHARACTER POSITION
F8E2	E607	0285	AND 7 ;MULTIPLE OF 8?
F8E4	20F4	0286	JR NZ, TABON ;NO, CONTINUE SPACING
F8E6	CDECF8	0287	DISCH: CALL CHOUT
F8E9	F1	0288	POP AF
F8EA	D9	0289	EXX
F8EB	C9	0290	RET
		0291	;