

TUSCAN 2K MONITOR		TCL Z80 ASSEMBLER PAGE 0008			
ADDR	CODE	STMT	SOURCE	STATEMENT	
F9AC	FE40	0408	CP	40H	;ONBOARD VDU
F9AE	CA2BF9	0409	JP	Z,VDUOUT	
F9B1	DB07	0410	WTPHS: IN	A,(PRINTHS)	;WAIT FOR HANDSHAKE
F9B3	E601	0411	AND	1H	;BIT 0
F9B5	20FA	0412	JR	NZ,WTPHS	;WAIT FOR LOW LEVEL
F9B7	79	0413	LD	A,C	
F9B8	D303	0414	OUT	(PRINT),A	;OUTPUT 8 BIT DATA
F9BA	AF	0415	XOR	A	;STROBE LOW
F9BB	D307	0416	OUT	(PRINTST),A	
F9BD	2F	0417	CPL		;STROBE HIGH
F9BE	D307	0418	OUT	(PRINTST),A	
F9C0	79	0419	LD	A,C	;RESTORE CHAR
F9C1	C1	0420	POP	BC	
F9C2	C9	0421	RET		
		0422			
		0423	PUNHL	- SR TO TO OUTPUT THE DOUBLE BYTE IN HL TO TAPE	
		0424	INPUTS	- HL = WORD TO OUTPUT	
		0425	OUTPUTS	- 2 BYTES ON TAPE <L>,<H>	
		0426	DESTROYS	- A	
		0427			
F9C3	7D	0428	PUNHL: LD	A,L	;SEND <L> FIRST
F9C4	CDC8F9	0429	CALL	PUNCH	
F9C7	7C	0430	LD	A,H	;THEN SEND <H>
		0431			
		0432	PUNCH	- OUTPUT BYTE TO MODEM (TAPE)	
		0433	INPUTS	- A= BYTE TO BE SENT	
		0434	OUTPUTS	- NONE	
		0435	DESTROYS	- NOTHING	
		0436			
F9C8	F5	0437	PUNCH: PUSH	AF	;SAVE BYTE
F9C9	DB02	0438	PUNCH: IN	A,(TAPES)	;GET STATUS OF UART
F9CB	E610	0439	AND	10H	;TBMT ASSERTED?
F9CD	28FA	0440	JR	Z,PUNCHL	;NO, WAIT
F9CF	F1	0441	POP	AF	;GET CHAR
F9D0	D301	0442	OUT	(TAPEDO),A	;SEND IT
F9D2	C9	0443	RET		
		0444			
		0445	READER	- ROUTINE TO READ BYTE FROM MODEM	
		0446	INPUTS	- NONE	
		0447	OUTPUTS	- A= BYTE READ	
		0448	DESTROYS	- A,FLAGS	
		0449			
F9D3	DB02	0450	READER: IN	A,(TAPES)	;GET STATUS
F9D5	E601	0451	AND	1H	;DAV ASSERTED?
F9D7	28FA	0452	JR	Z,READER	;NO, WAIT
F9D9	DB03	0453	IN	A,(TAPEDI)	;READ BYTE
F9DB	C9	0454	RET		
		0455			
		0456	GETIBUF	- SR TO LOAD THE MONITOR BUFFER	
		0457	INPUTS	- NONE	
		0458	OUTPUTS	- INBUFF = BUFFERED LINE	
		0459		- BUFPTR = BUFFIN+1 (NO CHARS READ)	
		0460	DESTROYS	- ALL REGISTERS	
		0461			
F9DC	118600	0462	GETIBUF: LD	DE,INBUFF+1	;PTR TO BUFFER
F9DE	ED534600	0463	LD	(BUFPTR),DE	;RESET PTR
F9E3	1B	0464	DEC	DE	
F9E4	3E50	0465	LD	A,BUFSIZ	;SET LENGTH BYTE