

TUSCAN 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0009

ADDR	CODE	STMT	SOURCE STATEMENT
F9E6	12	0466	LD (DE),A
		0467	
		0468	;LOAD BUFFER
		0469	;BUFFIN - ROUTINE TO READ A LINE INTO AN INPUT BUFFER
		0470	- EXPANDS TABS TO EVERY 8TH COLUMN. FULLY SUPPORTS
		0471	- DELETE AND LINE CANCEL (^U). PRINTER TURNED
		0472	- ON/OFF BY ^P. KEYBOARD ALPHA-LOCK TURNED ON/OFF
		0473	- BY ^A. ^C AS THE FIRST CHARACTER WILL CAUSE
		0474	- A SYSTEM RESTART.
		0475	- BACKSPACE IS TREATED AS A DELETE. THE LINE
		0476	- CAN BE TERMINATED BY A CR OR AN LF CODE. BOTH
		0477	- ARE TREATED AS A CR WHEN THEY ARE ENTERED IN
		0478	- THE BUFFER.
		0479	;INPUTS - DE = PTR TO INPUT BUFFER
		0480	(DE) = LENGTH OF BUFFER
		0481	;OUTPUTS- (DE+1...) = INPUT LINE
		0482	;DESTROYS-ALL REGISTERS
		0483	
F9E7	EB	0484	BUFFIN: EX DE,HL ;HL=PTR TO BUFFER
F9E8	4E	0485	LD C,(HL) ;C=MAX BUFFER LENGTH
F9E9	0D	0486	DEC C ;ALLOW FOR <CR>
F9EA	3A4200	0487	LD A,(CHCNT) ;GET END OF PROMPT POS
F9EB	324300	0488	LD (PRMP),A ;REMEMBER IT FOR DELTAB
F9EC	224400	0489	LD (BUFAD),HL ;PTR TO TEXT AREA
F9ED	0600	0490	LINLOOP:LD B,0 ;B=CURRENT LENGTH=0
F9EE	CD8AF8	0491	CHLOOP: CALL CONIN ;GET CHARACTER
F9EF	FE0A	0492	CP LF ;LF?
F9F0	2859	0493	JR Z,GOTBUF ;YES,DONE
F9F1	FE0D	0494	CP CR ;CR?
F9F2	2855	0495	JR Z,GOTBUF ;YES,DONE
F9F3	FE7F	0496	CP DEL ;DELETE?
F9F4	2010	0497	JR NZ,NODEL
F9F5	78	0498	DELET: LD A,B ;GET CURRENT BUFF LENGTH
F9F6	B7	0499	OR A ;=0?
F9F7	28ED	0500	JR Z,CHLOOP ;YES,IGNORE
F9F8	7E	0501	LD A,(HL) ;GET CHAR TO DELETE
F9F9	05	0502	DEC B ;BACKUP CTR & PTR
F9FA	2B	0503	DEC HL
F9FB	E5	0504	PUSH HL
F9FC	C5	0505	PUSH BC
F9FD	CD59FA	0506	CALL DELETE ;DO DELETION
F9FE	C1	0507	POP BC
F9FF	EB	0508	POP HL
F9A0	18E1	0509	JR CHLOOP ;GET REPLACEMENT
F9A1	FE08	0510	NODEL: CP BS ;BS?
F9A2	28EC	0511	JR Z,DELET ;TREAT AS DELETE
F9A3	FE15	0512	CP 15H ;^U?
F9A4	2011	0513	JR NZ,NOCAN ;NO
F9A5	3A4300	0514	LINDEL: LD A,(PRMP) ;FIND PROMPT POSITION
F9A6	214200	0515	LD HL,CHCNT ;PTR TO CURSOR NOW
F9A7	BE	0516	CP (HL) ;SAME?
F9A8	2A4400	0517	LD HL,(BUFAD) ;RESET BUFFER PTR
F9A9	30CB	0518	JR NC,LINLOOP
F9AA	CD96FA	0519	CALL ERA ;NO,DELETE ONE CHAR
F9AB	18EF	0520	JR LINDEL
F9AC	FE10	0521	NOCAN: CP 10H ;^P?
F9AD	2008	0522	JR NZ,NOTOG
F9AE	117C00	0523	LD DE,PRNTSW ;PTR TO SWITCH