

| TUSCAN 2K MONITOR |        | TCL Z80 ASSEMBLER PAGE 0010 |                                                |
|-------------------|--------|-----------------------------|------------------------------------------------|
| ADDR              | CODE   | STMT                        | SOURCE STATEMENT                               |
| FA34              | 1A     | 0524                        | TOGSW: LD A, (DE) ;GET IT                      |
| FA35              | 2F     | 0525                        | CPL ;TOGGLE IT                                 |
| FA36              | 12     | 0526                        | LD (DE), A                                     |
| FA37              | 18BC   | 0527                        | JR CHLOOP ;GET NEXT CHAR                       |
| FA39              | FE01   | 0528                        | NOTOG: CP 01H ;A (ALPHA LOCK)?                 |
| FA3B              | 2005   | 0529                        | JR NZ, NOLOCK ;NO                              |
| FA3D              | 117D00 | 0530                        | LD DE, LOCKSW ;GET SWITCH                      |
| FA40              | 18F2   | 0531                        | JR TOGSW ;TOGGLE SWITCH                        |
| FA423             |        | 0532                        | NOLOCK: INC HL ;MUST BE ORDINARY CHAR          |
| FA43              | 77     | 0533                        | LD (HL), A ;SAVE IT IN BUFF                    |
| FA44              | CDD4F8 | 0534                        | CALL CONOUT ;ECHO CHAR                         |
| FA47              | 04     | 0535                        | INC B ;BUMP CTR                                |
| FA48              | FE03   | 0536                        | CP ETX ;C?                                     |
| FA4A              | 78     | 0537                        | LD A, B ;FIRST CHARACTER?                      |
| FA4B              | 2005   | 0538                        | JR NZ, LENTST ;NOT ^C                          |
| FA4D              | FE01   | 0539                        | CP 1                                           |
| FA4F              | CA3800 | 0540                        | JP Z, RST7 ;RESTART IF SO                      |
| FA52              | B9     | 0541                        | LENTST: CP C ;BUFFER FULL?                     |
| FA53              | 38A0   | 0542                        | JR C, CHLOOP ;NO                               |
| FA55              | 23     | 0543                        | GOTBUF: INC HL ;PTR TO NEXT FREE               |
| FA56              | 360D   | 0544                        | LD (HL), CR ;MARK END OF BUFFER                |
| FA58              | C9     | 0545                        | RET                                            |
|                   |        | 0546                        | ;                                              |
| FA59              | A7     | 0547                        | DELETE: AND A ;NULL?                           |
| FA5A              | C8     | 0548                        | RET Z ;IGNORE                                  |
| FA5B              | FE04   | 0549                        | CP EOT ;EOT?                                   |
| FA5D              | C8     | 0550                        | RET Z                                          |
| FA5E              | 4F     | 0551                        | LD C, A ;SAVE CHAR                             |
| FA5F              | E6EF   | 0552                        | AND 0EFH                                       |
| FA61              | FE0B   | 0553                        | CP 0BH                                         |
| FA63              | C8     | 0554                        | RET Z                                          |
| FA64              | FE0C   | 0555                        | CP FF                                          |
| FA66              | C8     | 0556                        | RET Z                                          |
| FA67              | 79     | 0557                        | LD A, C ;RESTORE CHAR                          |
| FA68              | E1     | 0558                        | HL ;UNSTACK RETURN ADDR                        |
| FA69              | C1     | 0559                        | POP BC ;TO GET AT BC                           |
| FA6A              | C5     | 0560                        | PUSH BC ;B= # OF CHARS IN BUFFER               |
| FA6B              | E5     | 0561                        | PUSH HL ;STACK RESTORED                        |
| FA6C              | 2A4400 | 0562                        | LD HL, (BUFAD) ;GET BUFFER ADDRESS             |
| FA6F              | 3A4300 | 0563                        | LD A, (PRMP) ;GET END OF PROMPT                |
| FA72              | 4F     | 0564                        | LD C, A ;C=CURSOR POSITION AFTER DELETE        |
| FA73              | 78     | 0565                        | CALPOS: LD A, B ;SEE IF MORE CHARS TO DELETE   |
| FA74              | A7     | 0566                        | AND A                                          |
| FA75              | 280B   | 0567                        | JR Z, DELCNT ;NO, SEE HOW FAR TO BS            |
| FA77              | 23     | 0568                        | INC HL ;BUMP PTR                               |
| FA78              | 7E     | 0569                        | LD A, (HL) ;GET CHAR FROM BUFFER               |
| FA79              | 05     | 0570                        | DEC B ;DEC COUNT TO BE READ                    |
| FA7A              | 0C     | 0571                        | INC C ;BUMP NEW POSITION                       |
| FA7B              | FE09   | 0572                        | CP TAB ;IS THIS A TAB?                         |
| FA7D              | CC8FFA | 0573                        | CALL Z, TABPOS ;YES, MOVE TO NEXT TAB          |
| FA80              | 18F1   | 0574                        | JR CALPOS ;YES                                 |
| FA82              | 3A4200 | 0575                        | DELCNT: LD A, (CHCNT) ;GET OLD CURSOR POSITION |
| FA85              | 91     | 0576                        | SUB C ;SUBTRACT NEW                            |
| FA86              | F5     | 0577                        | ERACH: PUSH AF ;A=# OF CHARS TO BACKUP         |
| FA87              | CD96FA | 0578                        | CALL ERA ;BACK SPACE                           |
| FA8A              | F1     | 0579                        | POP AF                                         |
| FA8B              | 3D     | 0580                        | DEC A ;UNTIL A=0                               |
| FA8C              | 20F8   | 0581                        | JR NZ, ERACH ;DONE! (NOT THAT BAD?)            |