

TUSCAN 2K MONITOR TCL Z80 ASSEMBLER PAGE 0013

ADDR	CODE	SIMT	SOURCE STATEMENT
FB17	C5	0698	BLANK: PUSH BC
FB18	0E28	0699	LD C,40 ;WAIT 5-10 SECONDS
FB1A	06FA	0700	D250: LD B,250
FB1C	CD78F9	0701	CALL DBMS ;DELAY LOOP
FB1F	0D	0702	DEC C
FB20	20F8	0703	JR NZ,D250 ;OUTER LOOP
FB22	C1	0704	POP BC
FB23	C9	0705	RET
		0706	;
		0707	;DPCMP - SR TO COMPARE HL AND DE
		0708	;INPUTS - HL,DE NUMBERS TO BE COMPARED
		0709	;OUTPUTS- FLAGS <- HL-DE
		0710	;DESTROYS-NOTHING
		0711	;
FB24	E5	0712	DPCMP: PUSH HL ;SAVE REGISTERS
FB25	B7	0713	OR A ;RESET CY
FB26	ED52	0714	SBC HL,DE ;DO COMPARE
FB28	E1	0715	POP HL
FB29	C9	0716	RET
		0717	;
		0718	;READ - FUNCTION TO READ A NAMED TAPE FILE INTO
		0719	MEMORY. THE COMMAND FORMAT IS :
		0720	RNAME WHERE NAME IS THE FILE NAME
		0721	WHEN A NAME IS FOUND ON THE TAPE IT IS DISPLAYED
		0722	ON THE CONSOLE. IF IT IS NOT THE REQUIRED NAME
		0723	THE CURSOR DROPS TO THE NEXT LINE AND THE SEARCH
		0724	CONTINUES. IF THE NAME IS THE DESIRED ONE THEN
		0725	THE CURSOR IS LEFT AT THE END OF THE NAME AND THE
		0726	FILE IS LOADED. DURING THE LOADING, THE UART STATUS
		0727	BITS ARE TESTED TO ENSURE NO ERRORS OCCURED. IF AN
		0728	ERROR IS DETECTED, THEN A '?' IS PRINTED ON THE
		0729	CONSOLE. THE LOAD CAN BE ABORTED BY TYPEING A
		0730	CONTROL C.
		0731	;
FB2A	2A4600	0732	READ: LD HL,(BUFPTR) ;GET PTR TO NAME
FB2D	44	0733	LD B,H ;PTR IN BC
FB2E	4D	0734	LD C,L
		0735	;LOAD FILE
		0736	;
		0737	;FILIN - SR TO LOAD A FILE FROM TAPE
		0738	;INPUTS - BC = PTR TO NAME (TERMINATED BY CR)
		0739	;OUTPUTS- HL = START ADDR OF FILE LOADED
		0740	DE = END ADDR OF FILE LOADED
		0741	Z FLAG = 1 IF GOOD LOAD
		0742	Z FLAG = 0 IF ERROR OCCURED
		0743	;DESTROYS-ALL REGISTERS
		0744	;
FB2F	60	0745	FILIN: LD H,B ;SAVE ADDR OF NAME
FB30	69	0746	LD L,C
FB31	224400	0747	LD (BUFAD),HL
FB34	11B7FF	0748	LD DE,TPROMP ;SAY FILES FOUND
FB37	CDA1FA	0749	CALL BUFPTR
FB3A	CDB0FA	0750	GETFIL: CALL CRLE
FB3D	2A4400	0751	LD HL,(BUFAD) ;PTR TO FILE NAME
FB40	0620	0752	GETLDR: LD B,32 ;MUST FIND 32 LEADER BYTES
FB42	CDD3F9	0753	GETLD: CALL READER ;READ BYTE
FB45	FE0D	0754	CP CR ;LEADER BYTE?
FB47	20F7	0755	JR NZ,GETLDR ;NO,START AGAIN