

TUSCAN 2K MONITOR		TCL Z80 ASSEMBLER PAGE 0014			
ADDR	CODE	STMT	SOURCE	STATEMENT	
FB49	05	0756	DEC	B	;COUNT BYTE
FB4A	20F6	0757	JR	NZ,GETLD	;UNTIL FOUND ENOUGH
FB4C	CDD3F9	0758	WAITMRK:CALL	READER	;LOOK FOR END OF
FB4F	A7	0759	AND	A	;LEADER MARKER (00H)
FB50	20FA	0760	JR	NZ,WAITMRK	
FB52	CDD3F9	0761	CALL	READER	;GET HEADER LENGTH
FB55	47	0762	LD	B,A	
FB56	CDD3F9	0763	GETHDR:CALL	READER	;READ HEADER
FB59	CDD4F8	0764	CALL	CONOUT	;PRINT IT ON CONSOLE
FB5C	BE	0765	CP	(HL)	;MATCH WANTED HEADER?
FB5D	2031	0766	JR	NZ,PRTHDR	;NO,PRINT REST
FB5F	05	0767	DEC	B	;END OF TAPE HEADER?
FB60	23	0768	INC	HL	;PTR TO NEXT NAME CHAR
FB61	20F3	0769	JR	NZ,GETHDR	;NOT END
FB63	7E	0770	LD	A,(HL)	;CHECK END OF NAME
FB64	FE0D	0771	CP	CR	
FB66	20D2	0772	JR	NZ,GETFIL	;NOT,SO NO MATCH
FB68	AF	0773	XOR	A	;NO TAPE ERRORS YET
FB69	324A00	0774	LD	(PAR1),A	;RESET FLAG
FB6C	CDD3F9	0775	CALL	READER	;GET TYPE (AND IGNORE)
FB6F	CDC2F8	0776	CALL	TAPE	;GET START ADDR
FB72	6F	0777	LD	L,A	
FB73	CDC2F8	0778	CALL	TAPE	
FB76	67	0779	LD	H,A	
FB77	E5	0780	PUSH	HL	;SAVE START ADDR
FB78	CDC2F8	0781	CALL	TAPE	;GET END ADDR
FB7B	5F	0782	LD	E,A	
FB7C	CDC2F8	0783	CALL	TAPE	
FB7F	57	0784	LD	D,A	
FB80	CDC2F8	0785	LDFIL:CALL	TAPE	;GET DATA BYTE
FB83	77	0786	LD	(HL),A	;PUT INTO MEMORY
FB84	CD24FB	0787	CALL	DPCMP	;END OF FILE?
FB87	23	0788	INC	HL	;PTR TO NEXT FREE
FB88	20F6	0789	JR	NZ,LDFIL	;NOT END
FB8A	E1	0790	POP	HL	;RESTORE START ADDR
FB8B	3A4A00	0791	LD	A,(PAR1)	;SEE IF ANY ERRORS
FB8E	A7	0792	AND	A	;SET Z FLAG (Z=1 FOR NONE,
FB8F	C9	0793	RET		;Z=0 FOR ERRORS)
		079			
FB90	05	0795	PRTHDR:DEC	B	;SEE IF END OF HEADER
FB91	28A7	0796	JR	Z,GETFIL	;YES,GET NEXT HEADER
FB93	CDD3F9	0797	CALL	READER	;GET NEXT CHAR
FB96	CDD4F8	0798	CALL	CONOUT	;PRINT IT
FB99	18F5	0799	JR	PRTHDR	;LOOP TO END
		0800			
		0801			;UTILITY ROUTINES FOR THE MONITOR FUNCTIONS FOLLOW
		0802			
		0803			;GETCH - SR TO READ A CHARACTER FROM THE INPUT BUFFER
		0804			;INPUTS - NONE
		0805			;OUTPUTS - A=CHAR
		0806			;DESTROYS- NOTHING
		0807			
FB9B	E5	0808	GETCH: PUSH	HL	
FB9C	2A4600	0809	LD	HL,(BUFPTR)	;GET BUFFER POINTER
FB9F	7E	0810	LD	A,(HL)	;GET CHAR
FBA0	23	0811	INC	HL	;BUMP PTR
FBA1	224600	0812	LD	(BUFPTR),HL	;SAVE NEW POINTER
FBA4	E1	0813	POP	HL	