

TUSCAN 2K MONITOR  
ADDR CODE STMT SOURCE STATEMENT

TCL Z80 ASSEMBLER PAGE 0015

```

FBA5 C9      0814      RET
0815      ;
0816      ;GETUCT - SR TO GET A CHARACTER AND TEST IT FOR A TERMINATOR
0817      ; ( A TERMINATOR IS A COMMA, AN '^' OR A <CR>)
0818      ; RETURNS UPPER CASE LETTERS ONLY
0819      ;INPUTS - NONE
0820      ;OUTPUTS- A=CHARACTER READ (MASKED TO UPPER CASE)
0821      ; - CY FLAG = 1 FOR TERMINATOR
0822      ; - CY FLAG = 0 FOR OTHER CHARS
0823      ;DESTROYS - FLAGS
0824      ;
FBA6 CD9BFB 0825      GETUCT: CALL    GEICH      ;GET CHARACTER
FBA9 CDB0F8 0826      CALL    UCMASK     ;MASK TO UPPER CASE
FBAC FE2C    0827      TERM:   CP      ','      ;TERMINATOR?
FBAE 37      0828      SCF
FBAF C8      0829      RET      Z           ;YES,CY=1
FBB0 FE0D    0830      CP      CR
FBB2 37      0831      SCF
FBB3 C8      0832      RET      Z           ;YES,CY=1
FBB4 FE5E    0833      CP      '^'
FBB6 37      0834      SCF
FBB7 C8      0835      RET      Z           ;YES,CY=1
FBB8 3F      0836      CCF
FBB9 C9      0837      RET           ;NO,CY=0
0838      ;
0839      ;GETDEC - SR TO GET A CHARACTER AND TEST IT FOR A VALID
0840      ; DECIMAL DIGIT. RETURNS IF SO, ELSE COMPLAINS
0841      ; AND RE-INITIALISES. CY SET TO INDICATE TERMINATOR
0842      ;GETHEX - AS ABOVE BUT TESTS FOR HEX INSTEAD OF DECIMAL
0843      ;INPUTS - NONE
0844      ;OUTPUTS- A=DIGIT (BINARY VALUE) OR TERMINATOR
0845      ; - CY=1 IF TERMINATOR
0846      ; - CY=0 OTHERWISE
0847      ; - DOES NOT RETURN IF INVALID DIGIT!!
0848      ; (NB ERROR CAN BE TRAPPED AT RST 38H LOCATION
0849      ; SEE PARER FOR DETAILS)
0850      ;DESTROYS- FLAGS
0851      ;
FBBA CDA6FB 0852      GETDEC: CALL    GETUCT     ;GET CHARACTER
FBBD D8      0853      RET      C           ;GOT TERMINATOR
FBBE D630    0854      DECCHK: SUB    '0'      ;TEST FOR 0..9
FBC0 381C    0855      JR      C,PARER
FBC2 FE0A    0856      CP      9+1
FBC4 3F      0857      CCF
FBC5 D0      0858      RET      NC
FBC6 1816    0859      JR      PARER
0860      ;
FBC8 CDA6FB 0861      GETHEX: CALL    GETUCT     ;GET UC CHAR
FBCB D8      0862      RET      C           ;GOT TERMINATOR
FBCC D630    0863      HEXCHK: SUB    '0'      ;0..9 OR A..F
FBCE 380E    0864      JR      C,PARER
FBD0 FE0A    0865      CP      9+1
FBD2 3F      0866      CCF
FBD3 D0      0867      RET      NC
FBD4 D607    0868      SUB    'A'-'0'-10
FBD6 FE0A    0869      CP      10
FBD8 3804    0870      JR      C,PARER
FBDA FE10    0871      CP      16

```