

TUSCAN 2K MONITOR
ADDR CODE

TCL Z80 ASSEMBLER PAGE 0016

SMT SOURCE STATEMENT

```

FBDC 3F      0872      CCF
FBDD D0      0873      RET      NC      ;ELSE FALL INTO PARER
0874 ;
0875 ;PARER - ROUTINE TO DEAL WITH ERRORS IN PARAMETERS
0876 ; IT PRINTS THE PART OF THE BUFFER THAT WAS READ
0877 ; UPTO THE ERRONEOUS CHARACTER, FOLLOWED BY
0878 ; A '?' AND THEN RETURNS TO THE MONITOR VIA A
0879 ; RST 38H INSTRUCTION. THIS CAN BE INTERCEPTED BY
0880 ; SETTING UP THE VECTOR WITH A NEW ONE. IT SHOULD
0881 ; BE NOTED THAT THE VALUE OF THE SP IS UNPREDICTABLE
0882 ; WHEN THIS ROUTINE IS ENTERED AND SO ANY RECOVERY
0883 ; ROUTINES SHOULD TAKE THIS INTO ACCOUNT.
0884 ; INPUTS - INBUFF = LINE CONTAINING ERROR
0885 ;          BUFPTR = POINTS TO ERRORNEOUS CHARACTER
0886 ; OUTPUTS- NONE
0887 ; DESTROYS- HL,DE,A,FLAGS, ****SP****
0888 ;
FBDE 2A4600  0889 PARER: LD      HL,(BUFPTR) ;PTR TO NEXT CHARACTER
FBE1 2B      0890      DEC     HL      ;BACK UP TO ERROR
FBE2 363F    0891      LD      HL,'?' ;MARK ERROR
FBE4 23      0892      INC     HL
FBE5 3604    0893      LD      HL,EOT ;MARK END OF BUFFER
FBE7 118600  0894      LD      DE,INBUFF+1 ;PTR TO INPUT LINE
FBEA CD1FA   0895      CALL    BUFPTR ;PRINT BUFFER
FBED FF      0896      RST     38H ;RESTART MONITOR
0897 ;
0898 ;MODPAR - SR TO PRINT THE VALUE OF A PARAMETER IN A
0899 ; AND TO READ A NEW VALUE IN FROM THE KEYBOARD TO HL.
0900 ; INPUTS - A=BYTE TO PRINT
0901 ; OUTPUTS- HL=PARAMETER READ
0902 ;          A=TERMINATOR
0903 ;          CY=0 IF PARAMETER READ
0904 ;          CY=1 IF NO PARAMETER READ
0905 ; DESTROYS-ALL REGISTERS
0906 ;
FBEE CD91FC  0907 MODPAR: CALL    PRTASP ;PRINT OLD PARAMETER
0908 ; ;GET NEW ONE
0909 ;
0910 ;READPAR- SR TO READ IN A PARAMETER FROM THE KEYBOARD INTO HL
0911 ; INPUTS - NONE
0912 ; OUTPUTS- HL=PARAMETER READ
0913 ;          A=TERMINATOR
0914 ;          CY=0 IF PARAMETER READ
0915 ;          CY=1 IF NO PARAMETER READ
0916 ; DESTROYS-ALL REGISTERS
0917 ;
FBF1 CDDCF9  0918 READPAR:CALL    GETBUF ;READ BUFFER FROM KBD
0919 ; ;EXTRACT PARAMETER
0920 ;
0921 ;PARAM - SR TO LOAD A 16 BIT PARAMETER INTO HL
0922 ; PARAMETER CAN BE ASCII LITERAL CHARACTER (EG 'A')
0923 ; OR UNSIGNED DECIMAL NUMBER (EG £127)
0924 ; OR UNSIGNED HEX NUMBER (EG A75F)
0925 ; NUMBERS ARE CALCULATED MODULO 65536
0926 ; INPUTS- NONE
0927 ; OUTPUTS - HL=NUMBER READ FROM BUFFER
0928 ;          A= TERMINATOR (COMMA OR <CR>)
0929 ;          - CY = 0 IF PARAMETER READ

```