

TUSCAN 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0018

ADDR	CODE	STMT	SOURCE STATEMENT
FC3A	224A00	0988	LD (PAR1),HL ;SAVE IT
FC3D	FE2C	0989	CP ;EXPECT ANOTHER?
FC3F	08	0990	EX AF,AF' ;COUNT 1ST ONE
FC40	3C	0991	INC A
FC41	08	0992	EX AF,AF'
FC42	2009	0993	JR NZ,ALLREAD ;NO MORE
FC44	CDF4FB	0994	CALL PARAM ;GET 2ND PARAMETER
FC47	224C00	0995	LD (PAR2),HL ;SAVE IT (EVEN IF DEFAULT)
FC4A	08	0996	EX AF,AF'
FC4B	3C	0997	INC A
FC4C	08	0998	EX AF,AF'
FC4D	08	0999	ALLREAD: EX AF,AF' ;GET # OF PARAMETERS TO A
FC4E	324E00	1000	LD (NPARS),A ;SAVE # OF PARAMETERS READ
FC51	08	1001	EX AF,AF' ;A=LAST TERMINATOR ('', ' OR CR)
FC52	C9	1002	RET
		1003	;
		1004	;PCHECK - SR TO LOAD 1 OR 2 PARAMETERS INTO PAR1 & PAR2
		1005	IF NO PARAMETER IS FOUND THEN AN ERROR MESSAGE
		1006	IS PRINTED AND A JUMP MADE TO THE MONITOR LOOP.
		1007	;INPUTS - NONE
		1008	;OUTPUTS- NPARS = # OF PARAMETERS READ (1 OR 2)
		1009	PAR1 = 1ST PARAMETER READ
		1010	PAR2 = 2ND PARAMETER READ (IF ANY)
		1011	A = LAST TERMINATOR FOUND
		1012	;DESTROYS-AF',AF,HL,DE,BC (MAY ABORT VIA PARER IF AN
		1013	ERROR OCCURS IN A PARAMETER OR IF NO PARAMETER
		1014	IS FOUND)
		1015	;
FC53	CD33FC	1016	PCHECK: CALL GET2PAR ;READ PARAMETERS
FC56	F5	1017	PUSH AF ;SAVE TERMINATOR
FC57	3A4E00	1018	LD A, (NPARS) ;SEE HOW MANY PARAMS
FC5A	A7	1019	AND A
FC5B	2881	1020	JR Z,PARER ;NONE,ERROR
FC5D	F1	1021	POP AF
FC5E	C9	1022	RET
		1023	;
		1024	;PRTA - SR TO PRINT A AS 2 HEX DIGITS ON THE CONSOLE
		1025	;INPUTS - A=BYTE TO DISPLAY
		1026	;OUTPUTS- NONE,PRINTS 2 HEX DIGITS
		1027	;DESTROYS-A,FLAGS
		1028	;
FC5F	F5	1029	PRTA: PUSH AF ;SAVE BYTE
FC60	0F	1030	RRCA ;GET MS DIGIT
FC61	0F	1031	RRCA
FC62	0F	1032	RRCA
FC63	0F	1033	RRCA
FC64	CD68FC	1034	CALL HXCVRT ;CONVERT AND PRINT
FC67	F1	1035	POP AF ;GET LS DIGIT
FC68	E60F	1036	HXCVRT: AND 0FH ;MASK OF RUBBISH
FC6A	C630	1037	ADD A,'0' ;CONVERT TO ASCII
FC6C	FE3A	1038	CP '9'+1 ;0..9?
FC6E	3802	1039	JR C,HXPRN ;YES,PRINT CHAR
FC70	C607	1040	ADD A,7 ;ELSE A..F
FC72	C3D4F8	1041	HXPRN: JP CONOUT
		1042	;
		1043	;HEX - FUNCTION TO CONVERT A NUMBER TO HEX OR TO
		1044	CALCULATE AN OFFSET FOR A JR INSTRUCTION.
		1045	THE COMMAND FORMAT IS :