

TUSCAN 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0019

ADDR	CODE	STMT	SOURCE	STATEMENT
		1046	:	HNNN WHERE NNN IS THE NUMBER TO CONVERT
		1047	:	TO HEX (IN ANY VALID INPUT FORM).
		1048	:	HNNN,MMM
		1049	:	WHERE NNN IS THE ADDRESS OF THE JR
		1050	:	INSTRUCTION AND MMM IS THE ADDRESS
		1051	:	TO JUMP TO.
		1052	:	
FC75	CD53FC	1053	HEXC:	CALL PCHECK ;GET PARAMETERS
FC78	2A4A00	1054		LD HL,(PAR1) ;LOAD 1ST
FC7B	3A4E00	1055		LD A,(NPARS) ;SEE IF ONLY ONE
FC7E	3D	1056		DEC A
FC7F	280B	1057		JR Z,PRTHLSP ;YES PRINT HEX VALUE
FC81	23	1058		INC HL ;ELSE ALLOW FOR JR
FC82	23	1059		INC HL ;INSTRUCTION
FC83	EB	1060		EX DE,HL
FC84	2A4C00	1061		LD HL,(PAR2) ;GET 2ND PARAMETER (TO)
FC8ED52		1062	SBC	HL,DE ;CALCULATE OFFSET (CY WAS 0)
		1063		;AND PRINT
		1064	:	
		1065	;PNLHLSP-	SR TO PRINT HL AS 4 HEX DIGITS ON THE CONSOLE
		1066	:	PRECEDED BY A NEWLINE (CR & LF)
		1067	;PRTHLSP-	SR TO PRINT HL AS 4 HEX DIGITS ON THE CONSOLE
		1068	:	FOLLOWED BY A SPACE
		1069	;INPUTS -	HL=16 BIT VALUE TO DISPLAY
		1070	;OUTPUTS-	NONE
		1071	;DESTROYS-A,	FLAGS
		1072	:	
FC89	CDB0FA	1073	PNLHLSP:CALL	CRLF ;NEW LINE
FC8C	7C	1074	PRTHLSP:LD	A,H ;GET HI BYTE
FC8D	CD5FFC	1075		CALL PRTA ;PRINT IT
FC90	7D	1076		LD A,L ;GET LO BYTE
		1077		;PRINT IT & SPACE
		1078	:	
		1079	;PRTASP -	SR TO PRINT THE CONTENTS OF A FOLLOWED BY A SPACE
		1080	;INPUTS -	A = 8 BIT VALUE TO DISPLAY
		1081	;OUTPUTS-	NONE
		1082	;DESTROYS-A,	FLAGS
		1083	:	
FC91	CD5FFC	1084	PRTASP: CALL	PRTA ;PRINT A
		1085		;AND SPACE
		1086	:	
		1087	;SPACE -	SR TO PRINT A SPACE ON THE CONSOLE
		1088	;INPUTS -	NONE
		1089	;OUTPUTS-	NONE
		1090	;DESTROYS-A	
		1091	:	
FC94	3E20	1092	SPACE: LD	A,' ' ;SPACE CODE
FC96	C3D4F8	1093		JP CONOUT ;DISPLAY IT
		1094	:	
		1095	;MONLP -	ROUTINE TO ACT AS SUPERVISOR AND TO DIRECT
		1096	:	THE MONITOR TO THE VARIOUS FUNCTION ROUTINES
		1097	:	IN ADDITION IT LOADS UP TO 2 PARAMETERS INTO
		1098	:	PAR1 AND PAR2 AND STORES THE NUMBER OF
		1099	:	PARAMETERS READ IN NPARS. THE MONITOR ROUTINES
		1100	:	ARE CALLED SO THAT THEY CAN RETURN BY THE USE
		1101	:	OF A RET OR RET CC INSTRUCTION.
		1102	:	
FC99	310001	1103	MONLP: LD	SP,MONSIK ;RESET STACK