

TUSCAN 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0020

ADDR	CODE	STMT	SOURCE	STATEMENT
FC9C	CDB0FA	1104	CALL	CRLF
FC9F	3E2A	1105	LD	A,PROMPT
FCA1	CDD4F8	1106	CALL	CONOUT
FCA4	CDDCF9	1107	CALL	GETBUF
FCA7	CDB0FA	1108	CALL	CRLF
FCAA	CDA6FB	1109	CALL	GETUCT
FCAD	2199FC	1110	LD	HL,MONLP
FCB0	E5	1111	PUSH	HL
FCB1	FE2D	1112	CP	'-'
FCB3	2840	1113	JR	Z,MINUSB
FCB5	D641	1114	SUB	'A'
FCB7	CAA8FD	1115	JP	Z,ASCII
FCBA	3D	1116	DEC	A
FCBB	CA5AFD	1117	JP	Z,SETBPT
FCBE	3D	1118	DEC	A
FCBF	3D	1119	DEC	A
FCC0	CA05FF	1120	JP	Z,DUMP
FCC3	3D	1121	DEC	A
FCC4	CAEDF7	1122	JP	Z,EDIT
FCC7	3D	1123	DEC	A
FCC8	CA8DFD	1124	JP	Z,FILL
FCCB	3D	1125	DEC	A
FCCC	CAC5FD	1126	JP	Z,GO
FCCF	3D	1127	DEC	A
FCD0	28A3	1128	JR	Z,HEXC
FCD2	D605	1129	SUB	5
FCD4	CA64FF	1130	JP	Z,MOVE
FCD7	D603	1131	SUB	3
FCD9	CA0080	1132	JP	Z,PASCAL
FCDC	3D	1133	DEC	A
FCDD	3D	1134	DEC	A
FCDE	CA2AFB	1135	JP	Z,READ
FCEL	3D	1136	DEC	A
FCE2	CAE5FE	1137	JP	Z,SET
FCE5	3D	1138	DEC	A
FCE6	CA00F0	1139	JP	Z,TRACE
FCE9	D603	1140	SUB	3
FCEB	CABDFA	1141	JP	Z,WRITE
FCEE	3D	1142	DEC	A
FCEF	CA7CFE	1143	JP	Z,XAMIN
		1144		
FCF2	C3DEFB	1145	COMER: JP	PARER
		1146		
FCF5	CDA6FB	1147	MINUSB: CALL	GETUCT
FCF8	FE42	1148	CP	'B'
FCFA	20F6	1149	JR	NZ,COMER
		1150		
		1151		
		1152		
		1153		
		1154		
		1155		
		1156		
		1157		
		1158		
		1159		
		1160		
		1161		

;PRINT PROMPT
 ;GET COMMAND
 ;EXTRACT FUNCTION LETTER
 ;PTR TO RETURN ADDRS
 ;STACK ADDR
 ;BREAKPOINT CLEAR?
 ;YES,CHECK FOR B
 ;GET FUNCTION NUMBER
 ;A
 ;B
 ;D
 ;E
 ;F
 ;G
 ;H
 ;M
 ;P
 ;R
 ;S
 ;T (IF THERE)
 ;W
 ;X
 ;FALL INTO BPT CLEAR
 ;CLRBPT - FUNCTION TO RESET ONE OR MORE BREAKPOINTS. THE
 ;COMMAND SYNTAX IS :
 ; -B CLEAR ALL BREAKPOINTS
 ; -BNNN CLEAR BREAKPOINT AT ADDRESS NNN
 ;THE BREAKPOINTS ARE STORED IN A TABLE DURING MONITOR
 ;EXECUTION AND ARE SET WHEN THE USER PROGRAM IS RUN.
 ;THE TABLE FORMAT IS :
 ; LOW ORDER ADDR
 ; HIGH ORDER ADDR