

TUSCAN 2K MONITOR
ADDR CODE

SMT SOURCE STATEMENT

TCL Z80 ASSEMBLER PAGE 0023

```

1278 ; ANNN WHERE NNN IS THE ADDRESS TO INSERT THE
1279 ; STRING. THE STRING IS TERMINATED WITH
1280 ; A <CR> WHICH IS NOT INSERTED IN MEMORY.
1281 ; AN <EOT> IS INSERTED AT THE END OF
1282 ; THE STRING IN MEMORY.
1283 ; THE ADDRESS OF THE EOT IS PRINTED ON
1284 ; THE CONSOLE.
1285 ;
FDA8 CDF4FB 1286 ASCII: CALL PARAM ;GET ADDR
FDAB DADEFB 1287 JP C,PARER ;NO ADDR GIVEN
FDAE E5 1288 PUSH HL ;SAVE ADDR
FDAF CDDCF9 1289 CALL GETBUF ;GET LINE OF TEXT
FDB2 E1 1290 POP HL
FDB3 CD9BFB 1291 ASCII: CALL GEICH ;GET CHAR
FDB6 77 1292 LD (HL),A ;PUT IN MEMORY
FDB7 23 1293 INC HL
FDB8 FE0D 1294 CP CR ;TERMINATOR?
FDBA 20F7 1295 JR NZ,ASCII ;NO
FDEC 2B 1296 DEC HL ;PTR TO EOT
FDBD 3604 1297 LD (HL),EOT ;STORE IT
FDBF CDB0FA 1298 CALL CRLF
FDC2 C38CFC 1299 JP PRTHLSP ;PRINT END ADDR
1300 ;
1301 ;GO - FUNCTION TO EXECUTE A PROGRAM EITHER FROM THE
1302 ; SPECIFIED ADDRESS OR FROM THE VALUE OF THE
1303 ; PSEUDO PROGRAM COUNTER. BREAKPOINTS ARE SET
1304 ; BEFORE THE PROGRAM IS EXECUTED AND THE REGISTERS
1305 ; ARE LOADED FROM THE PSEUDO-REGISTERS. IF A
1306 ; BREAKPOINT EXISTS AT THE START ADDRESS THEN THE
1307 ; BREAKPOINT IS NOT SET.
1308 ; THE COMMAND FORMAT IS :
1309 ; G TO CONTINUE A PROGRAM
1310 ; GNNN TO START A PROGRAM FROM NNN
1311 ;
FDC5 CDF4FB 1312 GO: CALL PARAM ;SEE IF GO ADDR
FDC8 3803 1313 JR C,CONTINUE ;NOT,SO CONTINUE FROM LAST
FDCA 227700 1314 LD (PCSAV),HL ;YES,SET UP START ADDR
>FDCD 1315 CONTINUE:
FDCD 2106FE 1316 LD HL,BREAK ;SET UP RE-ENTRY ADDR
FDD0 223900 1317 LD (RST7+1),HL
FDD3 214F00 1318 LD HL,BPTAB ;PTR TO TABLE
FDD6 0608 1319 LD B,NBP ;CTR OF BPTS
FDD8 5E 1320 INSTALL:LD E,(HL) ;GET BPT ADDR
FDD9 23 1321 INC HL
FDDA 56 1322 LD D,(HL)
Fddb 23 1323 INC HL
FDDC E5 1324 PUSH HL ;SAVE TABLE PTR
FDDD 2A7700 1325 LD HL,(PCSAV) ;GET USER PC
FDE0 CD24FB 1326 CALL DPCMP ;SAME AS BPT ADDR?
FDE3 E1 1327 POP HL ;RESTORE PTR
FDE4 1A 1328 LD A,(DE) ;GET OP CODE (DE)
FDE5 77 1329 LD (HL),A ;SAVE IT IN TABLE
FDE2803 1330 JR Z,MISS ;IF ADDR SAME,DO NOT SET BPT
FDE8 3EFF 1331 LD A,BRK ;INSTALL BPT CODE
FDEA 12 1332 LD (DE),A
FDEB 23 1333 MISS: INC HL
FDEC 10EA 1334 DJNZ INSTALL
FDEE 316700 1335 LD SP,ISAV ;PTR TO REGISTERS

```