

TUSCAN 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0024

ADDR	CODE	SIMT	SOURCE STATEMENT
FDF1	F1	1336	POP AF
FDF2	ED47	1337	LD I,A ;RESTORE I
FDF4	F1	1338	POP AF ;AF
FDF5	C1	1339	POP BC ;BC
FDF6	D1	1340	POP DE ;DE
FDF7	E1	1341	POP HL ;HL
FDF8	DDE1	1342	POP IX ;IX
FDEA	EDE1	1343	POP IY ;IY
FDFC	E1	1344	POP HL ;SP
FDED	F9	1345	LD SP,HL
FDFE	2A7700	1346	LD HL,(PCSAV) ;GET USER PC
FE01	E5	1347	PUSH HL ;ONTO USER STACK
FE02	2A6F00	1348	LD HL,(HLSAV) ;GET USER HL
FE05	C9	1349	RET ;GOTO USER PC
		1350	;
		1351	;;BREAK - ROUTINE TO SAVE THE USER PROGRAM ENVIRONMENT
		1352	;; IN THE PSEUDO REGISTERS. RESTART 38H VECTOR IS
		1353	;; RESET TO POINT TO THE MONITOR AND THEN THE MONITOR
		1354	;; COMMAND LOOP IS RE-ENTERED. THE CONTENTS OF THE
		1355	;; PSEUDO REGISTERS ARE DISPLAYED ON THE CONSOLE
		1356	;;
FE06	226F00	1357	BREAK: LD (HLSAV),HL ;SAVE HL
FE09	227900	1358	LD (DISPAD),HL ;USE HL AS DISPLAY PTR
FE0C	E1	1359	POP HL ;UNSTACK PC
FE0D	2B	1360	DEC HL ;ALLOW FOR BPT
FE0E	227700	1361	LD (PCSAV),HL ;SAVE PC
FE11	ED737500	1362	LD (SPSAV),SP ;SP
FE15	317500	1363	LD SP,SPSAV
FE18	FDE5	1364	PUSH IY ;ETC.
FE1A	DDE5	1365	PUSH IX
FE1C	3B	1366	DEC SP ;(SKIP HLSAV)
FE1D	3B	1367	DEC SP
FE1E	D5	1368	PUSH DE
FE1F	C5	1369	PUSH BC
FE20	F5	1370	PUSH AF
FE21	ED57	1371	LD A,I ;FINALLY I
FE23	F5	1372	PUSH AF
FE24	310001	1373	LD SP,MONSTK ;RESET STACK FOR MONITOR
FE27	214F00	1374	LD HL,BPTAB ;REMOVE BPTS
FE2A	0608	1375	LD B,NBP ;CTR OF THEM
FE2C	5E	1376	RESETPB: LD E,(HL) ;GET ADDR FROM TABLE
FE2D	23	1377	INC HL
FE2E	56	1378	LD D,(HL)
FE2F	23	1379	INC HL
FE30	7E	1380	LD A,(HL) ;GET OPCODE
FE31	23	1381	INC HL
FE32	12	1382	LD (DE),A ;RESTORE TO USER PROG
FE33	10F7	1383	DJNZ RESETPB
FE35	2199FC	1384	LD HL,MONLP ;RESET RST 38H VECTOR
FE38	223900	1385	LD (RST7+1),HL
		1386	;
		1387	;;STATUS - ROUTINE TO DISPLAY THE VALUE OF THE PSEUDO
		1388	;; REGISTERS ON THE CONSOLE.
		1389	;;
FE3B	CD3FFE	1390	STATUS: CALL RDIS ;DISPLAY REGISTERS
FE3E	FF	1391	RST 38H ;RETURN TO MONITOR
		1392	;
FE3F	11CFFF	1393	RDIS: LD DE,REGHDR ;PRINT HEADER