

TUSCAN 2K MONITOR
ADDR CODE

SMT SOURCE STATEMENT

TCL Z80 ASSEMBLER PAGE 0027

```

1510 ; THE HEX ADDRESS IS DISPLAYED ON THE CONSOLE
1511 ; FOLLOWED BY THE HEX DATA. THE DATA CAN BE OPTIONALLY
1512 ; MODIFIED BY TYPING NEW DATA. IF THIS DATA IS
1513 ; TERMINATED BY AN '^' THEN THE PREVIOUS LOCATION
1514 ; IS OPENED FOR MODIFICATION, OTHERWISE THE NEXT
1515 ; LOCATION IS OPENED. TO LEAVE THE FUNCTION
1516 ; TYPE CONTROL C WHEN NEW DATA IS REQUIRED.
1517 ;
FEE5 CD53FC 1518 SET: CALL PCHECK ;GET ADDRESS
FEE8 2A4A00 1519 LD HL,(PAR1)
FEEB EB 1520 EX DE,HL ;USE DE AS PTR
FEED 62 1521 SETLP: LD H,D ;ADDR TO HL FOR
FEED 6B 1522 LD L,E ;PRINTING
EEEE CD89FC 1523 CALL PNLHLSP ;CR,LF,<HL>,SPACE
FEF1 LA 1524 LD A,(DE) ;GET OLD DATA
FEF2 D5 1525 PUSH DE
FEF3 CDEEFB 1526 CALL MODPAR ;PRINT IT & GET NEW DATA
FEF6 D1 1527 POP DE ;TERMINATOR IN A
FEF7 3803 1528 JR C,NOUPDAT ;NO NEW VALUE
FEF9 EB 1529 EX DE,HL ;SWAP PTR & DATA
FEFA 73 1530 LD (HL),E ;UPDATE MEMORY
FEFB EB 1531 EX DE,HL
FEFC FE5E 1532 NOUPDAT: CP ;TEST TERMINATOR
FEFE 1B 1533 DEC DE ;ASSUME MATCH,SO STEP BACK
FEFF 28EB 1534 JR Z,SETLP ;CORRECT
FF01 13 1535 INC DE ;ELSE STEP FORWARD
FF02 13 1536 INC DE
FF03 18E7 1537 JR SETLP
1538 ;
1539 ;DUMP - FUNCTION TO DUMP AN AREA OF MEMORY ON THE CONSOLE
1540 ; IN HEX AND ASCII. THE COMMAND FORMAT IS :
1541 ; D DISPLAY 128 BYTES FROM LAST DISPLAYED
1542 ; ADDRESS.
1543 ; DNNN DISPLAY 128 BYTES FROM ADDRESS NNN.
1544 ; DNNN,MMM
1545 ; DISPLAY FROM ADDRESS NNN TO MMM
1546 ;
1547 ; THE DISPLAY ALWAYS STARTS AT ADDRESS XXX0 WHERE
1548 ; XXX0 IS THE NEAREST ADDRESS BELOW NNN WHICH IS A
1549 ; MULTIPLE OF 16. THE DISPLAY ENDS AT ADDRESS XXXF
1550 ; WHICH IS THE NEAREST ADDRESS ABOVE MMM WHICH FILLS
1551 ; A ROW.
1552 ;
FF05 CD33FC 1553 DUMP: CALL GET2PAR ;GET PARAMETERS
FF08 3A4E00 1554 LD A,(NPARS) ;SEE HOW MANY
1555 ;
1556 AND A ;ZERO?
1557 LD HL,(DISPAD) ;DEFAULT ADDR
1558 LD DE,DEFLEN ;DEFAULT LENGTH
1559 JR Z,DISPLAY ;USE DEFAULTS
1560 LD HL,(PAR1) ;AT LEAST ONE PARAMETER
1561 DEC A ;ANY MORE?
1562 JR Z,DISPLAY ;NO USE DEFAULT LENGTH
1563 EX DE,HL ;SAVE START ADDR
1564 LD HL,(PAR2) ;GET END ADDR
1565 EX DE,HL ;HL=START,DE=END
1566 JR DISPl
1567 DISPLAY: PUSH HL ;SAVE START ADDR

```