

| TUSCAN 2K MONITOR |        | TCL Z80 ASSEMBLER PAGE 0028 |                                                         |
|-------------------|--------|-----------------------------|---------------------------------------------------------|
| ADDR              | CODE   | SIMT                        | SOURCE STATEMENT                                        |
| FF22              | 19     | 1568                        | ADD HL,DE ;CALCULATE END ADDR                           |
| FF23              | EB     | 1569                        | EX DE,HL ;DE=END                                        |
| FF24              | E1     | 1570                        | POP HL ;HL=START                                        |
| FF25              | 7D     | 1571                        | DISP1: LD A,L ;RESET TO START OF LINE                   |
| FF26              | E6F0   | 1572                        | AND 0F0H ;IE MULTIPLE OF 16                             |
| FF28              | 6F     | 1573                        | LD L,A                                                  |
| FF29              | 7B     | 1574                        | LD A,E ;SAME WITH END ADDR                              |
| FF2A              | E6F0   | 1575                        | AND 0F0H                                                |
| FF2C              | C610   | 1576                        | ADD A,16 ;BUT ROUND UP                                  |
| FF2E              | 5F     | 1577                        | LD E,A                                                  |
| FF2F              | 3001   | 1578                        | JR NC,DISPLIN ;IF CY MUST BUMP HIGH ADDR                |
| FF31              | 14     | 1579                        | INC D                                                   |
| FF32              | E5     | 1580                        | DISPLIN: PUSH HL ;SAVE ADDR FOR ASCII DUMP              |
| FF33              | CD89FC | 1581                        | CALL PNLHLSP ;PRINT CR,LF,ADDR,SPACE                    |
| FF36              | CD94FC | 1582                        | CALL SPACE ;2ND SPACE                                   |
| FF39              | 0608   | 1583                        | LD B,8 ;BYTES PER LINE/2                                |
| FF3B              | 7E     | 1584                        | PRTPAIR: LD A,(HL) ;GET BYTE                            |
| FF3C              | 23     | 1585                        | INC HL                                                  |
| FF3D              | CD5FFC | 1586                        | CALL PRTPA ;PRINT IT                                    |
| FF40              | 7E     | 1587                        | LD A,(HL) ;GET NEXT                                     |
| FF41              | 23     | 1588                        | INC HL                                                  |
| FF4CD91FC         | 1589   | CALL                        | PRTASP ;PRINT IT                                        |
| FF45              | 10F4   | 1590                        | DJNZ PRTPAIR                                            |
| FF47              | E1     | 1591                        | POP HL                                                  |
| FF48              | 0610   | 1592                        | LD B,16 ;GET ADDR OF LINE                               |
| FF4A              | 7E     | 1593                        | TXTPRT: LD A,(HL) ;CTR OF BYTES                         |
| FF4B              | FE20   | 1594                        | CP ;GET BYTE                                            |
| FF4D              | 3804   | 1595                        | JR C,NOASC ;PRINTABLE CHAR?                             |
| FF4F              | FE80   | 1596                        | CP DEL+1 ;NO                                            |
| FF51              | 3802   | 1597                        | JR C,PRNT ;YES                                          |
| FF53              | 3E2E   | 1598                        | NOASC: LD A,'.' ;IF NOT ASCII USE '.'                   |
| FF55              | CDD4F8 | 1599                        | PRNT: CALL CONOUT ;PRINT CHAR                           |
| FF58              | 23     | 1600                        | INC HL                                                  |
| FF59              | 10EF   | 1601                        | DJNZ TXTPRT                                             |
| FF5B              | 227900 | 1602                        | LD (DISPAD),HL ;UPDATE DEFAULT ADDR                     |
| FF5E              | CD24FB | 1603                        | CALL DPCMP ;END?                                        |
| FF61              | 20CF   | 1604                        | JR NZ,DISPLIN ;NO                                       |
| FF63              | C9     | 1605                        | RET                                                     |
|                   |        | 1606                        | ;                                                       |
|                   |        | 1607                        | MOVE - FUNCTION TO MOVE BLOCKS OF MEMORY. IT CHECKS FOR |
|                   |        | 1608                        | ADDRESS RANGE OVERLAP AND MOVES MEMORY SO AS NOT        |
|                   |        | 1609                        | TO DESTROY THE DATA. THE COMMAND FORMAT IS :            |
|                   |        | 1610                        | MMNN,MMM,YYY                                            |
|                   |        | 1611                        | WHERE NNN IS THE START ADDR OF THE                      |
|                   |        | 1612                        | BLOCK TO BE MOVED,                                      |
|                   |        | 1613                        | MMM IS THE END ADDR,                                    |
|                   |        | 1614                        | AND YYY IS THE DESTINATION ADDR                         |
|                   |        | 1615                        | ;                                                       |
| FF64              | CD53FC | 1616                        | MOVE: CALL PCHECK ;GET PARAMETERS 1 & 2                 |
| FF67              | FE2C   | 1617                        | CP ;3RD PARAMETER THERE?                                |
| FF69              | C2DEFB | 1618                        | JP NZ,PARER                                             |
| FF6C              | CDF4FB | 1619                        | CALL PARAM ;GET 3RD PARAMETER                           |
| FF6F              | E5     | 1620                        | PUSH HL ;SAVE TO ADDR                                   |
| FF70              | 2A4A00 | 1621                        | LD HL,(PAR1) ;GET START ADDR                            |
| FF73              | EB     | 1622                        | EX DE,HL                                                |
| FF74              | 2A4C00 | 1623                        | LD HL,(PAR2) ;GET END ADDR                              |
| FF77              | D5     | 1624                        | PUSH DE                                                 |
| FF78              | B7     | 1625                        | OR A ;RESET CY                                          |