

## **DFM** analysis report\_JLCDFM

File name: Gerber.zip

Report generated at: 2025-10-29 18:26:09

PCB layers: 2

PCB size: 10x19cm

Analyze project: 

✓ PCB DFM SMT DFM







PCB DFM>Routing layer analysis					
Analyze project	Analysis results	PCB screenshot	Layer distribution	Statistics	
Sharp trace corner (Check for sharp corners in traces)	null <mark>Warning</mark>		Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 6 Good: 0	
BGA pad (Check BGA pads on the board)	No	No	No	Danger: 0 Warning: 0 Good: 0	
Via placed within a pad (Check if there is a via placed within a pad)	No	No	No	Danger: 0 Warning: 0 Good: 0	
Trace to board edge (Detect traces too close to the board edge)	No	No	No	Danger: 0 Warning: 0 Good: 0	
Trace spacing (Measure spacing between adjacent parallel traces)	0.2mm Good		Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 0 Good: 100	
Unconnected trace end  (Free-standing trace ends not connected to pads)	null <b>W</b> arning		Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 32 Good: 0	
Trace width (Trace width information)	0.2mm Good		Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 0 Good: 87	
Fiducial (Detect fiducial marks on the board)	null <b>W</b> arning	O	Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 6 Good: 0	
Pad to board edge (Measure distance of pads from the board edge)	No	No	No	Danger: 0 Warning: 0 Good: 0	
Pad spacing (Measure pad to pad spacing)	0.18mm Good		Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 0 Good: 100	
Plated through-hole to trace clearance (Measure clearance of plated through-holes to traces)	0.35mm Good		Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 0 Good: 36	
Annular ring (Annular ring width of pads compared to holes)	0.15mm <mark>Warning</mark>		Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr Gerber\PCB_Tarjeta_DevOps- B_Cu.gbr	Danger: 0 Warning: 100 Good: 0	
tht to smd	No	No	No	Danger: 0	

soldermask opening edges)				
Solder mask opening exposing trace (Detect clearance of solder mask openings to nearby traces)	Unanalyzed	No	No	No
Soldermask opening with multiple segments (Check if solder mask openings are constructed from multiple geometric shapes)	Unanalyzed	No	No	No
Negative soldermask expansion (Detect solder mask openings smaller than their corresponding pads)	Unanalyzed	No	No	No
PCB DFM>Silkscreen layer analysis				
Analyze project	Analysis results	PCB screenshot	Layer distribution	Statistics
Silkscreen to pad				Danger: 0

No

No

PCB DFM>Soldermask layer analysis

PCB screenshot

No

No

Layer distribution

No

Warning: 0

Good: 0

Danger: 0

Warning: 0

Good: 0

Statistics

No

Good: 0

Danger: 0

Warning: 0

Good: 0

No

No

Analysis results

Unanalyzed

(Detect clearance of vias to pads)

Via to pad

(Detect clearance of vias to pads)

Analyze project

Soldermask bridge

(Detect distance between parallel

through-holes)

Unconnected via
(Detect isolated unconnected

vias)

No

			B_Silkscreen.gbr	
Silkscreen line width (Check silkscreen line width)	0.1mm Danger		Gerber\PCB_Tarjeta_DevOps- F_Silkscreen.gbr Gerber\PCB_Tarjeta_DevOps-	Danger: 18 Warning: 82 Good: 0
Silkscreen to hole (Detect clearance of silkscreen to holes)	0mm Danger	<b>14</b> (	Gerber\PCB_Tarjeta_DevOps- F_Silkscreen.gbr Gerber\PCB_Tarjeta_DevOps- B_Silkscreen.gbr	Danger: 90 Warning: 10 Good: 0
(Detect clearance of silkscreen to pads)	No	No	No	Warning: 0 Good: 0

Analyze project	Analysis results	PCB screenshot	Layer distribution	Statistics
Unconnected via (Detect isolated unconnected vias)	No	No	No	Danger: 0 Warning: 0 Good: 0
Missing plated through-hole (Detect top and bottom pads at the same location without plated through-holes)	null <mark>Warning</mark>		Gerber\PCB_Tarjeta_DevOps- F_Cu.gbr	Danger: 0 Warning: 6 Good: 0
Unconnected via (Detect isolated unconnected vias)	No	No	No	Danger: 0 Warning: 0 Good: 0
Plated through-hole spacing (Measure spacing between plated through-holes)	0mm Danger		Gerber\PCB_Tarjeta_DevOps- PTH.drl	Danger: 50 Warning: 0 Good: 0
Short slot detection (Detect slots shorter than twice their width)	No	No	No	Danger: 0 Warning: 0 Good: 0
Slot width check (Measure slot width)	0.6mm <mark>Dange</mark> r		Gerber\PCB_Tarjeta_DevOps- PTH.drl	Danger: 4 Warning: 0 Good: 0
Via to PTH spacing (Measure spacing of vias to plated	No	No	No	Danger: 0 Warning: 0

No

No