



Onesign Display

UX Scenario Walkthrough for LG Content Store Review

App overview

Onesign Display is a digital signage application for LG webOS TVs, designed for hospitality venues — restaurants, cafés, bars, and pubs. Operators pair a TV to their Onesign Display account using a one-time token, then manage the menus and content shown on that screen remotely from a cloud admin portal. The app on the TV is a thin client that displays whichever content the operator has assigned, with no interactive elements once the screen is paired.

Vendor

Onesign & Digital · D86, Princesway North, Gateshead, NE11 0TU, United Kingdom ·
sales@onesignanddigital.com · 0191 487 6767

App package

App ID: com.onesignanddigital.display

Version: 1.0.0

Minimum webOS: 4.0

Type: Web app (iframes a hosted player at onesign-display.vercel.app)

Service: Subscription-based (external billing via the web portal)

1. Prerequisites for testing

The reviewer needs three things to complete the test scenarios:

1. An LG TV running webOS 4.0 or later (the LG Cloud Test Lab is suitable). The app has been verified on webOS 4.0, 6.0, and 22+.
2. A working internet connection on the TV. The app loads content from *onesign-display.vercel.app* over HTTPS. No offline mode is supported in v1.0.0.
3. A reviewer-only pairing token, supplied in the **Test Info** section of this submission. The token is pre-paired to a sandbox account containing demo menu content (an HTML menu plus three sample slides) and will remain valid throughout the review window.

TV settings (recommended for end users)

These settings are not required to validate the app's behaviour, but are documented here because they are part of the customer-facing setup guide (see *onesign-display.vercel.app/support*):

- Settings → General → Eco → Auto Power Off → Off
- Settings → General → Eco → Eco Mode → Off
- Settings → General → External Devices → SIMPLINK → Off

2. Test scenarios

Scenario A — First-time pairing

Validates that a freshly installed app can be paired and begin playback using only the TV remote.

Step 1 — Launch the app from the launcher

From the LG home screen, locate **Onesign Display** in the apps row and select it with the remote's OK button.

Observe the splash background (black with the Onesign Display wordmark) shown briefly during the initial load.

Expected: App launches within 3–5 seconds.

Expected: Setup screen appears, prompting the user to enter a pairing token.

Expected: The pairing token input field has focus by default.

Step 2 — Enter the pairing token

Using the remote's OK key, open the on-screen keyboard and type the pairing token supplied in the Test Info section.

Press the down-arrow key to move focus from the input field to the **Connect** button, then press OK.

Expected: Setup screen is replaced by the player surface within 5 seconds.

Expected: Demo menu content begins displaying immediately.

Expected: If the token is invalid, the player surface shows an 'Invalid token' message and returns to the setup screen after 5 seconds.

Scenario B — Content playback

Validates that the player displays content correctly, transitions between slides, and remains running indefinitely without user input.



Example: Onesign Display running in a coffee shop, showing the operator's coffee menu on an LG TV. Composition is illustrative — actual content varies by operator.

Step 1 — Observe content playback

After pairing, the demo content rotates through its assigned playlist. Each slide displays for the duration configured by the operator (typically 5–30 seconds).

Transitions between slides use a smooth crossfade by default.

Expected: Demo content plays continuously without manual intervention.

Expected: No focus rings, cursors, or interactive UI elements are visible.

Expected: Slides transition smoothly without black flashes.

Expected: Screen remains awake throughout (subject to the TV's own power settings).

Scenario C — Re-pairing a screen

Validates that an operator can reset a paired screen without uninstalling the app — useful when transferring a TV between venues or after generating a new token.

Step 1 — Trigger the reset gesture

While the player is running, press and hold **any remote button** for 5 continuous seconds.

A confirmation modal appears in the centre of the screen, asking '*Reset pairing token?*' with **Cancel** and **Reset** buttons.

Step 2 — Validate the modal

Press the right arrow key to move focus from Cancel to Reset.

Press the left arrow key to move focus back to Cancel.

Press OK on **Cancel** — the modal closes and playback resumes.

Step 3 — Confirm the reset path

Repeat the long-press gesture to re-open the modal.

Move focus to **Reset** and press OK.

Expected: App returns to the initial setup screen with an empty token field.

Expected: The previously stored token is removed from local storage.

Expected: Re-entering the same token restores playback identically to Scenario A.

3. Edge cases

Back button suppression

Pressing the remote's **Back** button while the app is running must NOT cause the app to exit. This is intentional — signage deployments often involve staff who may accidentally press the back key while operating the venue. The app silently ignores back-key events while the player is active. The only way to exit is via the TV's Home button or by force-closing from the LG launcher.

Expected: Back button press has no visible effect while the player is running.

Expected: Back button has no effect during the setup screen either.

Expected: The TV's Home button still exits the app as normal (this is not intercepted).

Network drop and recovery

If the TV loses internet connectivity during playback, the player continues to display the most recently cached content and shows a small 'Offline' indicator in the bottom-right corner. When connectivity returns, the indicator disappears and the player resumes fetching the latest content within 30 seconds.

Expected: Disconnecting Wi-Fi causes the 'Offline' indicator to appear within ~60 seconds.

Expected: Cached content continues to display during the outage.

Expected: Reconnecting causes the indicator to disappear within ~30 seconds.

Expected: Latest content is fetched and displayed automatically — no manual action required.

Long-running stability

The player includes a 15-minute heartbeat watchdog that automatically reloads the page if no successful content fetch has occurred during that window. This is a defence-in-depth measure against memory leaks, stalled render loops, or other long-session failure modes that can affect TV browsers. The reload is transparent to the user and the pairing token persists, so playback resumes within 5–10 seconds.

4. Expected-behaviour summary

Action	Expected outcome
Open the app from the launcher	Splash background, then setup screen with token input
Enter valid token + press Connect	Player surface appears within 5 seconds; demo content plays
Enter invalid token + press Connect	'Invalid token' shown; returns to setup screen after 5s
Player running (no user input)	Content rotates continuously; screen stays awake
Press the Back button	No effect — back-key is intentionally suppressed
Hold any remote key for 5 seconds	Reset confirmation modal opens (Cancel / Reset)
Reset confirmation → Cancel	Modal closes; playback resumes
Reset confirmation → Reset	Token cleared; app returns to setup screen
Disconnect internet during playback	Cached frame stays on screen; 'Offline' indicator shows
Reconnect internet	Indicator clears; fresh content fetched within 30s
Press the TV Home button	App exits normally; resumes with stored token on next launch

Known limitations (v1.0.0)

- No offline mode — internet connectivity is required to fetch content
- Screen Wake Lock API is unavailable on webOS < 6.0; on older models the app relies on audio/canvas activity heartbeats only
- For 24/7 commercial deployment, customer must disable Auto Power Off in the TV's own settings (one-time, documented in the support page)

For any questions during review, please contact sales@onesignanddigital.com.