LQFP64 pin	name	v4.2.2	v4.2.7									
1	VBAT											
	PC13-TAMPER-RTC				GPIO							
3	PC14- OSC32_IN				GPIO							
4	PC15- OSC32_OUT				GPIO							
	PD0-OSC_IN											
	PD0-03C_IIV											
	PD1-OSC_OUT											
7	NRST											
	PC0				GPIO							
	PC1				GPIO							
					GPIU							
10	PC2	X_STEP_PIN	X_DIR_PIN	From firmware disassembly								
- 11	PC3	(X Y Z E0)_ENABLE_PIN	(XIYIZIE0) ENABLE PI	IN From firmware disassembly								
	VSSA											
	VDDA											
14	PA0-WKUP	FAN_PIN										
15	PA1	HEATER_0_PIN										
		HEATER_BED_PIN										
		HEATER_BED_FIN										
	PA3											
18	VSS_4											
19	VDD_4											
20	PA4	FIL_RUNOUT_PIN,ONBOARD_SD_CS_PIN										
		X_STOP_PIN										
	PA6	Y_STOP_PIN										
23	PA7	Z_STOP_PIN										
		TEMP_BED_PIN										
		TERRI _DED_FIN										
	PC5	TEMP_0_PIN										
26	PB0	SERVO0_PIN										
27	PB1	Z_PROBE_PIN										
		BTN_ENC	BTN_ENC	From users compiling marlin								
	PB10	BTN_EN1	BTN_EN1	From users compiling marlin								
30	PB11											
31	VSS_1											
	VDD 1											
		LCD_PINS_RS	LCD_PINS_RS	From users compiling marlin								
34	PB13	LCD_PINS_D4	LCD_PINS_D4	From users compiling marlin								
35	PB14	BTN_EN2	BTN_EN2	From users compiling marlin								
		LCD_PINS_ENABLE	LCD_PINS_ENABLE	From users compiling marlin								
	PBID	LCD_FIN3_ENABLE	LCD_FIN3_ENABLE	From users complining mainin								
	PC6	BEEPER_PIN										
38	PC7	SD_DETECT_PIN										
39	PC8				SDCard D0							
	PC9				SDCard D1							
					SDCalu D1							
	PA8											
42	PA9	USART1_TX	USART1_TX	From users compiling marlin								
43	PA10	USART1_RX	USART1_RX	From users compiling marlin								
		IIC_EEPROM_SDA										
	PA12	IIC_EEPROM_SCL										
		IIC_EEFROM_SCE										
	PA13				SWDIO							
47	VSS_2											
	VDD 2											
	PA14				SWCLK							
					SWEEK							
	PA15											
	PC10				SDCard D2							
52	PC11				SDCard D3							
	PC12				SDCard CE							
	PD2											
					SDCard CMD							
	PB3	E0_DIR_PIN	E0_STEP_PIN	From firmware disassembly								
56	PB4-NJTRST	E0_STEP_PIN	E0_DIR_PIN	From firmware disassembly								
		Z_DIR_PIN	Z_STEP_PIN	From firmware disassembly								
	PB6	Z_STEP_PIN	Z_DIR_PIN	From firmware disassembly								
		Y_DIR_PIN	Y_STEP_PIN	From firmware disassembly								
	BOOT0											
61	PB8	Y_STEP_PIN	Y_DIR_PIN	From firmware disassembly								
		X_DIR_PIN	X_STEP_PIN	From firmware disassembly								
		A_DIR_FIN	A_STEP_PIN	From firmware disassembly								
	VSS_3											
64	VDD_3											
	Key											
	Damian Martinez											