```
"# PROGRAM NAME  :  Seperate Vision Align
"# FUNCTION      :
"# CALL PROGRAM  :  MPS195
"# SUB PROGRAM   :
"# FUNC PROGRAM  :

VAR;

    LONG L_CAM_MARK_I               %ML97180;
    LONG R_CAM_MARK_I               %ML97210;

    BOOL L_CAM_ALIGN_RE             %MB970000;
    BOOL R_CAM_ALIGN_RE             %MB970001;

    BOOL L_CAM_LINE_RE              %MB970020;
    BOOL R_CAM_LINE_RE              %MB970021;

    BOOL L_CAM_MANUAL_ALIGN_RE      %MB970040;
    BOOL R_CAM_MANUAL_ALIGN_RE      %MB970041;

    BOOL L_CAM_DL_ALIGN_RE          %MB970080;
    BOOL R_CAM_DL_ALIGN_RE          %MB970081;

    BOOL L_CAM_ALIGN_RE             %MB970100;
    BOOL R_CAM_ALIGN_RE             %MB970101;

    BOOL L_CAM_LINE_RE              %MB970120;
    BOOL R_CAM_LINE_RE              %MB970121;

    BOOL L_CAM_MANUAL_ALIGN_RE      %MB970140;
    BOOL R_CAM_MANUAL_ALIGN_RE      %MB970141;

    BOOL L_CAM_DL_ALIGN_RE          %MB970180;
    BOOL R_CAM_DL_ALIGN_RE          %MB970181;

    BOOL L_CAM_ALIGN_RESULT_C       %MB970200;
    BOOL R_CAM_ALIGN_RESULT_C       %MB970300;

    BOOL L_CAM_ALIGN_RESULT_N       %MB970201;
    BOOL R_CAM_ALIGN_RESULT_N       %MB970301;

    LONG L_CAM_ALIGN_ERROR_COD      %ML97022;       // 0:OK 1:NO MARK ID 2:MANUAL SEARCH 3:MANUAL OK
 4:MANUAL ABORT
    LONG R_CAM_ALIGN_ERROR_COD      %ML97032;       // 0:OK 1:NO MARK ID 2:MANUAL SEARCH 3:MANUAL OK
 4:MANUAL ABORT

    BOOL L_CAM_MANUAL_ALIGN_IN      %MB970222;
    BOOL R_CAM_MANUAL_ALIGN_IN      %MB970322;

    BOOL L_CAM_MANUAL_ALIGN_ABOR    %MB970224;
    BOOL R_CAM_MANUAL_ALIGN_ABOR    %MB970324;

    LONG L_CAM_ALIGN_SEARCH_TYP     %ML97194;
    LONG R_CAM_ALIGN_SEARCH_TYP     %ML97224;

    LONG L_CAM_ALIGN_SCRIBE_N       %ML97196;
    LONG R_CAM_ALIGN_SCRIBE_N       %ML97226;

    LONG L_CAM_RESULT_              %ML97024;
    LONG L_CAM_RESULT_              %ML97026;
    LONG R_CAM_RESULT_              %ML97034;
    LONG R_CAM_RESULT_              %ML97036;

END_VAR;

    // Alignment Data Clear
    ML15408 = 0;                                        // 1 Camera Mode Alignment Count
    DW00080 = 0;                                        // Alignment Result Judge
    DW00003 = 0;                                        // Alignment Data Check
    DW00005 = 0;
    DW00010 = 0;

    // Manual Alignment Cutter X JOG Moving Valume Write
    DL00020 = 0;
    DL00022 = 0;

    L_CAM_ALIGN_REQ = 0;
    R_CAM_ALIGN_REQ = 0;
    L_CAM_LINE_REQ = 0;
    R_CAM_LINE_REQ = 0;
    L_CAM_MANUAL_ALIGN_REQ = 0;
    R_CAM_MANUAL_ALIGN_REQ = 0;
    L_CAM_DL_ALIGN_REQ = 0;
    R_CAM_DL_ALIGN_REQ = 0;
    L_CAM_ALIGN_SEARCH_TYPE = 0;
    R_CAM_ALIGN_SEARCH_TYPE = 0;
    L_CAM_ALIGN_SCRIBE_NO = MW12513;
```

```
00018        R_CAM_ALIGN_SCRIBE_NO = MW12513;

00019        IF MB047361 == 1                                       // Dummy Alignment Flag
00020            L_CAM_MARK_ID = GL21192;
00021            R_CAM_MARK_ID = GL21192;
00022        ELSE;
00023            L_CAM_MARK_ID = ML01116;
00024            R_CAM_MARK_ID = ML01116;
00025        IEND;

00026        MSEE MPS194;                                           // Alignment Position Move 1 Cycle

00027        TIM TMW26234;

00028        IF MB000023 == 1;
00029            MB045159 = 1;                                      // Step Mode Next Flag
00030            IOW (!MB21684D | MB20544E) | MB045013 ==           // Step Mode
00031            MB045159 = 0;                                      // Step Mode Next Flag
00032        IEND;

             // → Chuck Break Receive Complete Bit Set
00033        IF MB000004 == 1;
00034            MB045130 = 1;
00035        IEND;

             // Manual PTP
00036        DB000020 = 0;
00037        DB000021 = 0;
00038        IF ML01118 == 1                                        // DUMMY ALIGN MODE (0: Unuse / 1: Use)
00039            IF !MB047361 == 1                                  // Dummy Align Seach Flag
00040                DB000020 = 1;
00041                DB000021 = 1;
00042            IEND;
00043        IEND;
00044        IF !MB000004 == 1;
00045            IF MW00051 == 82                                   // Manual_Alignment Position
00046                DB000020 = 1;
00047                DB000021 = 0;
00048            IEND;
00049        IEND;
00050        IF MB000800 == 1                                       // MCTAG_Idling
00051            DB000020 = 1;
00052            DB000021 = 0;
00053        IEND;

00054        IOW IBA00C1 & IBA08C1 & IBA28C1 & IBA30C1 & IBA80C1 & IBA88C1 == // Axis Move Comp

             // Alignment Valume Reset
00055        L_CAM_RESULT_X = 0;
00056        L_CAM_RESULT_Y = 0;
00057        R_CAM_RESULT_X = 0;
00058        R_CAM_RESULT_Y = 0;

             " Glass ID
00059        IF CW00011 == 1                                        // SCT
00060            BLK MW24140 DW00040 W8
00061        ELSE;
00062            IF CW00011 == 2                                    // LCCT
00063                BLK MW24210 DW00040 W8;
00064            ELSE;                                              // RCCT
00065                BLK MW24290 DW00040 W8
00066            IEND;
00067        IEND;

00068        BLK DW00040 MW97184 W8;
00069        BLK DW00040 MW97214 W8;

00070        IF DB00020 == 0                                        // Dummy Run Check Or Camera Align No Use Mode
00071            IF GL21028 == 0;
00072                DW00001 = 1;
00073            ELSE;
00074                DW00001 = 0;                                   // Alignment Execute Count
00075            IEND;

00076            WHILE DW00001 <= MW26098;
00077                DB000800 = 0;                                  // Alignment O.K Judge
00078                DB000801 = 0;                                  // Alignment N.G Judge

                     // # Step01 Alignment Execute
00079                IF GL21028 == 0                                // Alignment Type [2 Camera)
00080                    IF L_CAM_ALIGN_RES | R_CAM_ALIGN_RES == 1;
00081                        L_CAM_ALIGN_REQ = 0                    // L Camera Alignment Request On
00082                        R_CAM_ALIGN_REQ = 0                    // R Camera Alignment Request On
00083                        IOW !L_CAM_ALIGN_RES & !R_CAM_ALIGN_RES == 1;
00084                    IEND;
00085                    L_CAM_ALIGN_REQ = 1                        // L Camera Alignment Request On
```

```
00086           R_CAM_ALIGN_REQ = 1                         // R Camera Alignment Request On
00087           IOW L_CAM_ALIGN_ERROR_CODE == 0;
00088           IOW R_CAM_ALIGN_ERROR_CODE == 0;
00089           EOX;
00090       ELSE;
00091           IF GL21028 == 1                             // Alignment Type [L Camera]
00092               IF ML15408 == 1;
00093                   IF DW00001 == 1;
00094                       IOW MW04514 == 0;
00095                       MW04514 = 2;                    // Scribe → Scribe Cutter Command Code Setting
00096                       MB045150 = 1;                   // Scribe → Scribe Cutter Command Execute Bit ON
00097                       IOW MB045151 == 1               // Scribe ← Scribe Cutter Command Complete Bit ON
00098                       MB045150 = 0;                   // Scribe → Scribe Cutter Command Execute Bit OFF
00099                       IOW MB045151 == 0               // Scribe ← Scribe Cutter Command Complete Bit ON
00100                   IEND;
00101               IEND;
00102               L_CAM_ALIGN_REQ = 1                     // L Camera Alignment Request On
00103           IEND;
00104           IF GL21028 == 2                             // Alignment Type [R Camera]
00105               IF ML15408 == 1;
00106                   IF DW00001 == 1;
00107                       IOW MW04514 == 0;
00108                       MW04514 = 2;                    // Scribe → Scribe Cutter Command Code Setting
00109                       MB045150 = 1;                   // Scribe → Scribe Cutter Command Execute Bit ON
00110                       IOW MB045151 == 1               // Scribe ← Scribe Cutter Command Complete Bit ON
00111                       MB045150 = 0;                   // Scribe → Scribe Cutter Command Execute Bit OFF
00112                       IOW MB045151 == 0               // Scribe ← Scribe Cutter Command Complete Bit ON
00113                   IEND;
00114               IEND;
00115               R_CAM_ALIGN_REQ = 1                     // R Camera Alignment Request On
00116           IEND;
00117       IEND;

            // # Step02 Alignment Result Flag
            // → 2 Camera Mode
00118       IF GL21028 == 0                                 // Alignment Type [2 Camera)
00119           IOW (L_CAM_ALIGN_RESULT_OK | L_CAM_MANUAL_ALIGN_ING) & (R_CAM_ALIGN_RESULT_OK | R_CAM_MANUAL_ALIGN_ING) == 1;
00120           PFORK Line1 Line2;
                Line1:
00121               IF L_CAM_MANUAL_ALIGN_ING == 1;
                            " NEED ADD OPCALL
00122                   IOW !L_CAM_MANUAL_ALIGN_ING == 1;
00123                   IOW L_CAM_ALIGN_RES == 1;
00124                   IF L_CAM_MANUAL_ALIGN_ABORT == 1;
00125                       DB000802 = 1;                           // Manual Align Stop
00126                   IEND;
00127               IEND;
00128               JOINTO LabelX1;
                Line2:
00129               IF R_CAM_MANUAL_ALIGN_ING == 1;
                            " NEED ADD OPCALL
00130                   IOW !R_CAM_MANUAL_ALIGN_ING == 1;
00131                   IOW R_CAM_ALIGN_RES == 1;
00132                   IF R_CAM_MANUAL_ALIGN_ABORT == 1;
00133                       DB000802 = 1;                           // Manual Align Stop
00134                   IEND;
00135               IEND;
00136               JOINTO LabelX1;

00137           LabelX1: PJOINT;

                " Check Test due to No Stop When Occur Manual Searching
00138           IOW (L_CAM_ALIGN_RESULT_OK & R_CAM_ALIGN_RESULT_OK) | DB000802 == 1;

00139           IF L_CAM_ALIGN_RESULT_OK & R_CAM_ALIGN_RESULT_OK == 1;
00140               MB049380 = 0;                           // L Camera Alignment Result OK
00141               MB049381 = 0;                           // R Camera Alignment Result OK
00142               ML15102 = L_CAM_RESULT_X                // Alignment Data (X1)
00143               ML15104 = L_CAM_RESULT_Y * -1           // Alignment Data (Y1)
00144               ML15106 = R_CAM_RESULT_X                // Alignment Data (X2)
00145               ML15108 = R_CAM_RESULT_Y * -1           // Alignment Data (Y2)
00146               DW00004 = 0;
00147               DW00001 = MW26098 + 1;
00148               EOX;

00149               IF ML15102 <> 0;
```

```
                        DB000040 = 1;
                    IEND;
                    IF ML15104 <> 0;
                        DB000041 = 1;
                    IEND;
                    IF ML15106 <> 0;
                        DB000042 = 1;
                    IEND;
                    IF ML15108 <> 0;
                        DB000043 = 1;
                    IEND;

                    IF !DB000040 & !DB000041 == 1;
                        DB000048 = 1;
                    IEND;

                    IF !DB000042 & !DB000043 == 1;
                        DB000049 = 1;
                    IEND;

                    WHILE DB000048 == 1;
                        L_CAM_ALIGN_REQ = 0;
                        EOX;
                        L_CAM_ALIGN_REQ = 1;
                        IOW L_CAM_ALIGN_RESULT_OK == 1;
                        ML15102 = L_CAM_RESULT_X                // Alignment Data (X1)
                        ML15104 = L_CAM_RESULT_Y * -1           // Alignment Data (Y1)
                        L_CAM_ALIGN_REQ = 0;
                        EOX;
                        IF ML15102 <> 0;
                            DB000048 = 0;
                        IEND;
                        IF ML15104 <> 0;
                            DB000048 = 0;
                        IEND;
                        EOX;
                    WEND;

                    WHILE DB000049 == 1;
                        R_CAM_ALIGN_REQ = 0;
                        EOX;
                        R_CAM_ALIGN_REQ = 1;
                        IOW R_CAM_ALIGN_RESULT_OK == 1;
                        ML15106 = R_CAM_RESULT_X                // Alignment Data (X1)
                        ML15108 = R_CAM_RESULT_Y * -1           // Alignment Data (Y1)
                        R_CAM_ALIGN_REQ = 0;
                        EOX;
                        IF ML15106 <> 0;
                            DB000049 = 0;
                        IEND;
                        IF ML15108 <> 0;
                            DB000049 = 0;
                        IEND;
                        EOX;
                    WEND;

                ELSE;
                    IF L_CAM_ALIGN_RESULT_NG == 1;
                        MB049380 = 1;                       // L Camera Auto Mark Search Flag (0 :OFF 1: ON)
                        DB000801 = 1;                       // Alignment N.G Judge
                    ELSE;
                        ML15102 = L_CAM_RESULT_X            // Alignment Data (X1)
                        ML15104 = L_CAM_RESULT_Y * -1       // Alignment Data (Y1)
                        DB000800 = 1;                       // Alignment O.K Judge
                    IEND;

                    IF R_CAM_ALIGN_RESULT_NG == 1;
                        MB049381 = 1;                       // R Camera Auto Mark Search Flag (0 :OFF 1: ON)
                        DB000801 = 1;                       // Alignment N.G Judge
                    ELSE;
                        ML15106 = R_CAM_RESULT_X            // Alignment Data (X2)
                        ML15108 = R_CAM_RESULT_Y * -1       // Alignment Data (Y2)
                        DB000800 = 1;                       // Alignment O.K Judge
                    IEND;
                IEND;

                L_CAM_ALIGN_REQ = 0;
                R_CAM_ALIGN_REQ = 0;

            // → 1 Camera Mode
            ELSE;
                IF GL21028 == 1                             // Alignment Type (0 : L,R Camera / 1 : L Camera / 2 : R Camera)
                    IOW L_CAM_ALIGN_RES | L_CAM_MANUAL_ALIGN_ING == 1;

```

```
                    IF L_CAM_MANUAL_ALIGN_ING == 1;
                              " NEED ADD OPCALL
                        IOW !L_CAM_MANUAL_ALIGN_ING == 1;
                        IOW L_CAM_ALIGN_RES == 1;
                        IF L_CAM_MANUAL_ALIGN_ABORT == 1;
                            DB000802 = 1;                   // Manual Align Stop
                        IEND;
                    IEND;

                    IF L_CAM_ALIGN_RESULT_NG == 1;
                        MB049380 = 1;                       // L Camera Auto Mark Search Flag (0 :OFF 1: ON)
                        DB000801 = 1;                       // Alignment N.G Judge
                    ELSE;
                        IF ML15408 == 0;
                            ML15102 = L_CAM_RESULT_X        // Alignment Data (X1)
                            ML15104 = L_CAM_RESULT_Y        // Alignment Data (Y1)
                            ML15408 = 1;
                        ELSE;
                            ML15106 = L_CAM_RESULT_X        // Alignment Data (X2)
                            ML15108 = L_CAM_RESULT_Y        // Alignment Data (Y2)
                        IEND;
                        DB000800 = 1;                       // Alignment O.K Judge
                    IEND;

                    L_CAM_ALIGN_REQ = 0                     // L Camera Alignment Request Reset
                    IOW !L_CAM_ALIGN_RES == 1;
                ELSE;
                    IOW R_CAM_ALIGN_RES | R_CAM_MANUAL_ALIGN_ING == 1;

                    IF R_CAM_MANUAL_ALIGN_ING == 1;
                              " NEED ADD OPCALL
                        IOW !R_CAM_MANUAL_ALIGN_ING == 1;
                        IOW R_CAM_ALIGN_RES == 1;
                        IF R_CAM_MANUAL_ALIGN_ABORT == 1;
                            DB000802 = 1;                   // Manual Align Stop
                        IEND;
                    IEND;

                    IF R_CAM_ALIGN_RESULT_NG == 1;
                        MB049381 = 1;                       // R Camera Auto Mark Search Flag (0 :OFF 1: ON)
                        DB000801 = 1;                       // Alignment N.G Judge
                    ELSE;
                        IF ML15408 == 0;
                            ML15102 = R_CAM_RESULT_X        // Alignment Data (X1)
                            ML15104 = R_CAM_RESULT_Y        // Alignment Data (Y1)
                            ML15408 = 1;
                        ELSE;
                            ML15106 = R_CAM_RESULT_X        // Alignment Data (X2)
                            ML15108 = R_CAM_RESULT_Y        // Alignment Data (Y2)
                        IEND;
                        DB000800 = 1;                       // Alignment O.K Judge
                    IEND;

                    R_CAM_ALIGN_REQ = 0                     // R Camera Alignment Request Reset
                    IOW !R_CAM_ALIGN_RES == 1;
                IEND;
            IEND;
            IF DB000802 == 1                                // Manual Alignment Stop
                MB04539F = 1;
                DB000801 = 0;                               // Alignment N.G Judge
                MB000015 = 1;
                EOX;
            IEND;

            DW00006 = 0;

            // Alignment Data Area Check Alarm
//          IF L_CAM_ALIGN_RESULT == 1;
//              DB000100 = 0;
//
//              // Alignment X1
//              IF ML15102 >= 0                         // X1
//                  DL00030 = ML15102;
//              ELSE;
//                  DL00030 = -1 * ML15102;
//              IEND;
//              IF ML26236 <> 0;
//                  IF ML26236 < DL00030;
//                      DB000100 = 1;                       // Alignment Data Over
//                  IEND;
//              IEND;
//
//              // Alignment Y1
//              IF ML15104 >= 0                         // Y1
//                  DL00032 = ML15104;
```

```
//              ELSE;
//                  DL00032 = -1 * ML15104;
//              IEND;
//              IF ML26238 <> 0;
//                  IF ML26238 < DL00032;
//                      DB000100 = 1;                       // Alignment Data Over
//                  IEND;
//              IEND;
//              IF DB000100 == 1;
//                  MB03070F = 1;                           // Alignment Data Area Check Warning
//                  MB000015 = 1;
//              IEND;
//              DB000100 = 0;
//          IEND;
//
//          IF R_CAM_ALIGN_RESULT == 1;
//              DB000100 = 0;
//              // Alignment X2
//              IF ML15106 >= 0                         // X2
//                  DL00034 = ML15106;
//              ELSE;
//                  DL00034 = -1 * ML15106;
//              IEND;
//              IF ML26236 <> 0;
//                  IF ML26236 < DL00034;
//                      DB000100 = 1;                       // Alignment Data Over
//                  IEND;
//              IEND;
//              // Alignment Y2
//              IF ML15108 >= 0                         // Y2
//                  DL00036 = ML15108;
//              ELSE;
//                  DL00036 = -1 * ML15108;
//              IEND;
//              IF ML26238 <> 0;
//                  IF ML26238 < DL00036;
//                      DB000100 = 1;                       // Alignment Data Over
//                  IEND;
//              IEND;
//
//              IF DB000100 == 1;
//                  MB03070F = 1;                           // Alignment Data Area Check Warning
//                  MB000015 = 1;
//              IEND;
//              DB000100 = 0;
//          IEND;

            IF DB000800 | DB000801 == 1;
                DW00010 = 0;
                // → Alignment Data Zero Alarm
                IF ML15102 == 0                             // Alignment Data (X1)
                    DB000101 = 1;
                IEND;
                IF ML15104 == 0                             // Alignment Data (Y1)
                    DB000101 = 1;
                IEND;
                IF ML15106 == 0                             // Alignment Data (X2)
                    DB000101 = 1;
                IEND;
                IF ML15108 == 0                             // Alignment Data (Y2)
                    DB000101 = 1;
                IEND;
                IF DW00010 <> 0;
                    // → Alignment Data Check Alarm
                    MB04539B = 1;
                    MB000015 = 1;
                    EOX;
                IEND;
                DW00010 = 0;
            IEND;

            IF DB000030 & DB000031 & DB000032 & DB000030 == 1;
                // → Alignment Data Check Alarm
                MB04539C = 1;
                MB000015 = 1;
                EOX;
            IEND;

            DW00001 = DW00001 + 1;
            EOX;
        WEND;
        ML15112 = ML15102                                   // Alignment Data (X1)_Dummy
        ML15114 = ML15104                                   // Alignment Data (Y1)_Dummy
        ML15116 = ML15106                                   // Alignment Data (X2)_Dummy
        ML15118 = ML15108                                   // Alignment Data (Y2)_Dummy
    ELSE;
        IF MB030035 == 1;
```

```
            ML15102 = 0;                                         // Alignment Data (X1)
            ML15104 = 0;                                         // Alignment Data (Y1)
            ML15106 = 0;                                         // Alignment Data (X2)
            ML15108 = 0;                                         // Alignment Data (Y2)
            IF DB000021 == 1
                ML15102 = ML15112                                // Alignment Data (X1)
                ML15104 = ML15114                                // Alignment Data (Y1)
                ML15106 = ML15116                                // Alignment Data (X2)
                ML15108 = ML15118                                // Alignment Data (Y2)
            IEND;
        IEND;
    IEND;

        " Alignment BackUp Data and Current Data Check
    IF ML15102 <> 0;
        IF DL00030 == ML15102;
            DB000030 = 1;
        IEND;

        DL00050 = ML15102 - DL00030;
        IF DL00050 < 0;
            DL00050 = DL00050 * -1;
        IEND;
        IF DL00050 > ML26278;
            DB000050 = 1;
        IEND;
    IEND;
    IF ML15104 <> 0;
        IF DL00032 == ML15104;
            DB000031 = 1;
        IEND;

        DL00052 = ML15104 - DL00032;
        IF DL00052 < 0;
            DL00052 = DL00052 * -1;
        IEND;
        IF DL00052 > ML26278;
            DB000051 = 1;
        IEND;
    IEND;
    IF ML15106 <> 0;
        IF DL00034 == ML15106;
            DB000032 = 1;
        IEND;

        DL00054 = ML15106 - DL00034;
        IF DL00054 < 0;
            DL00054 = DL00054 * -1;
        IEND;
        IF DL00054 > ML26278;
            DB000052 = 1;
        IEND;
    IEND;
    IF ML15108 <> 0;
        IF DL00036 == ML15108;
            DB000033 = 1;
        IEND;

        DL00056 = ML15108 - DL00036;
        IF DL00056 < 0;
            DL00056 = DL00056 * -1;
        IEND;
        IF DL00056 > ML26278;
            DB000053 = 1;
        IEND;
    IEND;

    IF DB000030 & DB000031 & DB000032 & DB000033 & !MB000800 == 1;
        "  Alignment Data Check Alarm
        MB04539C = 1;
        MB000015 = 1;
        EOX;
    IEND;

    IF !MB000800 == 1;
        IF ML26278 <>0;
            IF DB000050 | DB000051 | DB000052 | DB000053 == 1;
                "  Alignment Data Check Alarm
                MB04539A = 1;
                MB000015 = 1;
                EOX;
            IEND;
        IEND;
    IEND;

    IF ML15102 == 0                                                    " Alignment Data (X1)
        DB000100 = 1;
```

```
    IEND;
    IF ML15104 == 0                                                    " Alignment Data (Y1)
        DB000101 = 1;
    IEND;
    IF ML15106 == 0                                                    " Alignment Data (X2)
        DB000102 = 1;
    IEND;
    IF ML15108 == 0                                                    " Alignment Data (Y2

        DB000103 = 1;
    IEND;

    IF DB000100 & DB000101 & !MB000800 == 1;
        "  Alignment N.G Judge
        MB04539B = 1;
        MB000015 = 1;
        EOX;
    IEND;

    IF DB000102 & DB000103 & !MB000800 == 1;
        "  Alignment N.G Judge
        MB04539B = 1;
        DB000801 = 1;
        MB000015 = 1;
        EOX;
    IEND;

    IF ML26276 <> 0;
        MB045049 = 0;
        MB045069 = 1;                                                  " L_CHECK Start
        IOW MB045059 == 1                                              " L_CHECK Comp
        MB045069 = 0;                                                  " L_CHECK End

        IF MB45049 & !MB000800 == 1;
            "  Alignment Data Check Alarm
            MB045399 = 1;
            MB000015 = 1;
            EOX;
        IEND;
    IEND;

    IF !MB04539C & !MB04539B & !MB045399 & !MB04539A == 1;
        DL00030 = ML15102                                          " Alignment Data (X1)
        DL00032 = ML15104                                          " Alignment Data (Y1)
        DL00034 = ML15106                                          " Alignment Data (X2)
        DL00036 = ML15108                                          " Alignment Data (Y2)
    IEND;

    IF MW00051 <> 82;
        IF !MB045013 == 1                                  // Cycle Stop Chec
            IF MB047361 == 1                               // Dummy Align Seach Flag
                //# Scribe Chuck Y
                IF !MB04524A == 1;
                    //→ Scribe Chuck Y Alignment Position
                    IOW MW04518 == 0;
                    MW04518 = 4;                           // Scribe → Scribe Chuck Command Code A
lignment Position
                    MB045190 = 1;                          // Scribe → Scribe Chuck Command Execut
e Bit ON
                    IOW MB045191 == 1                      // Scribe ← Scribe Chuck Command Comple
te Bit ON
                    MB045190 = 0;                          // Scribe → Scribe Chuck Command Execut
e Bit OFF
                    IOW MB045191 == 0                      // Scribe ← Scribe Chuck Command Comple
te Bit ON
                IEND;
            IEND;
        IEND;
    IEND;

//  IF MB000004 == 1;
//      IF ML23474 == 1                                    // Head Dust Hood UseMode (0:Not Use / 1
:Use)
//          IF !MB045132 == 1;                             // Scribe Comp
//              IF !MB000800 == 1;
//                  IOW MB046824 == 1                      // UPPER DUST HOOD DOWN Check
//                  IOW MB046805 == 1                      // LOWER DUST HOOD UP Check
//              IEND;
//          IEND;
//      IEND;
//  IEND;

    // → Alignment Execute 1 Cycle
    IF MB000004 == 1;
        IF !MB04539F == 1                                  // Manual Alignment Search Abort
            MB045131 = 1;                                  // Alignment Comp
        IEND;
```

```
00448        IEND;

00449   RET;
```