

H40.51:ABS Origin Setting									
0	0/0		FOR	[W]Var DW00020 ---	[W]Init 00000	[W]Max 00111	[W]Step 00001		
1	1/4	NL 2				EXPRESSION 'I' = 'DW00020' I = DW00020; 'Axis Index' = 'DW00020' + 1 DW00019 = DW00020 + 1;		[DW00019] .../0012	.../0170 .../0256
2	2/9	NL 2	IF	'MB100000i' == true MB100000i == true;					
3	3/11	NL 3				CNV AXIS Convert Axis Index to Line Axis [W]AxisIdx DW00019 Axis Index [B]Endbit DB00000F EndBit [W]LineNo DW00021 LineNo [W]AxisNo DW00022 AxisNo		[DW00021] .../0031 .../0079 .../0127 .../0208 .../0235 .../0266 .../0293 .../0320 [DW00022] .../0027	.../0047 .../0095 .../0190 .../0217 .../0244 .../0275 .../0302 .../0186 .../0063 .../0111 .../0199 .../0226 .../0253 .../0284 .../0311
4	4/17	NL 3	MB102200i ABS Search OK end MB102300i UPCX ABS Setting Cmp MB102100i ABS Search Start Signal #1			MB102300i UPCX ABS Setting Cmp		[MB102300] .../0018i	.../0166i
5	5/21	NL 3	MB102100i ABS Search Start Signal #1			MB102100i ABS Search Start Signal #1		[MB102100] .../0019i	.../0021i
6	10/23	NL 3	MB102200i ABS Search OK end			MB102200i ABS Search OK end		[MB102200] .../0017i	.../0023i
7	12/25	NL 3	MB00005A Running PC Command E xec			MB102400i ABS offset U pdate Forwa rd Request		[MB102400] .../0167i	
8	14/27	NL 3				EXPRESSION // Axis Number Reference 'J' = ('AxisNo'-1) * 0x80 J = (DW00022-1) * 0x80;			
9	15/31	NL 3	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00001	EXPRESSION // Line No.1 'Motion Command Response Code' = 'IW8008' DW00001 = IW8008j; // Axis Motion Command Response 'DW00002' = 'IW800Cj' DW00002 = IW800Cj; // Axis Condition 'DL00004' = 'OL8048' DL00004 = OL8048j; // Axis Abs Offset 'DL00006' = 'IL8010' DL00006 = IL8010j; // Axis Cposition 'DW00150' = 'IW802Dj' DW00150 = IW802Dj; // Alarm Code		[DW00002] .../0055w .../0103w [DL00004] .../0073w .../0105w .../0162 [DL00006] .../0075w .../0123w .../0163 [DW00150] .../0061w .../0109w .../0143	.../0071w .../0119w .../0087w .../0135w .../0089w .../0137w .../0091w .../0139w .../0093w .../0141w .../0149
10	17/47	NL 3	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00002	EXPRESSION 'Motion Command Response Code' = 'STR1Y1~Motion command response code' DW00001 = IW8808j; 'DW00002' = 'IW880Cj' DW00002 = IW880Cj; 'DL00004' = 'STR1Y1~Zero point offset' DL00004 = OL8848j; 'DL00006' = 'STR1Y1~Target position (CPOS)' DL00006 = IL8810j; 'DW00150' = 'STR1Y1~Servo alarm code' DW00150 = IW882Dj;		[DW00002] .../0039w .../0103w [DL00004] .../0041w .../0105w .../0162 [DL00006] .../0043w .../0107w .../0163 [DW00150] .../0045w .../0109w .../0143	.../0071w .../0119w .../0087w .../0135w .../0089w .../0137w .../0091w .../0139w .../0093w .../0141w .../0149
11	19/53	NL 3	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00005	EXPRESSION 'Motion Command Response Code' = 'CX~Motion command response code' DW00001 = IWA008j; 'DW00002' = 'IWA00Cj' DW00002 = IWA00Cj; 'DL00004' = 'CX~Zero point offset' DL00004 = OLA048j; 'DL00006' = 'CX~Target position (CPOS)' DL00006 = ILA010j; 'DW00150' = 'CX~Servo alarm code' DW00150 = IWA02Dj;		[DW00002] .../0039w .../0103w [DL00004] .../0041w .../0105w .../0162 [DL00006] .../0043w .../0107w .../0163 [DW00150] .../0045w .../0109w .../0143	.../0055w .../0119w .../0087w .../0135w .../0089w .../0137w .../0091w .../0139w .../0093w .../0141w .../0149

[illegible]

23	40/184	NL	3	MB101900i ABS Origin Setting Request								MB102000i ABS Origin Setting Response
24	40/186	NL	3					EXPRESSION				
								'J' = ('AxisNo'-1) * 0x80 J = (DW00022-1) * 0x80;				
25	43/193	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00001					
								EXPRESSION				
								'OL8048j' = 'DL00008' OL8048j = DL00008;				
26	52/202	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00002					
								EXPRESSION				
								'STR1Y1~Zero point offset' = 'DL00008' OL8848j = DL00008;				
27	53/211	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00005					
								EXPRESSION				
								'CX~Zero point offset' = 'DL00008' OLA048j = DL00008;				
28	53/220	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00006					
								EXPRESSION				
								'SCHY1~Zero point offset' = 'DL00008' OLA848j = DL00008;				
29	57/229	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00007					
								EXPRESSION				
								'BKPBY1~Zero point offset' = 'DL00008' OLB048j = DL00008;				
30	54/238	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00008					
								EXPRESSION				
								'OLB848j' = 'DL00008' OLB848j = DL00008;				
31	57/247	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00009					
								EXPRESSION				
								'OLC048j' = 'DL00008' OLC048j = DL00008;				
32	70/259	NL	3	DB000900i ABS Origin Setting Cmp	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00009	==	[WLFQD]SrcA DW00019 Axis Index	[WLFQD]SrcB 00097		
								EXPRESSION				
								'ML999990' = 'DL00008' ML999990 = DL00008;				
33	74/269	NL	3	DB000800i Motion Command Set	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00001					
								EXPRESSION				
								'OW8008j' = 'Motion Command Code' OW8008j = DW00010;				
34	77/278	NL	3	DB000800i Motion Command Set	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00002					
								EXPRESSION				
								'STR1Y1~Motion command' = 'Motion Command Code' OW8808j = DW00010;				
35	80/287	NL	3	DB000800i Motion Command Set	==	[WLFQD]SrcA DW00021 LineNo	[WLFQD]SrcB 00005					
								EXPRESSION				
								'CX~Motion command' = 'Motion Command Code' OWA008j = DW00010;				

Line No	Condition	Action
36 83/290	DB000800i Motion Com mand Set	[WLFQD]SrcA DW00021 LineNo == [WLFQD]SrcB 00006 EXPRESSION 'SCHY1~Motion command' = 'Motion Command Code' OWA808j = DW00010;
37 86/305	DB000800i Motion Com mand Set	[WLFQD]SrcA DW00021 LineNo == [WLFQD]SrcB 00007 EXPRESSION 'BKPHY1~Motion command' = 'Motion Command Code' OWB008j = DW00010;
38 88/314	DB000800i Motion Com mand Set	[WLFQD]SrcA DW00021 LineNo == [WLFQD]SrcB 00008 EXPRESSION 'OWB808j' = 'Motion Command Code' OWB808j = DW00010;
39 89/323	DB000800i Motion Com mand Set	[WLFQD]SrcA DW00021 LineNo == [WLFQD]SrcB 00009 EXPRESSION 'OWC008j' = 'Motion Command Code' OWC008j = DW00010;
40 95/329	DB000025 Zero Point R eturn Compl eted DB000900i ABS Origin Setting Cmp	DB000800i Motion Com mand Set
41 98/332	END_IF	
42 99/333	END_FOR	
43 100/334	END	

...	/0269i
...	/0296i
...	/0323i

.../0287i
.../0314i