

H10.51:IO Management_Unit1									

* DL Register Area - 120Word									
* DW00000 - DW00009 (Pls Use)									
* DW00010 - DW00039 (BIT Use)									
* DW00040 - DW00089 (Word Use)									
* DW00090 - DW00119 (Timer)									

# Program Name : IO Management_Unit1									
#									
# Function :									
#									
# Call Program : H10									
#									
# Sub Program :									
#									
# Func Program :									

Command Bit Operation									
Vacuum									
0	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001				
1	NL				EXPRESSION				
	2				'I' = 'DW00040' I = DW00040;				
2	NL	MB040840i	DB000000i					MB040850i	[MB040850]
	2	Unit1 Vacuum 1 On (Sol)	Pls					Unit1 Vacuum 1 Off (Sol)	.../0009i H50.11/0079w L20.41/0005
3	NL	MB040850i	DB000010i					MB040840i	[MB040840]
	2	Unit1 Vacuum 1 Off (Sol)	Pls					Unit1 Vacuum 1 On (Sol)	.../0006i H50.11/0070w L20.41/0001
4	NL	MB041920i	DB000020i					MB041920i	[MB041920]
	2	Unit1 Vacuum 17 On (Sol)	Pls					Unit1 Vacuum 17 On (Sol)	.../0012i .../0017iw
5	NL	MB041930i	DB000030i					MB041920i	[MB041920]
	2	Unit1 Vacuum 17 Off (Sol)	Pls					Unit1 Vacuum 17 On (Sol)	.../0012i .../0014iw
6		END_FOR							L20.41/0129
Blow									
7	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001				
8	NL				EXPRESSION				
	2				'I' = 'DW00040' I = DW00040;				
9	NL	MB040860i	DB000040i					MB040870i	[MB040870]
	2	Unit1 Blow 1 O n (Sol)	Pls					Unit1 Blow 1 O ff (Sol)	.../0028i H50.11/0122w L10.61/0244i
10	NL	MB040870i	DB000050i					MB040860i	[MB040860]
	2	Unit1 Blow 1 O ff (Sol)	Pls					Unit1 Blow 1 O n (Sol)	.../0025i H50.11/0118w L10.61/0242i
11	NL	MB041940i	DB000060i					MB041950i	[MB041950]
	2	Unit1 Blow 17 On (Sol)	Pls					Unit1 Blow 17 Off (Sol)	.../0034i L20.41/0389
12	NL	MB041950i	DB000070i					MB041940i	[MB041940]
	2	Unit1 Blow 17 Off (Sol)	Pls					Unit1 Blow 17 On (Sol)	.../0031i L20.41/0385
13		END_FOR							
Cylinder									
14	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00031	[W]Step 00001				
15	NL				EXPRESSION				
	2				'I' = 'DW00040' I = DW00040;				
16	NL	MB040800i	DB000080i					MB040820i	[MB040820]
	2	Unit1 Cylinder 1 Forward (Sol)	Pls					Unit1 Cylinder 1 Backward (Sol)	.../0047i L10.61/0081i
17	NL	MB040820i	DB000090i					MB040800i	[MB040800]
	2	Unit1 Cylinder 1 Backward (Sol)	Pls					Unit1 Cylinder 1 Forward (Sol)	.../0044i L10.61/0083i
18		END_FOR							
19				END					