

L60.22:Step Btn Enable(5 Circuit)									
0	MB00000F							DB000000	[DB000000] .../0105 .../0117 .../0123 .../0129 .../0232 .../0242 .../0248 .../0254
	Debug							---	.../0109 .../0119 .../0125 .../0131 .../0238 .../0244 .../0250 .../0252
1					STORE	[WLFQD]SrcA 05000	[WLFQD]SrcB DL00050		[DL00050] .../0038 .../0184 .../0161
2				SETW	[W]Dest MW90388	[W]Data HFFFF	[W]Width 00016		[MW90388] .../0261w L40.40/0210i
3				SETW	[W]Dest MW90516	[W]Data HFFFF	[W]Width 00016		[MW90516] .../0264w L40.40/0285i
Step(-) Enable 조건 33 Axis (CX) DL00010 ~ DL00018									
4				SUB	[WLFQD]SrcA CAMX~ APOS CAMX~Machine coordinate feed back Positi-	[WLFQD]SrcB CX~ APOS CX~Machine c oordinate feed back position -	[WLFQD]Dest DL00010		[DL00010] .../0040
5	<	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB ML26334 [EQ][90] Chuc k Y Origine Ed ge ~ Camera-	SUB	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB 10000	[WLFQD]Dest DL00012		[DL00012] .../0029w .../0034
6	>=	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB ML26334 [EQ][90] Chuc k Y Origine Ed ge ~ Camera-	SUB	[WLFQD]SrcA ML26334 [EQ][90] Chuck Y Origine Edge ~ Camera Ce-	[WLFQD]SrcB 10000	[WLFQD]Dest DL00012		[DL00012] .../0020w .../0034
7				SUB	[WLFQD]SrcA ML27810 [EQ]BKPBY O rigine Upper E dge ~ Camera-	[WLFQD]SrcB ML27824 [EQ]BKPBY ~ Cutter X Min In terference Dis-	[WLFQD]Dest DL00014		[DL00014] .../0051
8				SUB	[WLFQD]SrcA DL00012	[WLFQD]SrcB ML26324 [EQ]Chuck Y - Cutter X Interfe rence Avoid D-	[WLFQD]Dest DL00016		[DL00016] .../0048
9				SUB	[WLFQD]SrcA ML01156 Upper Left Ali gnment Position	[WLFQD]SrcB DL00050	[WLFQD]Dest DL00018		[DL00018] .../0054
10	>	[WLFQD]SrcA DL00010	[WLFQD]SrcB ML26344 [EQ]Left Uppe r Head ~ Right Upper Head -				MB903880		
	MB00000F								
	Debug								
11	MB045740						MB903881		
	All Cutter Z Wa it Position								
12	>	[WLFQD]SrcA DL00016	[WLFQD]SrcB SCHY1~APC S SCHY1~Machi ne coordinate feedback posi-				MB903882		
13	>	[WLFQD]SrcA DL00014	[WLFQD]SrcB BKPBY1~A POS BKPBY1~Mac hine coordinat e feedback p-				MB903883		
14	<=	[WLFQD]SrcA DL00018	[WLFQD]SrcB CAMX~APO CAMX~Machi ne coordinate feedback Posi-				MB903884		
	MB045726								
	Manual Alignm ent Flag								
34 Axis (CAMX) DL00020 ~ DL00028									
15				SUB	[WLFQD]SrcA CAMX~ APOS CAMX~Machine coordinate fe edback Positi-	[WLFQD]SrcB CX~ APOS CX~Machine c oordinate feed back position -	[WLFQD]Dest DL00020		[DL00020] .../0066
16				SUB	[WLFQD]SrcA ML01158 Upper Right Ali gnement Positi on	[WLFQD]SrcB DL00050	[WLFQD]Dest DL00022		[DL00022] .../0069
17	>	[WLFQD]SrcA DL00020	[WLFQD]SrcB ML26344 [EQ]Left Uppe r Head ~ Right Upper Head -				MB903890		
18	<=	[WLFQD]SrcA DL00022	[WLFQD]SrcB CX~ APOS CX~Machine c oordinate feed back position -				MB903891		
	MB045726								
	Manual Alignm ent Flag								

19	32/73	<	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB ML26334 [EQ][90] Chuc k Y Origine Ed ge ~ Camera-	SUB	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB 10000	[WLFQD]Dest DL00024 ---	[DL00024] .../0091w	.../0093
20	34/84	>=	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB ML26334 [EQ][90] Chuc k Y Origine Ed ge ~ Camera-	SUB	[WLFQD]SrcA ML26334 [EQ][90] Chuck Y Origine Edge ~ Camera Ce-	[WLFQD]SrcB 10000	[WLFQD]Dest DL00024 ---	[DL00024] .../0082w	.../0093
21	36/93				SUB	[WLFQD]SrcA DL00024 ---	[WLFQD]SrcB ML26324 [EQ]Chuck Y - Cutter X Interfe rence Avoid D-	[WLFQD]Dest DL00026 ---	[DL00026] .../0096	
22	37/95	>	[WLFQD]SrcA DL00026 ---	[WLFQD]SrcB 3CHY1~APC S SCHY1~Machi ne coordinate feedback posi-				MB903892 ○ ---		
23	39/99				SUB	[WLFQD]SrcA ML27810 [EQ]BKPBY O rigine Upper E dge ~ Camera-	[WLFQD]SrcB ML27824 [EQ]BKPBY ~ Cutter X Min In terference Dis-	[WLFQD]Dest DL00028 ---	[DL00028] .../0102	
24	40/102	>	[WLFQD]SrcA DL00028 ---	[WLFQD]SrcB BKPBY1~A POS BKPBY1~Mac hine coordinat e feedback p-				MB903893 ○ ---		
35 Axis (CZ) DL00030 ~ DL00038										
25	42/103		DB000000 ┌─┴─┐ ---					MB903900 ○ ---		
36 Axis (CS) DL00040 ~ DL00048										
26	44/107		MB045726 ┌─┴─┐ Manual Alignm ent Flag					MB903910 ○ ---		
37 Axis (SP) DL00050 ~ DL00058										
27	46/109		DB000000 ┌─┴─┐ ---					MB903920 ○ ---		
38 Axis (LCAMY) DL00060 ~ DL00068										
28	48/111		MB045726 ┌─┴─┐ Manual Alignm ent Flag					MB903930 ○ ---		
39 Axis (RCAMY) DL00070 ~ DL00078										
29	50/113		MB045726 ┌─┴─┐ Manual Alignm ent Flag					MB903940 ○ ---		
40 Axis (LCAMZ) DL00080 ~ DL00088										
30	52/115		DB000000 ┌─┴─┐ ---					MB903950 ○ ---		
41 Axis (RCAMZ) DL00090 ~ DL00098										
31	54/117		DB000000 ┌─┴─┐ ---					MB903960 ○ ---		
42 Axis (SP) DL00100 ~ DL00108										
32	56/119		DB000000 ┌─┴─┐ ---					MB903970 ○ ---		
43 Axis (SP) DL00110 ~ DL00118										
33	58/121		DB000000 ┌─┴─┐ ---					MB903980 ○ ---		
44 Axis (SP) DL00120 ~ DL00128										
34	60/123		DB000000 ┌─┴─┐ ---					MB903990 ○ ---		
45 Axis (SP) DL00130 ~ DL00138										
35	62/125		DB000000 ┌─┴─┐ ---					MB904000 ○ ---		
46 Axis (SP) DL00140 ~ DL00148										
36	64/127		DB000000 ┌─┴─┐ ---					MB904010 ○ ---		

47 Axis (SP)									
DL00150 ~ DL00158									
37	DB000000							MB904020	
38	DB000000							MB904030	
48 Axis (SP)									
DL00160 ~ DL00168									
Step(+) Enable 조건									
33 Axis (CX)									
DL00210 ~ DL00218									
39				SUB	[WLFQD]SrcA AMX~ APOS CAMX~Machine coordinate feedback Position -	[WLFQD]SrcB CX~ APOS CX~Machine coordinate feedback position -	[WLFQD]Dest DL00210 ---	[DL00210] .../0163	
40	<	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Center	[WLFQD]SrcB ML26334 [EQ][90] Chuck Y Origine Edge ~ Camera-	SUB	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Center	[WLFQD]SrcB 10000	[WLFQD]Dest DL00212 ---	[DL00212] .../0152w	.../0157
41	>=	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Center	[WLFQD]SrcB ML26334 [EQ][90] Chuck Y Origine Edge ~ Camera-	SUB	[WLFQD]SrcA ML26334 [EQ][90] Chuck Y Origine Edge ~ Camera Center	[WLFQD]SrcB 10000	[WLFQD]Dest DL00212 ---	[DL00212] .../0143w	.../0157
42				SUB	[WLFQD]SrcA ML27810 [EQ]BKPBY Origine Upper Edge ~ Camera-	[WLFQD]SrcB ML27824 [EQ]BKPBY ~ Cutter X Min Interference Dis-	[WLFQD]Dest DL00214 ---	[DL00214] .../0171	
43				SUB	[WLFQD]SrcA DL00212 ---	[WLFQD]SrcB ML26324 [EQ]Chuck Y - Cutter X Interference Avoid D-	[WLFQD]Dest DL00216 ---	[DL00216] .../0168	
44				SUB	[WLFQD]SrcA ML01156 Upper Left Alignment Position	[WLFQD]SrcB DL00050 ---	[WLFQD]Dest DL00218 ---	[DL00218] .../0174	
45	>	[WLFQD]SrcA DL00210 ---	[WLFQD]SrcB ML26344 [EQ]Left Upper Head ~ Right Upper Head -				MB905160		
46	MB045740						MB905161		
47	All Cutter Z Wait Position						MB905162		
48	>	[WLFQD]SrcA DL00216 ---	[WLFQD]SrcB SCHY1~APCS SCHY1~Machine coordinate feedback position -				MB905163		
49	<=	[WLFQD]SrcA DL00214 ---	[WLFQD]SrcB BKPBY1~APCS BKPBY1~Machine coordinate feedback position -				MB905164		
50	MB045726								
51	Manual Alignment Flag								
34 Axis (CAMX)									
DL00220 ~ DL00228									
50				SUB	[WLFQD]SrcA AMX~ APOS CAMX~Machine coordinate feedback Position -	[WLFQD]SrcB CX~ APOS CX~Machine coordinate feedback position -	[WLFQD]Dest DL00220 ---	[DL00220] .../0186	
51				SUB	[WLFQD]SrcA ML01158 Upper Right Alignment Position	[WLFQD]SrcB DL00050 ---	[WLFQD]Dest DL00222 ---	[DL00222] .../0192	
52	>	[WLFQD]SrcA DL00220 ---	[WLFQD]SrcB ML26344 [EQ]Left Upper Head ~ Right Upper Head -				MB905170		
53	MB00000F								
53	Debug								
53	<=	[WLFQD]SrcA DL00222 ---	[WLFQD]SrcB CX~ APOS CX~Machine coordinate feedback position -				MB905171		
54	MB045726								
54	Manual Alignment Flag								
54	<	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Center	[WLFQD]SrcB ML26334 [EQ][90] Chuck Y Origine Edge ~ Camera-	SUB	[WLFQD]SrcA ML26332 [EQ][0] Chuck Y Origine Edge ~ Camera Center	[WLFQD]SrcB 10000	[WLFQD]Dest DL00224 ---	[DL00224] .../0214w	.../0216

55	10/2/2017	>=	[WLFQD]SrcA ML26332 [EQ]]0] Chuck Y Origine Edge ~ Camera Cen-	[WLFQD]SrcB ML26334 [EQ]]90] Chuc k Y Origine Ed ge ~ Camera-	SUB	[WLFQD]SrcA ML26334 [EQ]]90] Chuck Y Origine Edge ~ Camera Ce-	[WLFQD]SrcB 10000	[WLFQD]Dest DL00224 ---	[DL00224] .../0205w	.../0216
56	10/12/16				SUB	[WLFQD]SrcA DL00224 ---	[WLFQD]SrcB ML26324 [EQ]Chuck Y - Cutter X Interfe rence Avoid D-	[WLFQD]Dest DL00226 ---	[DL00226] .../0219	
57	10/2/219	>	[WLFQD]SrcA DL00226 ---	[WLFQD]SrcB SCHY1~.APC S SCHY1~Machi ne coordinate feedback posi-				MB905172 ○ ---		
58	10/1/222				SUB	[WLFQD]SrcA ML27810 [EQ]BKPBY O rigine Upper E dge ~ Camera-	[WLFQD]SrcB ML27824 [EQ]BKPBY ~ Cutter X Min In terference Dis-	[WLFQD]Dest DL00228 ---	[DL00228] .../0225	
59	10/5/225	>	[WLFQD]SrcA DL00228 ---	[WLFQD]SrcB BKPBY1~.A POS BKPBY1~Mac hine coordinat e feedback p-				MB905173 ○ ---		
35 Axis (CZ) DL00230 ~ DL00238										
60	10/7/228		DB000000 ---					MB905180 ○ ---		
36 Axis (CS) DL00240 ~ DL00248										
61	10/9/230		MB045726 Manual Alignm ent Flag					MB905190 ○ ---		
37 Axis (SP) DL00250 ~ DL00258										
62	11/1/232		DB000000 ---					MB905200 ○ ---		
38 Axis (LCAMY) DL00260 ~ DL00268										
63	11/3/234		MB045726 Manual Alignm ent Flag					MB905210 ○ ---		
39 Axis (RCAMY) DL00270 ~ DL00278										
64	11/5/236		MB045726 Manual Alignm ent Flag					MB905220 ○ ---		
40 Axis (LCAMZ) DL00280 ~ DL00288										
65	11/7/238		DB000000 ---					MB905230 ○ ---		
41 Axis (RCAMZ) DL00290 ~ DL00298										
66	11/9/240		DB000000 ---					MB905240 ○ ---		
42 Axis (SP) DL00300 ~ DL00308										
67	12/1/242		DB000000 ---					MB905250 ○ ---		
43 Axis (SP) 43 Axis (LCTY1) DL00310 ~ DL00318										
68	12/3/244		DB000000 ---					MB905260 ○ ---		
44 Axis (SP) 44 Axis (LCTY2) DL00320 ~ DL00328										
69	12/5/246		DB000000 ---					MB905270 ○ ---		
45 Axis (SP) DL00330 ~ DL00338										
70	12/7/248		DB000000 ---					MB905280 ○ ---		
46 Axis (SP) DL00340 ~ DL00348										
71	12/9/250		DB000000 ---					MB905290 ○ ---		

