

```

00001      *****
00002      ** DL Register Area - 120Word
00003      **
00004      ** DW00000 - DW00009 (PLS Use)
00005      ** DW00010 - DW00039 (Bit Use)
00006      ** DW00040 - DW00089 (Word Use)
00007      ** DW00090 - DW00119 (Timer)
00008      *****
00009
00010      "# Program Name   : BKP Manual (Pto
00011      "# Function      :
00012      "# Call Program   : H60.2
00013      "# Sub Program    :
00014      "# Func Program   :
00015
00016      VAR;
00017
00018      END_VAR;
00019
00020      " Request All Stop Request Reset
00021 00000      MB045709 = 0;
00022
00023 00001      MW23912 = ML20080          " Recipe ID (Scribe)
00024 00002      MW23916 = ML20080          " Recipe ID (Break)
00025
00026      " Recipe Data Reading
00027 00003      MB214602 = 1;              " Parameter Update Request (Scribe)
00028 00004      IOW MB205202 == 1          " Parameter Update Reply (Scribe)
00029 00005      MB214604 = 1;              " Parameter Update Request (Break)
00030 00006      IOW MB205204 == 1          " Parameter Update Reply (Break)
00031 00007      MB21462B = 1;              " Parameter Update Request (Scribe Pitch)
00032 00008      )
00033 00009      IOW MB20522B == 1          " Parameter Update Reply (Scribe Pitch)
00034      EOX;
00035 00010      MSEE MPS180;              " Data Update
00036
00037      " Request Scribe Recipe Data Updata Waiting
00038 00011      MB045241 = 1;
00039 00012      MW05420 = 0;
00040 00013      EOX;
00041
00042 00014      IOW MB50720 == 1          " BCHK Auto Task Update Waiting
00043
00044      *****
00045      ***** Break Pusher Bar LBL01~08 *****
00046      *****
00047
00048
00049
00050 00015      SFORK   MW00052 == 01 ? LBL01      " [BKPBY] Break Pusher Bar Y Standby Position
00051      MW00052 == 02 ? LBL02      "
00052      MW00052 == 03 ? LBL03      " [BKPBY] Break Pusher Bar Y Breaking Position
00053      MW00052 == 04 ? LBL04      "
00054      MW00052 == 05 ? LBL05      "
00055      MW00052 == 06 ? LBL06      "
00056      MW00052 == 07 ? LBL07      "
00057      MW00052 == 08 ? LBL08      "
00058      DEFAULTI      ? LBL300;
00059
00060 00016      LBL01: " Break Pusher Bar Y Standby Position
00061
00062 00017      ML16128 = ML46430          " Break Pusher Bar Y Standby Position
00063 00018      IOW MB050760 == 1          " Break Pusher Bar Y Standby Position permission
00064 00019      MOV [BKPBY1]ML16128 [BKPBY2]ML16128;
00065 00020      IOW MB051000 == 1          " Break Pusher Bar Y Standby Position Check
00066
00067 00021      JOINTO LBL0X;
00068
00069 00022      LBL02:
00070 00023      JOINTO LBL0X;
00071
00072 00024      LBL03: " Break Pusher Bar Y Breaking Position
00073
00074 00025      ML16128 = ML72814          " Break Pusher Bar Y Standby Position
00075 00026      ML16130 = ML72814;
00076 00027      IOW MB050763 == 1          " Break Pusher Bar Y Standby Position permission
00077 00028      MOV [BKPBY1]ML16128 [BKPBY2]ML16130;
00078 00029      IOW MB051003 == 1          " Break Pusher Bar Y Standby Position Check
00079
00080 00030      JOINTO LBL0X;
00081
00082 00031      LBL04:
00083 00032      JOINTO LBL0X;
00084
00085 00033      LBL05:
00086 00034      JOINTO LBL0X;

```

```

00087
00088 00035      LBL06:
00089 00036          JOINTO LBL0X;
00090
00091 00037      LBL07:
00092 00038          JOINTO LBL0X;
00093
00094 00039      LBL08:
00095 00040          JOINTO LBL0X;
00096
00097 00041      LBL300:
00098 00042          JOINTO LBL0X;
00099 00043      LBL0X: SJOINT;
00100
00101
00102
00103      *****
00104      ***** Break Pusher Bar LBL09~16 *****
00105      *****
00106 00044      SFORK   MW00052 == 09 ? LBL09      " [BKPB] Break Pusher Bar Y Last Breaking Position
00107                      MW00052 == 10 ? LBL10      "
00108                      MW00052 == 11 ? LBL11      " [BKPB] Break Pusher Bar Y Cleaning Start Position
00109                      MW00052 == 12 ? LBL12      " [BKPB] Break Pusher Bar Y Cleaning End Position
00110                      MW00052 == 13 ? LBL13      "
00111                      MW00052 == 14 ? LBL14      "
00112                      MW00052 == 15 ? LBL15      "
00113                      MW00052 == 16 ? LBL16      "
00114                      DEFAULT      ? LBL301;
00115
00116 00045      LBL09: " Break Pusher Bar Y Last Breaking Position
00117
00118 00046          ML16128 = ML72834                      " Break Pusher Bar Y Last Breaking Position
00119 00047          IOW MB050768 == 1                      " Break Pusher Bar Y Last Breaking Position perm
00120 00048      mission
00121 00049          MOV [BKPB]ML16128 [BKPB]ML16128;
00122          IOW MB051008 == 1                      " Break Pusher Bar Y Last Breaking Position Chec
00123          k
00124
00125 00050          JOINTO LBL1X;
00126
00127 00051      LBL10:
00128 00052          JOINTO LBL1X;
00129
00128 00053      LBL11: " Break Pusher Bar Y Cleaning Start Position
00129
00130 00054          ML16128 = ML72842                      " Break Pusher Bar Y Cleaning Start Position
00131 00055          IOW MB05076A == 1                      " Break Pusher Bar Y Cleaning Start Position per
00132 00056      mission
00133 00057          MOV [BKPB]ML16128 [BKPB]ML16128;
00134          IOW MB05100A == 1                      " Break Pusher Bar Y Cleaning Start Position Che
00135          ck
00136
00137 00058          JOINTO LBL1X;
00138
00137 00059      LBL12: " Break Pusher Bar Y Cleaning End Position
00138
00139 00060          ML16128 = ML72846                      " Break Pusher Bar Y Cleaning End Position
00140 00061          IOW MB05076B == 1                      " Break Pusher Bar Y Cleaning End Position permi
00141 00062      ssion
00142 00063          MOV [BKPB]ML16128 [BKPB]ML16128;
00143          IOW MB05100B == 1                      " Break Pusher Bar Y Cleaning End Position Check
00144
00144 00064          JOINTO LBL1X;
00145
00146 00065      LBL13:
00147 00066          JOINTO LBL1X;
00148
00149 00067      LBL14:
00150 00068          JOINTO LBL1X;
00151
00152 00069      LBL15:
00153 00070          JOINTO LBL1X;
00154
00155 00071      LBL16:
00156 00072          JOINTO LBL1X;
00157
00158 00073      LBL301:
00159 00074          JOINTO LBL1X;
00160 00075      LBL1X: SJOINT;
00161
00162
00163      *****
00164      ***** Break Pusher Bar LBL17~24 *****
00165      *****
00166
00167 00076      SFORK   MW00052 == 17 ? LBL17      " [BKPBZ] Break Pusher Bar Z Standby Position
00168                      MW00052 == 18 ? LBL18      "

```

```

00169          MW00052 == 19 ? LBL19      " [BKPZ] Break Pusher Bar Z Breaking Start Position
00170          MW00052 == 20 ? LBL20      " [BKPZ] Break Pusher Bar Z Breaking End Position
00171          MW00052 == 21 ? LBL21      "
00172          MW00052 == 22 ? LBL22      "
00173          MW00052 == 23 ? LBL23      "
00174          MW00052 == 24 ? LBL24      "
00175          DEFAULT      ? LBL302;
00176
00177 00077      LBL17: " Break Pusher Bar Z Standby Position
00178
00179 00078          ML16132 = ML73202          " Break Pusher Bar Z Standby Position
00180 00079          IOW MB050770 == 1          " Break Pusher Bar Z Standby Position permission
00181 00080          MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00182 00081          IOW MB051020 == 1          " Break Pusher Bar Z Standby Position Check
00183
00184 00082          JOINTO LBL2X;
00185
00186 00083      LBL18:
00187 00084          JOINTO LBL2X;
00188
00189 00085      LBL19: " Break Pusher Bar Z Breaking Start Position
00190
00191 00086          ML16132 = ML73214          " Break Pusher Bar Z Breaking Start Position
00192 00087          IOW MB050773 == 1          " Break Pusher Bar Z Breaking Start Position per
mission
00193 00088          MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00194 00089          IOW MB051023 == 1          " Break Pusher Bar Z Breaking Start Position Che
ck
00195
00196 00090          JOINTO LBL2X;
00197
00198 00091      LBL20: " Break Pusher Bar Z Breaking Start Position
00199
00200 00092          ML16132 = ML73218          " Break Pusher Bar Z Breaking End Position
00201 00093          IOW MB050774 == 1          " Break Pusher Bar Z Breaking End Position permi
ssion
00202 00094          MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00203 00095          IOW MB051024 == 1          " Break Pusher Bar Z Breaking End Position Check
00204
00205 00096          JOINTO LBL2X;
00206
00207 00097      LBL21:
00208 00098          JOINTO LBL2X;
00209
00210 00099      LBL22:
00211 00100          JOINTO LBL2X;
00212
00213 00101      LBL23: " Break Pusher Bar Z Last Breaking Start Position
00214
00215 00102          ML16132 = ML73234          " Break Pusher Bar Z Breaking End Position
00216 00103          IOW MB050778 == 1          " Break Pusher Bar Z Breaking End Position permi
ssion
00217 00104          MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00218 00105          IOW MB051028 == 1          " Break Pusher Bar Z Breaking End Position Check
00219
00220 00106          JOINTO LBL2X;
00221
00222 00107      LBL24: " Break Pusher Bar Z Last Breaking End Position
00223
00224 00108          ML16132 = ML73238          " Break Pusher Bar Z Breaking End Position
00225 00109          IOW MB050779 == 1          " Break Pusher Bar Z Breaking End Position permi
ssion
00226 00110          MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00227 00111          IOW MB051029 == 1          " Break Pusher Bar Z Breaking End Position Check
00228
00229 00112          JOINTO LBL2X;
00230
00231 00113      LBL302:
00232 00114          JOINTO LBL2X;
00233 00115      LBL2X: SJOINT;
00234
00235      *****
00236      ***** Break Pusher Bar LBL25~32 *****
00237      *****
00238
00239
00240 00116      SFORK  MW00052 == 25 ? LBL25      "
00241          MW00052 == 26 ? LBL26      "
00242          MW00052 == 27 ? LBL27      " [BKPZ] Break Pusher Bar Z Cleaning Position
00243          MW00052 == 28 ? LBL28      "
00244          MW00052 == 29 ? LBL29      "
00245          MW00052 == 30 ? LBL30      "
00246          MW00052 == 31 ? LBL31      "
00247          MW00052 == 32 ? LBL32      "
00248          DEFAULT      ? LBL303;
00249
00250 00117      LBL25:

```

```

00251 00118      JOINTO LBL3X;
00252
00253 00119      LBL26:
00254 00120      JOINTO LBL3X;
00255
00256 00121      LBL27: " Break Pusher Bar Z Cleaning Position
00257
00258 00122      ML16132 = ML73242                " Break Pusher Bar Z Cleaning Position
00259 00123      IOW MB05077A == 1                " Break Pusher Bar Z Cleaning Position permissio
n
00260 00124      MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00261 00125      IOW MB05102A == 1                " Break Pusher Bar Z Cleaning Position Check
00262
00263 00126      JOINTO LBL3X;
00264
00265 00127      LBL28:
00266 00128      JOINTO LBL3X;
00267
00268 00129      LBL29:
00269 00130      JOINTO LBL3X;
00270
00271 00131      LBL30:
00272 00132      JOINTO LBL3X;
00273
00274 00133      LBL31:
00275 00134      JOINTO LBL3X;
00276
00277 00135      LBL32:
00278 00136      JOINTO LBL3X;
00279
00280 00137      LBL303:
00281 00138      JOINTO LBL3X;
00282 00139      LBL3X: SJOINT;
00283
00284
00285      "*****
00286      "***** Break Pusher Bar LBL65~72 *****
00287      "*****
00288
00289 00140      SFORK MW00052 == 65 ? LBL65      " [Position] Break Pusher Bar Standby Position
00290      MW00052 == 66 ? LBL66      "
00291      MW00052 == 67 ? LBL67      " [Position] Break Pusher Bar Breaking Start Position
00292      MW00052 == 68 ? LBL68      " [Position] Break Pusher Bar Breaking End Position
00293      MW00052 == 69 ? LBL69      "
00294      MW00052 == 70 ? LBL70      "
00295      MW00052 == 71 ? LBL71      " [Position] Break Pusher Bar Last Breaking Start Position
00296      MW00052 == 72 ? LBL72      " [Position] Break Pusher Bar Last Breaking End Position
00297      DEFAULT ? LBL308;
00298
00299 00141      LBL65: " Break Pusher Bar Standby Positi
0300
0301 00142      IOW MW04520 == 0                " [ SC Request BCHK ] Command Code ID Se
t
0302 00143      MW04520 = 10;                " [ SC Request BCHK ] Command Code ID Se
t
0303 00144      MB045210 = 1;                " [ SC Request BCHK ] Command S
0304 00145      IOW MB045211 == 1            " [ SC Response BCHK ] Command Complete
0305 00146      MB045210 = 0;                " [ SC Request BCHK ] Command S
0306 00147      IOW MB045211 == 0            " [ SC Response BCHK ] Command Complete
0307 00148      MW04520 = 0;                " [ SC Request BCHK ] Command Code ID Se
t
0308
0309 00149      IOW MB04572A == 0            " BCHK Moving Flag OFF
0310
0311 00150      JOINTO LBL8X;
0312
0313 00151      LBL66: "
0314 00152      JOINTO LBL8X;
0315
0316 00153      LBL67: " Break Pusher Bar Breaking Start Position
0317
0318      " Cutter X Cutting After Escape Position
0319 00154      IF !MB045741 == 1;
0320 00155      MW04514 = 1;
0321 00156      MB045150 = 1;                " Scribe Req Scribe Cutter Command Execu
te Bit ON
0322 00157      IOW MB045151 == 1            " Scribe Res Scribe Cutter Command Compl
ete Bit ON
0323 00158      MB045150 = 0;                " Scribe Req Scribe Cutter Command Execu
te Bit OFF
0324 00159      IOW MB045151 == 0            " Scribe Res Scribe Cutter Command Compl
ete Bit ON
0325 00160      IEND;
0326
0327 00161      IOW MW04520 == 0                " [ SC Request BCHK ] Command Code ID Se
t

```

```

00328 00162      MW04520 = 3;                                " [ SC Request BCHK ] Command Code ID Se
t
00329 00163      MB045210 = 1;                                " [ SC Request BCHK ] Command S€
00330 00164      IOW MB045211 == 1;                            " [ SC Response BCHK ] Command Complete
00331 00165      MB045210 = 0;                                " [ SC Request BCHK ] Command S€

00332 00166      IOW MB045211 == 0;                            " [ SC Response BCHK ] Command Complete
00333 00167      MW04520 = 0;                                " [ SC Request BCHK ] Command Code ID Se
t
00334
00335 00168      IOW MB04572A == 0;                            " BCHK Moving Flag OFF
00336
00337 00169      JOINTO LBL8X;
00338
00339 00170      LBL68: " Break Pusher Bar Breaking End Position
00340
00341      " Cutter X Cutting After Escape Position
00342 00171      IF !MB045741 == 1;
00343 00172      MW04514 = 1;
00344 00173      MB045150 = 1;                                " Scribe Req Scribe Cutter Command Execu
te Bit ON
00345 00174      IOW MB045151 == 1;                            " Scribe Res Scribe Cutter Command Compl
ete Bit ON
00346 00175      MB045150 = 0;                                " Scribe Req Scribe Cutter Command Execu
te Bit OFF
00347 00176      IOW MB045151 == 0;                            " Scribe Res Scribe Cutter Command Compl
ete Bit ON
00348 00177      IEND;
00349
00350 00178      IOW MW04520 == 0;                                " [ SC Request BCHK ] Command Code ID Se
t
00351 00179      MW04520 = 4;                                " [ SC Request BCHK ] Command Code ID Se
t
00352 00180      MB045210 = 1;                                " [ SC Request BCHK ] Command S€
00353 00181      IOW MB045211 == 1;                            " [ SC Response BCHK ] Command Complete
00354 00182      MB045210 = 0;                                " [ SC Request BCHK ] Command S€

00355 00183      IOW MB045211 == 0;                            " [ SC Response BCHK ] Command Complete
00356 00184      MW04520 = 0;                                " [ SC Request BCHK ] Command Code ID Se
t
00357
00358 00185      IOW MB04572A == 0;                            " BCHK Moving Flag OFF
00359
00360 00186      JOINTO LBL8X;
00361
00362 00187      LBL69: "
00363 00188      JOINTO LBL8X;
00364
00365 00189      LBL70: "
00366 00190      JOINTO LBL8X;
00367
00368 00191      LBL71: " Break Pusher Bar Last Breaking Start Position
00369
00370      " Cutter X Cutting After Escape Position
00371 00192      IF !MB045741 == 1;
00372 00193      MW04514 = 1;
00373 00194      MB045150 = 1;                                " Scribe Req Scribe Cutter Command Execu
te Bit ON
00374 00195      IOW MB045151 == 1;                            " Scribe Res Scribe Cutter Command Compl
ete Bit ON
00375 00196      MB045150 = 0;                                " Scribe Req Scribe Cutter Command Execu
te Bit OFF
00376 00197      IOW MB045151 == 0;                            " Scribe Res Scribe Cutter Command Compl
ete Bit ON
00377 00198      IEND;
00378
00379 00199      IOW MW04520 == 0;                                " [ SC Request BCHK ] Command Code ID Se
t
00380 00200      MW04520 = 7;                                " [ SC Request BCHK ] Command Code ID Se
t
00381 00201      MB045210 = 1;                                " [ SC Request BCHK ] Command S€
00382 00202      IOW MB045211 == 1;                            " [ SC Response BCHK ] Command Complete
00383 00203      MB045210 = 0;                                " [ SC Request BCHK ] Command S€

00384 00204      IOW MB045211 == 0;                            " [ SC Response BCHK ] Command Complete
00385 00205      MW04520 = 0;                                " [ SC Request BCHK ] Command Code ID Se
t
00386
00387 00206      IOW MB04572A == 0;                            " BCHK Moving Flag OFF
00388
00389 00207      JOINTO LBL8X;
00390
00391 00208      LBL72: " Break Pusher Bar Last Breaking End Position
00392
00393      " Cutter X Cutting After Escape Position
00394 00209      IF !MB045741 == 1;
00395 00210      MW04514 = 1;

```

```

00396 00211          MB045150 = 1;          " Scribe Req Scribe Cutter Command Execu
te Bit ON
00397 00212          IOW MB045151 == 1      " Scribe Res Scribe Cutter Command Compl
ete Bit ON
00398 00213          MB045150 = 0;          " Scribe Req Scribe Cutter Command Execu
te Bit OFF
00399 00214          IOW MB045151 == 0      " Scribe Res Scribe Cutter Command Compl
ete Bit ON
00400 00215          IEND;
00401
00402 00216          IOW MW04520 == 0        " [ SC Request BCHK ] Command Code ID Se
t
00403 00217          MW04520 = 8;           " [ SC Request BCHK ] Command Code ID Se
t
00404 00218          MB045210 = 1;           " [ SC Request BCHK ] Command S€
00405 00219          IOW MB045211 == 1      " [ SC Response BCHK ] Command Complete
00406 00220          MB045210 = 0;           " [ SC Request BCHK ] Command S€

00407 00221          IOW MB045211 == 0      " [ SC Response BCHK ] Command Complete
00408 00222          MW04520 = 0;           " [ SC Request BCHK ] Command Code ID Se
t
00409
00410 00223          IOW MB04572A == 0       " BCHK Moving Flag OFF
00411
00412 00224          JOINTO LBL8X;
00413
00414 00225          LBL308:
00415 00226          JOINTO LBL8X;
00416 00227          LBL8X: SJOINT;
00417
00418
00419          *****
00420          ***** Break Pusher Bar LBL73~80 *****
00421          *****
00422
00423 00228          SFORK  MW00052 == 73 ? LBL73      "
00424          MW00052 == 74 ? LBL74      "
00425          MW00052 == 75 ? LBL75      " [Position] Break Pusher Bar Cleaning Start Position
00426          MW00052 == 76 ? LBL76      " [Position] Break Pusher Bar Cleaning End Position
00427          MW00052 == 77 ? LBL77      "
00428          MW00052 == 78 ? LBL78      "
00429          MW00052 == 79 ? LBL79      "
00430          MW00052 == 80 ? LBL80      "
00431          DEFAULTI      ? LBL309;
00432
00433 00229          LBL73: "
00434 00230          JOINTO LBL9X;
00435
00436 00231          LBL74: "
00437 00232          JOINTO LBL9X;
00438
00439 00233          LBL75: " Break Pusher Bar Cleaning Start Positi
00440
00441 00234          IOW MW04520 == 0        " [ SC Request BCHK ] Command Code ID Se
t
00442 00235          MW04520 = 11;         " [ SC Request BCHK ] Command Code ID Se
t
00443 00236          MB045210 = 1;           " [ SC Request BCHK ] Command S€
00444 00237          IOW MB045211 == 1      " [ SC Response BCHK ] Command Complete
00445 00238          MB045210 = 0;           " [ SC Request BCHK ] Command S€

00446 00239          IOW MB045211 == 0      " [ SC Response BCHK ] Command Complete
00447 00240          MW04520 = 0;           " [ SC Request BCHK ] Command Code ID Se
t
00448
00449 00241          IOW MB04572A == 0       " BCHK Moving Flag OFF
00450
00451 00242          JOINTO LBL9X;
00452
00453 00243          LBL76: " Break Pusher Bar Cleaning End Positi
00454
00455 00244          IOW MW04520 == 0        " [ SC Request BCHK ] Command Code ID Se
t
00456 00245          MW04520 = 12;         " [ SC Request BCHK ] Command Code ID Se
t
00457 00246          MB045210 = 1;           " [ SC Request BCHK ] Command S€
00458 00247          IOW MB045211 == 1      " [ SC Response BCHK ] Command Complete
00459 00248          MB045210 = 0;           " [ SC Request BCHK ] Command S€

00460 00249          IOW MB045211 == 0      " [ SC Response BCHK ] Command Complete
00461 00250          MW04520 = 0;           " [ SC Request BCHK ] Command Code ID Se
t
00462
00463 00251          IOW MB04572A == 0       " BCHK Moving Flag OFF
00464
00465 00252          JOINTO LBL9X;
00466

```

```

00467 00253      LBL77:
00468 00254          JOINTO LBL9X;
00469
00470 00255      LBL78:
00471 00256          JOINTO LBL9X;
00472
00473 00257      LBL79:
00474 00258          JOINTO LBL9X;
00475
00476 00259      LBL80:
00477 00260          JOINTO LBL9X;
00478
00479 00261      LBL309:
00480 00262          JOINTO LBL9X;
00481 00263      LBL9X: SJOINT;
00482
00483
00484
00485      "*****
00486      "***** Break Pusher Bar LBL97~104 *****
00487      "*****
00488 00264      SFORK    MW00052 == 97  ? LBL97,          "
00489                  MW00052 == 98  ? LBL98,          "
00490                  MW00052 == 99  ? LBL99,          "
00491                  MW00052 == 100 ? LBL100         "
00492                  MW00052 == 101 ? LBL101         "
00493                  MW00052 == 102 ? LBL102         "
00494                  MW00052 == 103 ? LBL103         "
00495                  MW00052 == 104 ? LBL104         "
00496                  DEFAULTI    ? LBL310;
00497
00498 00265      LBL97:
00499 00266          JOINTO LBL10X,
00500
00501 00267      LBL98:
00502 00268          JOINTO LBL10X,
00503
00504 00269      LBL99:
00505 00270          JOINTO LBL10X,
00506
00507 00271      LBL100:
00508 00272          JOINTO LBL10X,
00509
00510 00273      LBL101:
00511 00274          JOINTO LBL10X;
00512
00513 00275      LBL102:
00514 00276          JOINTO LBL10X;
00515
00516 00277      LBL103:
00517 00278          JOINTO LBL10X;
00518
00519 00279      LBL104:
00520 00280          JOINTO LBL10X;
00521
00522 00281      LBL310:
00523 00282          JOINTO LBL10X;
00524 00283      LBL10X: SJOINT;
00525
00526
00527      "*****
00528      "***** Break Pusher Bar LBL97~104 *****
00529      "*****
00530
00531 00284      SFORK    MW00052 == 105 ? LBL105         "
00532                  MW00052 == 106 ? LBL106         "
00533                  MW00052 == 107 ? LBL107         " [1Cycle] Break Pusher Bar Cleaning
00534                  MW00052 == 108 ? LBL108         "
00535                  MW00052 == 109 ? LBL109         "
00536                  MW00052 == 110 ? LBL110         "
00537                  MW00052 == 111 ? LBL111         "
00538                  MW00052 == 112 ? LBL112         "
00539                  DEFAULTI    ? LBL311;
00540
00541 00285      LBL105:
00542 00286          JOINTO LBL11X,
00543
00544 00287      LBL106:
00545 00288          JOINTO LBL11X,
00546
00547 00289      LBL107:
00548
00549          " Break Pusher Bar Clean 1 Cycle
00550          " Break Pusher Bar Clean Start Position
00551      //      IF !MB5100A | !MB05102A == 1;
00552      //          " [ SC ↔ BCHK ] Motion InterFace
00553      //          MW04520 = 11;

```

" [SC Req BCHK] Command Code ID Se

```

t
00554 // MB045210 = 1; " [ SC Req BCHK ] Command Se
00555 // IOW MB045211 == 1 " [ SC Res BCHK ] Command Complete
00556 // MB045210 = 0; " [ SC Req BCHK ] Command Se

00557 // IOW MB045211 == 0 " [ SC Res BCHK ] Command Complete
00558 // MW04520 = 0; " [ SC Req BCHK ] Command Code ID Se

t
00559 // " BCHK Moving Flag OFF
00560 // IOW MB04572A == 0
00561 // IEND;
00562 //
00563 // " Break Pusher Bar Clean End Position
00564 // IF !MB5100B | !MB05102A == 1;
00565 // " [ SC ↔ BCHK ] Motion InterFace
00566 // MW04520 = 12; " [ SC Req BCHK ] Command Code ID Se

t
00567 // MB045210 = 1; " [ SC Req BCHK ] Command Se
00568 // IOW MB045211 == 1 " [ SC Res BCHK ] Command Complete
00569 // MB045210 = 0; " [ SC Req BCHK ] Command Se

00570 // IOW MB045211 == 0 " [ SC Res BCHK ] Command Complete
00571 // MW04520 = 0; " [ SC Req BCHK ] Command Code ID Se

t
00572 // " BCHK Moving Flag OFF
00573 // IOW MB04572A == 0
00574 // IEND;
00575 //
00576 // IOW MW04520 == 0 " [ SC Request BCHK ] Command Code ID Se

t
00577 // MW04520 = 10; " [ SC Request BCHK ] Command Code ID Se

t
00578 // MB045210 = 1; " [ SC Request BCHK ] Command Se
00579 // IOW MB045211 == 1 " [ SC Response BCHK ] Command Complete
00580 // MB045210 = 0; " [ SC Request BCHK ] Command Se

00581 // IOW MB045211 == 0 " [ SC Response BCHK ] Command Complete
00582 // MW04520 = 0; " [ SC Request BCHK ] Command Code ID Se

t
00583 // " BCHK Moving Flag OFF
00584 // IOW MB04572A == 0
00585 //
00586 //
00587 00290 MSEE MPS272;
00588 //
00589 00291 MSEE MPS273;
00590 //
00591 00292 MSEE MPS265;
00592 //
00593 00293 JOINTO LBL11X,
00594 //
00595 00294 LBL108:
00596 00295 JOINTO LBL11X,
00597 //
00598 00296 LBL109:
00599 00297 JOINTO LBL11X;
00600 //
00601 00298 LBL110:
00602 00299 JOINTO LBL11X;
00603 //
00604 00300 LBL111:
00605 00301 JOINTO LBL11X;
00606 //
00607 00302 LBL112:
00608 00303 JOINTO LBL11X;
00609 //
00610 00304 LBL311:
00611 00305 JOINTO LBL11X;
00612 00306 LBL11X: SJOINT;
00613 //
00614 //
00615 00307 MW05420 = MW00052;
00616 00308 MB00003E = 1;
00617 00309 END;

```