

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : BKT Manual (PTP)
00011 "# Function :
00012 "# Call Program : H60.2
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 " All Stop Request Reset
00021 00000 MB045709 = 0;
00022
00023 00001 MW23912 = ML20080 " Recipe ID (Scribe)
00024
00025 " Recipe Data Reading
00026 00002 MB214602 = 1; " Parameter Update Request (Scribe)
00027 00003 IOW MB205202 == 1 " Parameter Update Reply (Scribe)
00028 00004 MB214604 = 1; " Parameter Update Request (Break)
00029 00005 IOW MB205204 == 1 " Parameter Update Reply (Break)
00030 00006 MB21462B = 1; " Parameter Update Request (Scribe Pitch)
00031 00007 ) IOW MB20522B == 1 " Parameter Update Reply (Scribe Pitch)
00032 00008 EOX;
00033
00034 00009 MSEE MPS180; " Data Update
00035
00036 " Scribe Recipe Data Updata Waiting
00037 00010 MB045241 = 1;
00038
00039 00011 MW05920 = 0;
00040 00012 EOX;
00041
00042 00013 IOW MB55720 == 1 " Break Table Parameter Update Set
00043
00044 *****
00045 ***** Break Table LBL01~08 *****
00046 *****
00047
00048
00049 00014 SFORK MW00053 == 01 ? LBL01 " [BKTY] Break Table Y Waiting Position
00050 MW00053 == 02 ? LBL02 "
00051 MW00053 == 03 ? LBL03 "
00052 MW00053 == 04 ? LBL04 " [BKTY] Break Table Y Breaking Start Position
00053 MW00053 == 05 ? LBL05 " [BKTY] Break Table Y Breaking End Position
00054 MW00053 == 06 ? LBL06 " [BKTY] Break Table Y Carry Out Position
00055 MW00053 == 07 ? LBL07 " [BKTY] Break Table Y Escape Position
00056 MW00053 == 08 ? LBL08 "
00057 DEFAULT ? LBL300;
00058
00059 00015 LBL01: " Break Table Y Standby Position
00060
00061 00016 ML16138 = ML73802 " Break Table Y Standby Position
00062 00017 IOW MB055760 == 1 " Break Table Y Standby Position permission
00063 00018 MOV [BKTY1]ML16138 [BKTY2]ML16138;
00064 00019 IOW MB056000 == 1 " Break Table Y Standby Position Check
00065
00066 00020 JOINTO LBL0X;
00067
00068 00021 LBL02: "
00069 00022 JOINTO LBL0X;
00070
00071 00023 LBL03: "
00072 00024 JOINTO LBL0X;
00073
00074 00025 LBL04: " Break Table Y Breaking Start Position
00075
00076 00026 ML16138 = ML73814 " Break Table Y Breaking Start Position
00077 00027 IOW MB055763 == 1 " Break Table Y Breaking Start Position permissi
on
00078 00028 MOV [BKTY1]ML16138 [BKTY2]ML16138;
00079 00029 IOW MB056003 == 1 " Break Table Y Breaking Start Position Check
00080
00081 00030 JOINTO LBL0X;
00082
00083 00031 LBL05: " Break Table Y Breaking End Position
00084
00085 00032 ML16138 = ML73818 " Break Table Y Breaking End Position

```

```

00086 00033      IOW MB055764 == 1                " Break Table Y Breaking End Position permission
00087 00034      MOV [BKTY1]ML16138 [BKTY2]ML16138;
00088 00035      IOW MB056004 == 1                " Break Table Y Breaking End Position Check
00089
00090 00036      JOINTO LBL0X;
00091
00092 00037      LBL06: " Break Table Y Carry Out Position
00093
00094 00038      ML16138 = ML73822                    " Break Table Y Carry Out Position
00095 00039      IOW MB055765 == 1                    " Break Table Y Carry Out Position permission
00096 00040      MOV [BKTY1]ML16138 [BKTY2]ML16138;
00097 00041      IOW MB056005 == 1                    " Break Table Y Carry Out Position Check
00098
00099 00042      JOINTO LBL0X;
0100
0101 00043      LBL07: " Break Table Y Escape Position
0102
0103 00044      ML16138 = ML73826                    " Break Table Y Escape Position
0104 00045      IOW MB055766 == 1                    " Break Table Y Escape Position permission
0105 00046      MOV [BKTY1]ML16138 [BKTY2]ML16138;
0106 00047      IOW MB056006 == 1                    " Break Table Y Escape Position Check
0107
0108 00048      JOINTO LBL0X;
0109
0110 00049      LBL08: "
0111 00050      JOINTO LBL0X;
0112
0113 00051      LBL300:
0114 00052      JOINTO LBL0X;
0115 00053      LBL0X: SJOINT;
0116
0117
0118      "*****
0119      "***** Break Table LBL09~16 *****
0120      "*****
0121
0122 00054      SFORK MW00053 == 09 ? LBL09          " [BKTY] Break Table Y Receive Position (Last Dummy)
0123      MW00053 == 10 ? LBL10          "
0124      MW00053 == 11 ? LBL11          "
0125      MW00053 == 12 ? LBL12          " [BKTY] Break Table Y Flatness Measurement Position
0126      MW00053 == 13 ? LBL13          "
0127      MW00053 == 14 ? LBL14          "
0128      MW00053 == 15 ? LBL15          "
0129      MW00053 == 16 ? LBL16          "
0130      DEFAULT ? LBL301;
0131
0132 00055      LBL09: " Break Table Y Receive Position (Last Dummy)
0133
0134 00056      ML16138 = ML73810                    " Break Table Y Receive Position (Last Dummy)
0135 00057      IOW MB055768 == 1                    " Break Table Y Receive Position (Last Dummy) pe
rmission
0136 00058      MOV [BKTY1]ML16138 [BKTY2]ML16138;
0137 00059      IOW MB056008 == 1                    " Break Table Y Receive Position (Last Dummy) Ch
eck
0138
0139 00060      JOINTO LBL1X;
0140
0141 00061      LBL10: "
0142 00062      JOINTO LBL1X;
0143
0144 00063      LBL11: "
0145 00064      JOINTO LBL1X;
0146
0147 00065      LBL12: " Break Table Y Flatness Measurement Position
0148
0149 00066      ML16138 = ML73846                    " Break Table Y Flatness Measurement Position
0150 00067      IOW MB05576B == 1                    " Break Table Y Flatness Measurement Position pe
rmission
0151 00068      MOV [BKTY1]ML16138 [BKTY2]ML16138;
0152 00069      IOW MB05600B == 1                    " Break Table Y Flatness Measurement Position Ch
eck
0153
0154 00070      JOINTO LBL1X;
0155
0156 00071      LBL13: "
0157 00072      JOINTO LBL1X;
0158
0159 00073      LBL14: "
0160 00074      JOINTO LBL1X;
0161
0162 00075      LBL15: "
0163 00076      JOINTO LBL1X;
0164
0165 00077      LBL16: "
0166 00078      JOINTO LBL1X;
0167
0168 00079      LBL301:

```

```

00169 00080      JOINTO LBL1X;
00170 00081      LBL1X: SJOINT;
00171
00172
00173      *****
00174      ***** Break Table LBL17~24 *****
00175      *****
00176
00177 00082      SFORK      MW00053 == 17 ? LBL17      " [BKTZ] Break Table Z Standby Position
00178                  MW00053 == 18 ? LBL18      " [BKTZ] Break Table Z Receive Before Position
00179                  MW00053 == 19 ? LBL19      " [BKTZ] Break Table Z Receive Position
00180                  MW00053 == 20 ? LBL20      " [BKTZ] Break Table Z Breaking Start Position
00181                  MW00053 == 21 ? LBL21      " [BKTZ] Break Table Z Breaking End Position
00182                  MW00053 == 22 ? LBL22      " [BKTZ] Break Table Z Carry Out Position
00183                  MW00053 == 23 ? LBL23      "
00184                  MW00053 == 24 ? LBL24      "
00185                  DEFAULT      ? LBL302;
00186
00187 00083      LBL17: " Break Table Z Standby Position
00188
00189 00084                  ML16144 = ML74402      " Break Table Z Standby Position
00190 00085                  IOW MB055770 == 1      " Break Table Z Standby Position permission
00191 00086                  MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00192 00087                  IOW MB056020 == 1      " Break Table Z Standby Position Check
00193
00194 00088      JOINTO LBL2X;
00195
00196 00089      LBL18: " Break Table Z Receive Before Position
00197
00198 00090                  ML16144 = ML74406      " Break Table Z Receive Before Position
00199 00091                  IOW MB055771 == 1      " Break Table Z Receive Before Position permissi
on
00200 00092      MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00201 00093      IOW MB056021 == 1      " Break Table Z Receive Before Position Check
00202
00203 00094      JOINTO LBL2X;
00204
00205 00095      LBL19: " Break Table Z Receive Position
00206
00207 00096                  ML16144 = ML74410      " Break Table Z Receive Position
00208 00097                  IOW MB055772 == 1      " Break Table Z Receive Position permission
00209 00098                  MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00210 00099                  IOW MB056022 == 1      " Break Table Z Receive Position Check
00211
00212 00100      JOINTO LBL2X;
00213
00214 00101      LBL20: " Break Table Z Breaking Start Position
00215
00216 00102                  ML16144 = ML74414      " Break Table Z Breaking Start Position
00217 00103                  IOW MB055773 == 1      " Break Table Z Breaking Start Position permissi
on
00218 00104      MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00219 00105      IOW MB056023 == 1      " Break Table Z Breaking Start Position Check
00220
00221 00106      JOINTO LBL2X;
00222
00223 00107      LBL21: " Break Table Z Breaking End Position
00224
00225 00108                  ML16144 = ML74418      " Break Table Z Breaking End Position
00226 00109                  IOW MB055774 == 1      " Break Table Z Breaking End Position permission
00227 00110                  MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00228 00111                  IOW MB056024 == 1      " Break Table Z Breaking End Position Check
00229
00230 00112      JOINTO LBL2X;
00231
00232 00113      LBL22: " Break Table Z Carry Out Position
00233
00234 00114                  ML16144 = ML74422      " Break Table Z Carry Out Position
00235 00115                  IOW MB055775 == 1      " Break Table Z Carry Out Position permission
00236 00116                  MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00237 00117                  IOW MB056025 == 1      " Break Table Z Carry Out Position Check
00238
00239 00118      JOINTO LBL2X;
00240
00241 00119      LBL23: "
00242 00120      JOINTO LBL2X;
00243
00244 00121      LBL24: "
00245 00122      JOINTO LBL2X;
00246
00247 00123      LBL302:
00248 00124      JOINTO LBL2X;
00249 00125      LBL2X: SJOINT;
00250
00251
00252      *****
00253      ***** Break Table LBL25~32 *****

```

```

00254          *****
00255
00256 00126   SFORK   MW00053 == 25 ? LBL25   "
00257          MW00053 == 26 ? LBL26   "
00258          MW00053 == 27 ? LBL27   "
00259          MW00053 == 28 ? LBL28   "
00260          MW00053 == 29 ? LBL29   "
00261          MW00053 == 30 ? LBL30   "
00262          MW00053 == 31 ? LBL31   "
00263          MW00053 == 32 ? LBL32   "
00264          DEFAULT ? LBL303;
00265
00266 00127   LBL25: "
00267 00128       JOINTO LBL3X;
00268
00269 00129   LBL26: "
00270 00130       JOINTO LBL3X;
00271
00272 00131   LBL27: "
00273 00132       JOINTO LBL3X;
00274
00275 00133   LBL28: "
00276 00134       JOINTO LBL3X;
00277
00278 00135   LBL29: "
00279 00136       JOINTO LBL3X;
00280
00281 00137   LBL30: "
00282 00138       JOINTO LBL3X;
00283
00284 00139   LBL31: "
00285 00140       JOINTO LBL3X;
00286
00287 00141   LBL32: "
00288 00142       JOINTO LBL3X;
00289
00290 00143   LBL303:
00291 00144       JOINTO LBL3X;
00292 00145   LBL3X: SJOINT;
00293
00294          *****
00295          ***** Break Table LBL33~34 *****
00296          *****
00297
00298
00299 00146   SFORK   MW00053 == 33 ? LBL33   " [BKTT] Break Table T Standby Position
00300          MW00053 == 34 ? LBL34   " [BKTT] Break Table T Breaking Start Position
00301          MW00053 == 35 ? LBL35   " [BKTT] Break Table T Breaking End Position
00302          MW00053 == 36 ? LBL36   "
00303          MW00053 == 37 ? LBL37   "
00304          MW00053 == 38 ? LBL38   "
00305          MW00053 == 39 ? LBL39   "
00306          MW00053 == 40 ? LBL40   "
00307          DEFAULT ? LBL304;
00308
00309 00147   LBL33: " Break Table T Standby Position
00310
00311 00148       ML16150 = ML75002           " Break Table T Standby Position
00312 00149       IOW MB055780 == 1           " Break Table T Standby Position permission
00313 00150       MOV [BKTT1]ML16150 [BKTT2]ML16150;
00314 00151       IOW MB056050 == 1           " Break Table T Standby Position Check
00315
00316 00152       JOINTO LBL4X;
00317
00318 00153   LBL34: " Break Table T Breaking Start Position
00319
00320 00154       ML16150 = ML75014           " Break Table T Breaking Start Position
00321 00155       IOW MB055783 == 1           " Break Table T Breaking Start Position permissi
on
00322 00156       MOV [BKTT1]ML16150 [BKTT2]ML16150;
00323 00157       IOW MB056053 == 1           " Break Table T Breaking Start Position Check
00324
00325 00158       JOINTO LBL4X;
00326
00327 00159   LBL35: " Break Table T Breaking End Position
00328
00329 00160       ML16150 = ML75018           " Break Table T Breaking End Position
00330 00161       IOW MB055784 == 1           " Break Table T Breaking End Position permission
00331 00162       MOV [BKTT1]ML16150 [BKTT2]ML16150;
00332 00163       IOW MB056054 == 1           " Break Table T Breaking End Position Check
00333
00334 00164       JOINTO LBL4X;
00335
00336 00165   LBL36: "
00337 00166       JOINTO LBL4X;
00338
00339 00167   LBL37: "

```

```

00340 00168      JOINTO LBL4X;
00341
00342 00169      LBL38: "
00343 00170      JOINTO LBL4X;
00344
00345 00171      LBL39: "
00346 00172      JOINTO LBL4X;
00347
00348 00173      LBL40: "
00349 00174      JOINTO LBL4X;
00350
00351 00175      LBL304:
00352 00176      JOINTO LBL4X;
00353 00177      LBL4X: SJOINT;
00354
00355
00356      *****
00357      ***** Break Table LBL65~72 *****
00358      *****
00359
00360 00178      SFORK      MW00053 == 65 ? LBL65      " Break Table Waiting Pos
00361      MW00053 == 66 ? LBL66      " Break Table Receive Before Pos
00362      MW00053 == 67 ? LBL67      " Break Table Receive Pos
00363      MW00053 == 68 ? LBL68      " Break Table Start Pos
00364      MW00053 == 69 ? LBL69      " Break Table Execute Pos
00365      MW00053 == 70 ? LBL70      " Break Table Carry Out Pos
00366      MW00053 == 71 ? LBL71      " Break Table Escape Position
00367      MW00053 == 72 ? LBL72      " Break Table Receive Position (Last Dummy)
00368      DEFAULT      ? LBL308;
00369
00370 00179      LBL65: " Break Table Waiting Pos
00371
00372 00180      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00373 00181      MW04522 = 7;      " [ SC Req TBL ] Command Code ID Set
00374 00182      MB045230 = 1;      " [ SC Req TBL ] Command Se
00375 00183      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00376 00184      MB045230 = 0;      " [ SC Req TBL ] Command Se

00377 00185      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00378 00186      MW04522 = 0;      " [ SC Req TBL ] Command Code ID Set
00379
00380 00187      JOINTO LBL8X;
00381
00382 00188      LBL66: " Break Table Receive Before Pos
00383
00384 00189      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00385 00190      MW04522 = 1;      " [ SC Req TBL ] Command Code ID Set
00386 00191      MB045230 = 1;      " [ SC Req TBL ] Command Se
00387 00192      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00388 00193      MB045230 = 0;      " [ SC Req TBL ] Command Se

00389 00194      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00390 00195      MW04522 = 0;      " [ SC Req TBL ] Command Code ID Set
00391
00392 00196      JOINTO LBL8X;
00393
00394 00197      LBL67: " Break Table Receive Pos
00395
00396 00198      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00397 00199      MW04522 = 2;      " [ SC Req TBL ] Command Code ID Set
00398 00200      MB045230 = 1;      " [ SC Req TBL ] Command Se
00399 00201      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00400 00202      MB045230 = 0;      " [ SC Req TBL ] Command Se

00401 00203      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00402 00204      MW04522 = 0;      " [ SC Req TBL ] Command Code ID Set
00403
00404 00205      JOINTO LBL8X;
00405
00406 00206      LBL68: " Break Table Start Pos
00407
00408 00207      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00409 00208      MW04522 = 3;      " [ SC Req TBL ] Command Code ID Set
00410 00209      MB045230 = 1;      " [ SC Req TBL ] Command Se
00411 00210      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00412 00211      MB045230 = 0;      " [ SC Req TBL ] Command Se

00413 00212      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00414 00213      MW04522 = 0;      " [ SC Req TBL ] Command Code ID Set
00415
00416 00214      JOINTO LBL8X;
00417
00418 00215      LBL69: " Break Table Execute Pos
00419
00420 00216      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00421 00217      MW04522 = 4;      " [ SC Req TBL ] Command Code ID Set
00422 00218      MB045230 = 1;      " [ SC Req TBL ] Command Se

```

```

00423 00219      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00424 00220      MB045230 = 0;          " [ SC Req TBL ] Command Se

00425 00221      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00426 00222      MW04522 = 0;          " [ SC Req TBL ] Command Code ID Set
00427
00428 00223      JOINTO LBL8X;
00429
00430 00224      LBL70: " Break Table Carry Out Pos
00431
00432 00225      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00433 00226      MW04522 = 5;          " [ SC Req TBL ] Command Code ID Set
00434 00227      MB045230 = 1;          " [ SC Req TBL ] Command Se
00435 00228      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00436 00229      MB045230 = 0;          " [ SC Req TBL ] Command Se

00437 00230      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00438 00231      MW04522 = 0;          " [ SC Req TBL ] Command Code ID Set
00439
00440 00232      JOINTO LBL8X;
00441
00442 00233      LBL71: " Break Table Escape Position
00443 00234      JOINTO LBL8X;
00444
00445 00235      LBL72: " Break Table Receive Position (Last Dummy)
00446 00236      JOINTO LBL8X;
00447
00448 00237      LBL308:
00449 00238      JOINTO LBL8X;
00450 00239      LBL8X: SJOINT;
00451
00452
00453      *****
00454      ***** Break Table LBL73~80 *****
00455      *****
00456
00457 00240      SFORK  MW00053 == 73 ? LBL73      " Break Table Flatness Measurement Position
00458      MW00053 == 74 ? LBL74      "
00459      MW00053 == 75 ? LBL75      "
00460      MW00053 == 76 ? LBL76      "
00461      MW00053 == 77 ? LBL77      "
00462      MW00053 == 78 ? LBL78      "
00463      MW00053 == 79 ? LBL79      "
00464      MW00053 == 80 ? LBL80      "
00465      DEFAULTI ? LBL309;
00466
00467 00241      LBL73: " Break Table Flatness Measurement Position
00468
00469 00242      IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00470 00243      MW04522 = 7;          " [ SC Req TBL ] Command Code ID Set
00471 00244      MB045230 = 1;          " [ SC Req TBL ] Command Se
00472 00245      IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00473 00246      MB045230 = 0;          " [ SC Req TBL ] Command Se

00474 00247      IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00475 00248      MW04522 = 0;          " [ SC Req TBL ] Command Code ID S

00476
00477 00249      ML16138 = ML73846      " Break Table Y Flatness Measurement Position
00478 00250      IOW MB05576B == 1      " Break Table Y Flatness Measurement Position pe
rmision
00479 00251      MOV [BKTY1]ML16138 [BKTY2]ML16138;
00480 00252      IOW MB05600B == 1      " Break Table Y Flatness Measurement Position Ch
eck

00481
00482
00483 00253      JOINTO LBL9X;
00484
00485 00254      LBL74: "
00486 00255      JOINTO LBL9X;
00487
00488 00256      LBL75: "
00489 00257      JOINTO LBL9X;
00490
00491 00258      LBL76: "
00492 00259      JOINTO LBL9X;
00493
00494 00260      LBL77: "
00495 00261      JOINTO LBL9X;
00496
00497 00262      LBL78: "
00498 00263      JOINTO LBL9X;
00499
00500 00264      LBL79: "
00501 00265      JOINTO LBL9X;
00502
00503 00266      LBL80: "

```

```

00504 00267      JOINTO LBL9X;
00505
00506 00268      LBL309:
00507 00269          JOINTO LBL9X;
00508 00270      LBL9X: SJOINT;
00509
00510
00511      *****
00512      ***** Break Table LBL105~112 *****
00513      *****
00514
00515 00271      SFORK    MW00053 == 105 ? LBL105      "
00516                      MW00053 == 106 ? LBL106      "
00517                      MW00053 == 107 ? LBL107      "
00518                      MW00053 == 108 ? LBL108      "
00519                      MW00053 == 109 ? LBL109      " Break Table Cleaning
00520                      MW00053 == 110 ? LBL110      "
00521                      MW00053 == 111 ? LBL111      "
00522                      MW00053 == 112 ? LBL112      "
00523                      DEFAULT      ? LBL311;
00524
00525 00272      LBL105: "
00526 00273          JOINTO LBL11X;
00527
00528 00274      LBL106: "
00529 00275          JOINTO LBL11X;
00530
00531 00276      LBL107: "
00532 00277          JOINTO LBL11X;
00533
00534 00278      LBL108: "
00535 00279          JOINTO LBL11X;
00536
00537 00280      LBL109: " Break Table Cleaning
00538
00539 00281          IF !MB30036 == 1;
00540 00282              IOW MW04522 == 0      " [ SC Req TBL ] Command Code ID Set
00541 00283              MW04522 = 5;      " [ SC Req TBL ] Command Code ID Set
00542 00284              MB045230 = 1;      " [ SC Req TBL ] Command Se
00543 00285              IOW MB045231 == 1      " [ SC Res TBL ] Command Complete
00544 00286              MB045230 = 0;      " [ SC Req TBL ] Command Se

00545 00287              IOW MB045231 == 0      " [ SC Res TBL ] Command Complete
00546 00288              MW04522 = 0;      " [ SC Req TBL ] Command Code ID Set
00547 00289          IEND;
00548
00549 00290          JOINTO LBL11X;
00550
00551 00291      LBL110: "
00552 00292          JOINTO LBL11X;
00553
00554 00293      LBL111: "
00555 00294          JOINTO LBL11X;
00556
00557 00295      LBL112: "
00558 00296          JOINTO LBL11X;
00559
00560 00297      LBL311:
00561 00298          JOINTO LBL11X;
00562 00299      LBL11X: SJOINT;
00563
00564
00565 00300      MW05920 = MW00053
00566 00301      MB00003E = 1;
00567 00302      END;

```