

```

00001      " Name:ServoParamSetting
00002      " Func:Set the servo axis parameter like this.
00003      "      Change Acceleration Time
00004      "      Change Deceleration Time
00005      "      Change Filter Time Constant
00006      "      Change Filter Type
00007      "      Error count alarm detection
00008      "      SoftLimit+
00009      "      SoftLimit-
00010      " From:MPM010
00011
00012  VAR;
00013 00000      LONG L1_SW = 0, " Line1 Servo Word Registor
00014 00001      LONG L2_SW = 0, " Line2 Servo Word Registor
00015 00002      LONG L3_SW = 0, " Line3 Servo Word Registor
00016 00003      LONG L4_SW = 0, " Line4 Servo Word Registor
00017 00004      LONG L5_SW = 0, " Line5 Servo Word Registor
00018 00005      LONG L6_SW = 0, " Line6 Servo Word Registor
00019 00006      LONG L7_SW = 0, " Line7 Servo Word Registor
00020
00021 00007      LONG L1_SL = 0, " Line1 Servo Long Registor
00022 00008      LONG L2_SL = 0, " Line2 Servo Long Registor
00023 00009      LONG L3_SL = 0, " Line3 Servo Long Registor
00024 00010      LONG L4_SL = 0, " Line4 Servo Long Registor
00025 00011      LONG L5_SL = 0, " Line5 Servo Long Registor
00026 00012      LONG L6_SL = 0, " Line6 Servo Long Registor
00027 00013      LONG L7_SL = 0, " Line7 Servo Long Registor
00028
00029 00014      LONG L1_SB = 0, " Line1 Servo Bit Registor
00030 00015      LONG L2_SB = 0, " Line2 Servo Bit Registor
00031 00016      LONG L3_SB = 0, " Line3 Servo Bit Registor
00032 00017      LONG L4_SB = 0, " Line4 Servo Bit Registor
00033 00018      LONG L5_SB = 0, " Line5 Servo Bit Registor
00034 00019      LONG L6_SB = 0, " Line6 Servo Bit Registor
00035 00020      LONG L7_SB = 0, " Line7 Servo Bit Registor
00036
00037 00021      LONG L1_PW = 0, " Line1 Axis Parameter Word Offset
00038 00022      LONG L2_PW = 0, " Line2 Axis Parameter Word Offset
00039 00023      LONG L3_PW = 0, " Line3 Axis Parameter Word Offset
00040 00024      LONG L4_PW = 0, " Line4 Axis Parameter Word Offset
00041 00025      LONG L5_PW = 0, " Line5 Axis Parameter Word Offset
00042 00026      LONG L6_PW = 0, " Line6 Axis Parameter Word Offset
00043 00027      LONG L7_PW = 0, " Line7 Axis Parameter Word Offset
00044
00045 00028      LONG L1_PL = 0, " Line1 Axis Parameter Long Offset
00046 00029      LONG L2_PL = 0, " Line2 Axis Parameter Long Offset
00047 00030      LONG L3_PL = 0, " Line3 Axis Parameter Long Offset
00048 00031      LONG L4_PL = 0, " Line4 Axis Parameter Long Offset
00049 00032      LONG L5_PL = 0, " Line5 Axis Parameter Long Offset
00050 00033      LONG L6_PL = 0, " Line6 Axis Parameter Long Offset
00051 00034      LONG L7_PL = 0, " Line7 Axis Parameter Long Offset
00052
00053 00035      LONG L1_ML = 0, " Line1 Axis Internal Data(2word)
00054 00036      LONG L2_ML = 0, " Line2 Axis Internal Data(2word)
00055 00037      LONG L3_ML = 0, " Line3 Axis Internal Data(2word)
00056 00038      LONG L4_ML = 0, " Line4 Axis Internal Data(2word)
00057 00039      LONG L5_ML = 0, " Line5 Axis Internal Data(2word)
00058 00040      LONG L6_ML = 0, " Line6 Axis Internal Data(2word)
00059 00041      LONG L7_ML = 0, " Line7 Axis Internal Data(2word)
00060  END_VAR;
00061
00062  MPS110; " CALLER : MPM001 MC Command
00063      " Set all lines' Acc/Dcc at same time"
00064      " ACC Setting
00065 00042      MB000120 = 0; " Param1 Executing
00066
00067 00043      PFORK Line1 Line2 Line3 Line4 Line5 Line6 Line7 Line8;
00068      Line1: "CirCuit No1
00069      DW00008 = 0;
00070 00045      WHILE DW00008 < 16 " Loop counter
00071 00046          IF MB100000[DW00008] == ON;
00072 00047              L1_SW = DW00008 * 128 " Servo setting parameter Index
00073 00048              L1_SL = DW00008 * 128 / 2;
00074 00049              L1_PW = DW00008 * 100 " Parameter Index
00075 00050              L1_PL = DW00008 * 100 / 2 " Parameter Index
00076 00051              L1_SB = DW00008 * 128 * 16 " Servo setting parameter BitIndex
00077 00052              L1_ML = DW00008;
00078
00079 00053              DL00000 = ML40094[L1_PL];
00080 00054              DL00002 = ML40098[L1_PL];
00081 00055              IF DL00000 == 0;
00082 00056                  DL00000 = 2147483647;
00083 00057              IEND;
00084 00058              IF DL00002 == 0;
00085 00059                  DL00002 = -2147483648;
00086 00060              IEND;
00087

```

```

00088 00061      DL00004 = ML40004[L1_PL];
00089 00062      DL00006 = ML40006[L1_PL];
00090 00063      IF DL00004 < 1000;
00091 00064          DL00004 = 1000;
00092 00065      IEND;
00093 00066      IF DL00006 < 1000;
00094 00067          DL00006 = 1000;
00095 00068      IEND;
00096
00097 00069      OW8003[L1_SW] = 0200H;          " Function Setting 1
00098 00070      OW803A[L1_SW] = MW40016[L1_PW];  " Filter time constant setting
00099 00071      OL8022[L1_SL] = ML40014[L1_PL];  " Error count alarm detection
00100 00072      OL8066[L1_SL] = DL00000;      " SoftLimit+
00101 00073      OL8068[L1_SL] = DL00002;        " SoftLimit-
00102 00074      OL8036[L1_SL] = DL00004;        " Acc setting
00103 00075      OL8038[L1_SL] = DL00006;        " Dcc setting
00104
00105      " ACC Setting
00106 00076      OW8008[L1_SW] = 10;          " Change Acceleration Time
00107 00077      IOW IW8008[L1_SW] == 10;
00108 00078      IOW IB80098[L1_SB] == 1;
00109 00079      OW8008[L1_SW] = 0
00110 00080      IOW IW8008[L1_SW] == 0      " Servo Command Clear
00111      " DCC Setting                  " Servo Command Clear Confirm
00112 00081      OW8008[L1_SW] = 11;          " Change Deceleration Time
00113 00082      IOW IW8008[L1_SW] == 11;
00114 00083      IOW IB80098[L1_SB] == 1;
00115 00084      OW8008[L1_SW] = 0
00116 00085      IOW IW8008[L1_SW] == 0      " Servo Command Clear
00117      " Change Filter Time Constant  " Servo Command Clear Confir
00118 00086      OW8008[L1_SW] = 12;          " Change Filter Time Constant
00119 00087      IOW IW8008[L1_SW] == 12;
00120 00088      IOW IB80098[L1_SB] == 1;
00121 00089      OW8008[L1_SW] = 0
00122 00090      IOW IW8008[L1_SW] == 0      " Servo Command Clear
00123      " Change Filter Type          " Servo Command Clear Confirm
00124 00091      OW8008[L1_SW] = 13;          " Change Filter Type
00125 00092      IOW IW8008[L1_SW] == 13;
00126 00093      IOW IB80098[L1_SB] == 1;
00127
00128      " Nop
00129 00094      OW8008[L1_SW] = 0
00130 00095      IOW IW8008[L1_SW] == 0      " Servo Command Clear
00131      " Servo Command Clear Confirm
00132 00096      L1_PW = DW00008 * 10      " Parameter Index
00133      " Travel distance per machine rotation
00134 00097      OW805C[L1_SW] = 6
00135 00098      OW800A[L1_SW] = 5
00136 00099      IOW IW800A[L1_SW] == 5;      " Travel distance per machine rotation
00137 00100      IOW IB800B8[L1_SB] == 1;    " Read fixed parameter
00138 00101      ML10400[L1_ML] = IL8056[L1_SL];
00139      " Nop
00140 00102      OW800A[L1_SW] = 0
00141 00103      IOW IW800A[L1_SW] == 0      " Servo SubCommand Clear
00142      " Servo SubCommand Clear Confirm
00143
00144 00104      " Rated motor speed
00145 00105      OW805C[L1_SW] = 34
00146 00106      OW800A[L1_SW] = 5
00147 00107      IOW IW800A[L1_SW] == 5;      " Rated motor speed
00148 00108      IOW IB800B8[L1_SB] == 1;    " Read fixed parameter
00149      ML10600[L1_ML] = IL8056[L1_SL];
00150      " Nop
00151 00109      OW800A[L1_SW] = 0
00152 00110      IOW IW800A[L1_SW] == 0      " Servo SubCommand Clear
00153      " Servo SubCommand Clear Confirm
00154 00111      " Servo motor gear ratio
00155 00112      OW805C[L1_SW] = 8
00156 00113      OW800A[L1_SW] = 5
00157 00114      IOW IW800A[L1_SW] == 5;      " Rated motor speed
00158 00115      IOW IB800B8[L1_SB] == 1;    " Read fixed parameter
00159      ML11400[L1_ML] = IL8056[L1_SL];
00160      " Nop
00161 00116      OW800A[L1_SW] = 0
00162 00117      IOW IW800A[L1_SW] == 0      " Servo SubCommand Clear
00163      " Servo SubCommand Clear Confirm
00164 00118      " Machine gear ratio
00165 00119      OW805C[L1_SW] = 9
00166 00120      OW800A[L1_SW] = 5
00167 00121      IOW IW800A[L1_SW] == 5;      " Rated motor speed
00168 00122      IOW IB800B8[L1_SB] == 1;    " Read fixed parameter
00169      ML11600[L1_ML] = IL8056[L1_SL];
00170      " Nop
00171 00123      OW800A[L1_SW] = 0
00172 00124      IOW IW800A[L1_SW] == 0      " Servo SubCommand Clear
00173      " Servo SubCommand Clear Confirm
00174 00125      OL8020[L1_SL] = 0
00174 00126      IEND;                    " NEAR signal output width

```

```

00175 00127          DW00008 = DW00008 + 1          " Loop counter
00176 00128          EOX;
00177 00129      WEND;
00178 00130      JOINTO LabelX;
00179
00180      Line2: "CirCuit No2
00181 00131          DW00018 = 0;
00182 00132      WHILE DW00018 < 16          " Loop counter
00183 00133          IF MB100010[DW00018] == ON;
00184 00134              L2_SW = DW00018 * 128          " Servo setting parameter Index
00185 00135              L2_SL = DW00018 * 128 / 2        " Servo setting parameter Index
00186 00136              L2_PW = DW00018 * 100            " Parameter Index
00187 00137              L2_PL = DW00018 * 100 / 2        " Parameter Index
00188 00138              L2_SB = DW00018 * 128 * 16       " Servo setting parameter BitIndex
00189 00139              L2_ML = DW00018 + (16 * 1);
00190
00191 00140              DL00010 = ML41694[L2_PL];
00192 00141              DL00012 = ML41698[L2_PL];
00193 00142              IF DL00010 == 0;
00194 00143                  DL00010 = 2147483647;
00195 00144              IEND;
00196 00145              IF DL00012 == 0;
00197 00146                  DL00012 = -2147483648;
00198 00147              IEND;
00199
00200 00148              DL00014 = ML41604[L2_PL];
00201 00149              DL00016 = ML41606[L2_PL];
00202 00150              IF DL00014 < 1000;
00203 00151                  DL00014 = 1000;
00204 00152              IEND;
00205 00153              IF DL00016 < 1000;
00206 00154                  DL00016 = 1000;
00207 00155              IEND;
00208
00209 00156          OW8803[L2_SW] = 0200H;          " Function setting 1
00210 00157          OW883A[L2_SW] = MW41616[L2_PW];    " Filter time constant setting
00211 00158          OL8822[L2_SL] = ML41614[L2_PL];    " Error count alarm detection
00212 00159          OL8866[L2_SL] = DL00010;          " SoftLimit+
00213 00160          OL8868[L2_SL] = DL00012;          " SoftLimit-
00214 00161          OL8836[L2_SL] = DL00014;          " Acc setting
00215 00162          OL8838[L2_SL] = DL00016;          " Dcc setting
00216
00217          " ACC Setting
00218 00163          OW8808[L2_SW] = 10;          " Change Acceleration Time
00219 00164          IOW IW8808[L2_SW] == 10;
00220 00165          IOW IB88098[L2_SB] == 1;
00221 00166          OW8808[L2_SW] = 0          " Servo Command Clear
00222 00167          IOW IW8808[L2_SW] == 0          " Servo Command Clear Confirm
00223          " DCC Setting
00224 00168          OW8808[L2_SW] = 11;          " Change Deceleration Time
00225 00169          IOW IW8808[L2_SW] == 11;
00226 00170          IOW IB88098[L2_SB] == 1;
00227 00171          OW8808[L2_SW] = 0          " Servo Command Clear
00228 00172          IOW IW8808[L2_SW] == 0          " Servo Command Clear Confir
00229          " Change Filter Time Constant
00230 00173          OW8808[L2_SW] = 12;          " Change Filter Time Constant
00231 00174          IOW IW8808[L2_SW] == 12;
00232 00175          IOW IB88098[L2_SB] == 1;
00233 00176          OW8808[L2_SW] = 0          " Servo Command Clear
00234 00177          IOW IW8808[L2_SW] == 0          " Servo Command Clear Confirm
00235          " Change Filter Type
00236 00178          OW8808[L2_SW] = 13;          " Change Filter Type
00237 00179          IOW IW8808[L2_SW] == 13;
00238 00180          IOW IB88098[L2_SB] == 1;
00239 00181          OW8808[L2_SW] = 0          " Servo Command Clear
00240 00182          IOW IW8808[L2_SW] == 0          " Servo Command Clear Confirm
00241
00242 00183          L2_PW = DW00018 * 10          " Parameter Index
00243          " Travel distance per machine rotation
00244 00184          OW885C[L2_SW] = 6          " Travel distance per machine rotation
00245 00185          OW880A[L2_SW] = 5          " Read fixed parameter
00246 00186          IOW IW880A[L2_SW] == 5;
00247 00187          IOW IB880B8[L2_SB] == 1;
00248 00188          ML10400[L2_ML] = IL8856[L2_SL];
00249 00189          OW880A[L2_SW] = 0          " Servo SubCommand Clear
00250 00190          IOW IW880A[L2_SW] == 0          " Servo SubCommand Clear Confirm
00251
00252          " Rated motor speed
00253 00191          OW885C[L2_SW] = 34          " Rated motor speed
00254 00192          OW880A[L2_SW] = 5          " Read fixed parameter
00255 00193          IOW IW880A[L2_SW] == 5;
00256 00194          IOW IB880B8[L2_SB] == 1;
00257 00195          ML10600[L2_ML] = IL8856[L2_SL];
00258 00196          OW880A[L2_SW] = 0          " Servo SubCommand Clear
00259 00197          IOW IW880A[L2_SW] == 0          " Servo SubCommand Clear Confirm
00260
00261          " Servo motor gear ratio

```

```

00262 00198          OW885C[L2_SW] = 8          " Rated motor speed
00263 00199          OW880A[L2_SW] = 5          " Read fixed parameter
00264 00200          IOW IW880A[L2_SW] == 5;
00265 00201          IOW IB880B8[L2_SB] == 1;
00266 00202          ML11400[L2_ML] = IL8856[L2_SL];
00267 00203          OW880A[L2_SW] = 0          " Servo SubCommand Clear
00268 00204          IOW IW880A[L2_SW] == 0      " Servo SubCommand Clear Confirm
00269
00270          " Machine gear ratio
00271 00205          OW885C[L2_SW] = 9          " Rated motor speed
00272 00206          OW880A[L2_SW] = 5          " Read fixed parameter
00273 00207          IOW IW880A[L2_SW] == 5;
00274 00208          IOW IB880B8[L2_SB] == 1;
00275 00209          ML11600[L2_ML] = IL8856[L2_SL];
00276 00210          OW880A[L2_SW] = 0          " Servo SubCommand Clear
00277 00211          IOW IW880A[L2_SW] == 0      " Servo SubCommand Clear Confirm
00278
00279 00212          OL8820[L2_SL] = 0          " NEAR signal output width
00280 00213          IEND;
00281 00214          DW00018 = DW00018 + 1          " Loop counter
00282 00215          EOX;
00283 00216          WEND;
00284 00217          JOINTO LabelX;
00285
00286          Line3: "CirCuit No3
00287 00218          OW903A = 0;
00288 00219          OW90BA = 0;
00289 00220          OW913A = 0;
00290 00221          OW91BA = 0;
00291 00222          OW923A = 0;
00292 00223          OW92BA = 0;
00293 00224          OW933A = 0;
00294 00225          OW93BA = 0;
00295 00226          OW943A = 0;
00296 00227          OW94BA = 0;
00297 00228          OW953A = 0;
00298 00229          OW95BA = 0;
00299 00230          OW963A = 0;
00300 00231          OW96BA = 0;
00301 00232          OW973A = 0;
00302 00233          OW97BA = 0;
00303 00234          OW983A = 0;
00304 00235          OW9003 = 0200H;
00305 00236          OW9083 = 0200H;
00306 00237          OW9103 = 0200H;
00307 00238          OW9183 = 0200H;
00308 00239          OW9203 = 0200H;
00309 00240          OW9283 = 0200H;
00310 00241          OW9303 = 0200H;
00311 00242          OW9383 = 0200H;
00312 00243          OW9403 = 0200H;
00313 00244          OW9483 = 0200H;
00314 00245          OW9503 = 0200H;
00315 00246          OW9583 = 0200H;
00316 00247          OW9603 = 0200H;
00317 00248          OW9683 = 0200H;
00318 00249          OW9703 = 0200H;
00319 00250          OW9783 = 0200H;
00320 00251          OW9803 = 0200H;
00321          " Change Filter Type
00322 00252          OW9008 = 13;          " Change Filter Type
00323 00253          OW9088 = 13;          " Change Filter Type
00324 00254          OW9108 = 13;          " Change Filter Type
00325 00255          OW9188 = 13;          " Change Filter Type
00326 00256          OW9208 = 13;          " Change Filter Type
00327 00257          OW9288 = 13;          " Change Filter Type
00328 00258          OW9308 = 13;          " Change Filter Type
00329 00259          OW9388 = 13;          " Change Filter Type
00330 00260          OW9408 = 13;          " Change Filter Type
00331 00261          OW9488 = 13;          " Change Filter Type
00332 00262          OW9508 = 13;          " Change Filter Type
00333 00263          OW9588 = 13;          " Change Filter Type
00334 00264          OW9608 = 13;          " Change Filter Type
00335 00265          OW9688 = 13;          " Change Filter Type
00336 00266          OW9708 = 13;          " Change Filter Type
00337 00267          OW9788 = 13;          " Change Filter Type
00338 00268          OW9808 = 13;          " Change Filter Type
00339 00269          IOW IW9008 == 13;
00340 00270          IOW IW9088 == 13;
00341 00271          IOW IW9108 == 13;
00342 00272          IOW IW9188 == 13;
00343 00273          IOW IW9208 == 13;
00344 00274          IOW IW9288 == 13;
00345 00275          IOW IW9308 == 13;
00346 00276          IOW IW9388 == 13;
00347 00277          IOW IW9408 == 13;
00348 00278          IOW IW9488 == 13;

```

```

00349 00279      IOW IW9508 == 13;
00350 00280      IOW IW9588 == 13;
00351 00281      IOW IW9608 == 13;
00352 00282      IOW IW9688 == 13;
00353 00283      IOW IW9708 == 13;
00354 00284      IOW IW9788 == 13;
00355 00285      IOW IW9808 == 13;
00356 00286      IOW IB90098 == 1;
00357 00287      IOW IB90898 == 1;
00358 00288      IOW IB91098 == 1;
00359 00289      IOW IB91898 == 1;
00360 00290      IOW IB92098 == 1;
00361 00291      IOW IB92898 == 1;
00362 00292      IOW IB93098 == 1;
00363 00293      IOW IB93898 == 1;
00364 00294      IOW IB94098 == 1;
00365 00295      IOW IB94898 == 1;
00366 00296      IOW IB95098 == 1;
00367 00297      IOW IB95898 == 1;
00368 00298      IOW IB96098 == 1;
00369 00299      IOW IB96898 == 1;
00370 00300      IOW IB97098 == 1;
00371 00301      IOW IB97898 == 1;
00372 00302      IOW IB98098 == 1;
00373 00303      OW9008 = 0;
00374 00304      OW9088 = 0;
00375 00305      OW9108 = 0;
00376 00306      OW9188 = 0;
00377 00307      OW9208 = 0;
00378 00308      OW9288 = 0;
00379 00309      OW9308 = 0;
00380 00310      OW9388 = 0;
00381 00311      OW9408 = 0;
00382 00312      OW9488 = 0;
00383 00313      OW9508 = 0;
00384 00314      OW9588 = 0;
00385 00315      OW9608 = 0;
00386 00316      OW9688 = 0;
00387 00317      OW9708 = 0;
00388 00318      OW9788 = 0;
00389 00319      OW9808 = 0;
00390 00320      IOW IW9008 == 0;
00391 00321      IOW IW9088 == 0;
00392 00322      IOW IW9108 == 0;
00393 00323      IOW IW9188 == 0;
00394 00324      IOW IW9208 == 0;
00395 00325      IOW IW9288 == 0;
00396 00326      IOW IW9308 == 0;
00397 00327      IOW IW9388 == 0;
00398 00328      IOW IW9408 == 0;
00399 00329      IOW IW9488 == 0;
00400 00330      IOW IW9508 == 0;
00401 00331      IOW IW9588 == 0;
00402 00332      IOW IW9608 == 0;
00403 00333      IOW IW9688 == 0;
00404 00334      IOW IW9708 == 0;
00405 00335      IOW IW9788 == 0;
00406 00336      IOW IW9808 == 0;
00407
00408 00337      JOINTO LabelX;
00409
00410      Line4: "CirCuit No5
00411 00338          DW00028 = 0;
00412 00339          WHILE DW00028 < 16
00413 00340              IF MB100020[DW00028] == ON;
00414 00341                  L3_SW = DW00028 * 128
00415 00342                  L3_SL = DW00028 * 128 / 2
00416 00343                  L3_PW = DW00028 * 100
00417 00344                  L3_PL = DW00028 * 100 / 2
00418 00345                  L3_SB = DW00028 * 128 * 16
00419 00346                  L3_ML = DW00028 + (16 * 2);
00420
00421 00347                  DL00020 = ML43294[L3_PL];
00422 00348                  DL00022 = ML43298[L3_PL];
00423 00349                  IF DL00020 == 0;
00424 00350                      DL00020 = 2147483647;
00425 00351                  IEND;
00426 00352                  IF DL00022 == 0;
00427 00353                      DL00022 = -2147483648;
00428 00354                  IEND;
00429
00430 00355                  DL00024 = ML43204[L3_PL];
00431 00356                  DL00026 = ML43206[L3_PL];
00432 00357                  IF DL00024 < 1000;
00433 00358                      DL00024 = 1000;
00434 00359                  IEND;
00435 00360                  IF DL00026 < 1000;

```

```

00436 00361          DL00026 = 1000;
00437 00362      IEND;
00438
00439 00363      OWA003[L3_SW] = 0200H;          " Function setting 1
00440 00364      OWA03A[L3_SW] = MW43216[L3_PW]; " Filter time constant setting
00441 00365      OLA022[L3_SL] = ML43214[L3_PL]; " Error count alarm detection
00442 00366      OLA036[L3_SL] = DL00024;        " Acc setting
00443 00367      OLA038[L3_SL] = DL00026;        " Dcc setting
00444
00445      " ACC Setting
00446 00368      OWA008[L3_SW] = 10;          " Change Acceleration Time
00447 00369      IOW IWA008[L3_SW] == 10;
00448 00370      IOW IBA0098[L3_SB] == 1;
00449
00450      " DCC Setting
00451 00371      OWA008[L3_SW] = 11;          " Change Deceleration Time
00452 00372      IOW IWA008[L3_SW] == 11;
00453 00373      IOW IBA0098[L3_SB] == 1;
00454      " Change Filter Time Constant
00455 00374      OWA008[L3_SW] = 12;          " Change Filter Time Constant
00456 00375      IOW IWA008[L3_SW] == 12;
00457 00376      IOW IBA0098[L3_SB] == 1;
00458
00459      " Change Filter Type
00460 00377      OWA008[L3_SW] = 13;          " Change Filter Type
00461 00378      IOW IWA008[L3_SW] == 13;
00462 00379      IOW IBA0098[L3_SB] == 1;
00463
00464      " Nop
00465 00380      OWA008[L3_SW] = 0          " Servo Command Clear
00466 00381      IOW IWA008[L3_SW] == 0      " Servo Command Clear Confirm
00467
00468      " SoftLimit+
00469 00382      OWA054[L3_SW] = 12          " Servo driver for assistance user constant No
00470 00383      OWA055[L3_SW] = 1              " Servo driver for assistance user constant Size
00471 00384      OLA056[L3_SL] = DL00020      " Servo driver for assistance user constant set
point
00472 00385      OWA00A[L3_SW] = 6;          " Write fixed parameter
00473 00386      IOW IWA00A[L3_SW] == 6;
00474 00387      IOW IBA00B8[L3_SB] == 1;
00475 00388      OWA00A[L3_SW] = 0          " Servo SubCommand Clear
00476 00389      IOW IWA00A[L3_SW] == 0      " Servo SubCommand Clear Confirm
00477
00478      " SoftLimit-
00479 00390      OWA054[L3_SW] = 14          " Servo driver for assistance user constant No
00480 00391      OWA055[L3_SW] = 1              " Servo driver for assistance user constant Size
00481 00392      OLA056[L3_SL] = DL00022      " Servo driver for assistance user constant set
point
00482 00393      OWA00A[L3_SW] = 6;          " Write fixed parameter
00483 00394      IOW IWA00A[L3_SW] == 6;
00484 00395      IOW IBA00B8[L3_SB] == 1;
00485 00396      OWA00A[L3_SW] = 0          " Servo SubCommand Clear
00486 00397      IOW IWA00A[L3_SW] == 0      " Servo SubCommand Clear Confirm
00487
00488 00398      L3_PW = DW00028 * 2          " Parameter Index
00489      " Travel distance per machine rotation
00490 00399      OWA05C[L3_SW] = 6          " Travel distance per machine rotation
00491 00400      OWA00A[L3_SW] = 5          " Read fixed parameter
00492 00401      IOW IWA00A[L3_SW] == 5;
00493 00402      IOW IBA00B8[L3_SB] == 1;
00494 00403      ML10400[L3_ML] = ILA056[L3_SL];
00495 00404      OWA00A[L3_SW] = 0          " Servo SubCommand Clear
00496 00405      IOW IWA00A[L3_SW] == 0      " Servo SubCommand Clear Confirm
00497
00498      " Rated motor speed
00499 00406      OWA05C[L3_SW] = 34          " Rated motor speed
00500 00407      OWA00A[L3_SW] = 5          " Read fixed parameter
00501 00408      IOW IWA00A[L3_SW] == 5;
00502 00409      IOW IBA00B8[L3_SB] == 1;
00503 00410      ML10600[L3_ML] = ILA056[L3_SL];
00504 00411      OWA00A[L3_SW] = 0          " Servo SubCommand Clear
00505 00412      IOW IWA00A[L3_SW] == 0      " Servo SubCommand Clear Confirm
00506
00507      " Servo motor gear ratio
00508 00413      OWA05C[L3_SW] = 8          " Rated motor speed
00509 00414      OWA00A[L3_SW] = 5          " Read fixed parameter
00510 00415      IOW IWA00A[L3_SW] == 5;
00511 00416      IOW IBA00B8[L3_SB] == 1;
00512 00417      ML11400[L3_ML] = ILA056[L3_SL];
00513 00418      OWA00A[L3_SW] = 0          " Servo SubCommand Clear
00514 00419      IOW IWA00A[L3_SW] == 0      " Servo SubCommand Clear Confirm
00515
00516      " Machine gear ratio
00517 00420      OWA05C[L3_SW] = 9          " Rated motor speed
00518 00421      OWA00A[L3_SW] = 5          " Read fixed parameter
00519 00422      IOW IWA00A[L3_SW] == 5;
00520 00423      IOW IBA00B8[L3_SB] == 1;

```

```

00521 00424          ML11600[L3_ML] = ILA056[L3_SL];
00522 00425          OWA00A[L3_SW] = 0          " Servo SubCommand Clear
00523 00426          IOW IWA00A[L3_SW] == 0      " Servo SubCommand Clear Confirm
00524
00525 00427          OLA020[L3_SL] = 0          " NEAR signal output width
00526 00428      IEND;
00527 00429      DW00028 = DW00028 + 1          " Loop counter
00528 00430      EOX;
00529 00431      WEND;
00530 00432      JOINTO LabelX;
00531
00532      Line5: "CirCuit No6
00533 00433      DW00038 = 0;
00534 00434      WHILE DW00038 < 16          " Loop counter
00535 00435          IF MB100030[DW00038] == ON;
00536 00436              L4_SW = DW00038 * 128          " Servo setting parameter Index
00537 00437              L4_SL = DW00038 * 128 / 2      " Servo setting parameter Index
00538 00438              L4_PW = DW00038 * 100          " Parameter Index
00539 00439              L4_PL = DW00038 * 100 / 2      " Parameter Index
00540 00440              L4_SB = DW00038 * 128 * 16      " Servo setting parameter BitIndex
00541 00441              L4_ML = DW00038 + (16 * 3);
00542
00543 00442          DL00030 = ML44894[L4_PL];
00544 00443          DL00032 = ML44898[L4_PL];
00545 00444          IF DL00030 == 0;
00546 00445              DL00030 = 2147483647;
00547 00446          IEND;
00548 00447          IF DL00032 == 0;
00549 00448              DL00032 = -2147483648;
00550 00449          IEND;
00551
00552 00450          DL00034 = ML44804[L4_PL];
00553 00451          DL00036 = ML44806[L4_PL];
00554 00452          IF DL00034 < 1000;
00555 00453              DL00034 = 1000;
00556 00454          IEND;
00557 00455          IF DL00036 < 1000;
00558 00456              DL00036 = 1000;
00559 00457          IEND;
00560
00561 00458          OWA803[L4_SW] = 0200H;          " Function setting 1
00562 00459          OWA83A[L4_SW] = MW44816[L4_PW];  " Filter time constant setting
00563 00460          OLA822[L4_SL] = ML44814[L4_PL];    " Error count alarm detection
00564 00461          OLA836[L4_SL] = DL00034;        " Acc setting
00565 00462          OLA838[L4_SL] = DL00036;          " Dcc setting
00566
00567          " ACC Setting
00568 00463          OWA808[L4_SW] = 10;          " Change Acceleration Time
00569 00464          IOW IWA808[L4_SW] == 10;
00570 00465          IOW IBA8098[L4_SB] == 1;
00571 00466          OWA808[L4_SW] = 0          " Servo Command Clear
00572 00467          IOW IWA808[L4_SW] == 0      " Servo Command Clear Confirm
00573
00574          " DCC Setting
00575 00468          OWA808[L4_SW] = 11;          " Change Deceleration Time
00576 00469          IOW IWA808[L4_SW] == 11;
00577 00470          IOW IBA8098[L4_SB] == 1;
00578 00471          OWA808[L4_SW] = 0          " Servo Command Clear
00579 00472          IOW IWA808[L4_SW] == 0      " Servo Command Clear Confirm
00580
00581          " Change Filter Time Constant
00582 00473          OWA808[L4_SW] = 12;          " Change Filter Time Constant
00583 00474          IOW IWA808[L4_SW] == 12;
00584 00475          IOW IBA8098[L4_SB] == 1;
00585 00476          OWA808[L4_SW] = 0          " Servo Command Clear
00586 00477          IOW IWA808[L4_SW] == 0      " Servo Command Clear Confirm
00587
00588          " Change Filter Type
00589 00478          OWA808[L4_SW] = 13;          " Change Filter Type
00590 00479          IOW IWA808[L4_SW] == 13;
00591 00480          IOW IBA8098[L4_SB] == 1;
00592 00481          OWA808[L4_SW] = 0          " Servo Command Clear
00593 00482          IOW IWA808[L4_SW] == 0      " Servo Command Clear Confirm
00594
00595          " SoftLimit+
00596 00483          OWA854[L4_SW] = 12          " Servo driver for assistance user constant No
00597 00484          OWA855[L4_SW] = 1          " Servo driver for assistance user constant Size
00598 00485          OLA856[L4_SL] = DL00030      " Servo driver for assistance user constant set
00599
00599 00486      point
00600 00487          OWA80A[L4_SW] = 6;          " Write fixed parameter
00601 00488          IOW IWA80A[L4_SW] == 6;
00602 00489          IOW IBA80B8[L4_SB] == 1;
00603 00490          OWA80A[L4_SW] = 0          " Servo SubCommand Clear
00604          IOW IWA80A[L4_SW] == 0      " Servo SubCommand Clear Confirm
00605
00606 00491          " SoftLimit-
00606 00491          OWA854[L4_SW] = 14          " Servo driver for assistance user constant No

```

```

00607 00492          OWA855[L4_SW] = 1          " Servo driver for assistance user constant Size
00608 00493          OLA856[L4_SL] = DL00032      " Servo driver for assistance user constant set

point

00609 00494          OWA80A[L4_SW] = 6;          " Write fixed parameter
00610 00495          IOW IWA80A[L4_SW] == 6;
00611 00496          IOW IBA80B8[L4_SB] == 1;
00612 00497          OWA80A[L4_SW] = 0          " Servo SubCommand Clear
00613 00498          IOW IWA80A[L4_SW] == 0      " Servo SubCommand Clear Confirm
00614
00615 00499          L4_PW = DW00038 * 2          " Parameter Index
00616          " Travel distance per machine rotation
00617 00500          OWA85C[L4_SW] = 6          " Travel distance per machine rotation
00618 00501          OWA80A[L4_SW] = 5          " Read fixed parameter
00619 00502          IOW IWA80A[L4_SW] == 5;
00620 00503          IOW IBA80B8[L4_SB] == 1;
00621 00504          ML10400[L4_ML] = ILA856[L4_SL];
00622 00505          OWA80A[L4_SW] = 0          " Servo SubCommand Clear
00623 00506          IOW IWA80A[L4_SW] == 0      " Servo SubCommand Clear Confirm
00624
00625          " Rated motor speed
00626 00507          OWA85C[L4_SW] = 34          " Rated motor speed
00627 00508          OWA80A[L4_SW] = 5          " Read fixed parameter
00628 00509          IOW IWA80A[L4_SW] == 5;
00629 00510          IOW IBA80B8[L4_SB] == 1;
00630 00511          ML10600[L4_ML] = ILA856[L4_SL];
00631 00512          OWA80A[L4_SW] = 0          " Servo SubCommand Clear
00632 00513          IOW IWA80A[L4_SW] == 0      " Servo SubCommand Clear Confirm
00633
00634          " Servo motor gear ratio
00635 00514          OWA85C[L4_SW] = 8          " Rated motor speed
00636 00515          OWA80A[L4_SW] = 5          " Read fixed parameter
00637 00516          IOW IWA80A[L4_SW] == 5;
00638 00517          IOW IBA80B8[L4_SB] == 1;
00639 00518          ML11400[L4_ML] = ILA856[L4_SL];
00640 00519          OWA80A[L4_SW] = 0          " Servo SubCommand Clear
00641 00520          IOW IWA80A[L4_SW] == 0      " Servo SubCommand Clear Confirm
00642
00643          " Machine gear ratio
00644 00521          OWA85C[L4_SW] = 9          " Rated motor speed
00645 00522          OWA80A[L4_SW] = 5          " Read fixed parameter
00646 00523          IOW IWA80A[L4_SW] == 5;
00647 00524          IOW IBA80B8[L4_SB] == 1;
00648 00525          ML11600[L4_ML] = ILA856[L4_SL];
00649 00526          OWA80A[L4_SW] = 0          " Servo SubCommand Clear
00650 00527          IOW IWA80A[L4_SW] == 0      " Servo SubCommand Clear Confirm
00651
00652 00528          OLA820[L4_SL] = 0          " NEAR signal output width
00653 00529          IEND;
00654 00530          DW00038 = DW00038 + 1      " Loop counte:
00655 00531          EOx;
00656 00532          WEND;
00657 00533          JOINTO LabelX;
00658
00659          Line6: "CirCuit No7
00660 00534          DW00048 = 0;
00661 00535          WHILE DW00048 < 16          " Loop counter
00662 00536              IF MB100040[DW00048] == ON;
00663 00537                  L5_SW = DW00048 * 128      " Servo setting parameter Index
00664 00538                  L5_SL = DW00048 * 128 / 2    " Servo setting parameter Index
00665 00539                  L5_PW = DW00048 * 100        " Parameter Index
00666 00540                  L5_PL = DW00048 * 100 / 2    " Parameter Index
00667 00541                  L5_SB = DW00048 * 128 * 16  " Servo setting parameter BitIndex
00668 00542                  L5_ML = DW00048 + (16 * 4);
00669
00670 00543          DL00040 = ML46494[L5_PL];
00671 00544          DL00042 = ML46498[L5_PL];
00672 00545          IF DL00040 == 0;
00673 00546              DL00040 = 2147483647;
00674 00547          IEND;
00675 00548          IF DL00042 == 0;
00676 00549              DL00042 = -2147483648;
00677 00550          IEND;
00678
00679 00551          DL00044 = ML46404[L5_PL];
00680 00552          DL00046 = ML46406[L5_PL];
00681 00553          IF DL00044 < 1000;
00682 00554              DL00044 = 1000;
00683 00555          IEND;
00684 00556          IF DL00046 < 1000;
00685 00557              DL00046 = 1000;
00686 00558          IEND;
00687
00688 00559          OWB003[L5_SW] = 0200H;          " Function setting 1
00689 00560          OWB03A[L5_SW] = MW46416[L5_PW];      " Filter time constant setting
00690 00561          OLB022[L5_SL] = ML46414[L5_PL];      " Error count alarm detection
00691 00562          OLB036[L5_SL] = DL00044;            " Acc setting
00692 00563          OLB038[L5_SL] = DL00046;            " Dcc setting

```



```

00693
00694      " ACC Setting
00695 00564      OWB008[L5_SW] = 10;      " Change Acceleration Time
00696 00565      IOW IWB008[L5_SW] == 10;
00697 00566      IOW IBB0098[L5_SB] == 1;
00698 00567      OWB008[L5_SW] = 0      " Servo Command Clear
00699 00568      IOW IWB008[L5_SW] == 0      " Servo Command Clear Confirm
00700
00701      " DCC Setting
00702 00569      OWB008[L5_SW] = 11;      " Change Deceleration Time
00703 00570      IOW IWB008[L5_SW] == 11;
00704 00571      IOW IBB0098[L5_SB] == 1;
00705 00572      OWB008[L5_SW] = 0      " Servo Command Clear
00706 00573      IOW IWB008[L5_SW] == 0      " Servo Command Clear Confirm
00707
00708      " Change Filter Time Constant
00709 00574      OWB008[L5_SW] = 12;      " Change Filter Time Constant
00710 00575      IOW IWB008[L5_SW] == 12;
00711 00576      IOW IBB0098[L5_SB] == 1;
00712 00577      OWB008[L5_SW] = 0      " Servo Command Clear
00713 00578      IOW IWB008[L5_SW] == 0      " Servo Command Clear Confirm
00714
00715      " Change Filter Type
00716 00579      OWB008[L5_SW] = 13;      " Change Filter Type
00717 00580      IOW IWB008[L5_SW] == 13;
00718 00581      IOW IBB0098[L5_SB] == 1;
00719 00582      OWB008[L5_SW] = 0      " Servo Command Clear
00720 00583      IOW IWB008[L5_SW] == 0      " Servo Command Clear Confirm
00721
00722      " SoftLimit+
00723 00584      OWB054[L5_SW] = 12      " Servo driver for assistance user constant No
00724 00585      OWB055[L5_SW] = 1      " Servo driver for assistance user constant Size
00725 00586      OLB056[L5_SL] = DL00040      " Servo driver for assistance user constant set
point
00726 00587      OWB00A[L5_SW] = 6;      " Write fixed parameter
00727 00588      IOW IWB00A[L5_SW] == 6;
00728 00589      IOW IBB00B8[L5_SB] == 1;
00729 00590      OWB00A[L5_SW] = 0      " Servo SubCommand Clear
00730 00591      IOW IWB00A[L5_SW] == 0      " Servo SubCommand Clear Confirm
00731
00732      " SoftLimit-
00733 00592      OWB054[L5_SW] = 14      " Servo driver for assistance user constant No
00734 00593      OWB055[L5_SW] = 1      " Servo driver for assistance user constant Size
00735 00594      OLB056[L5_SL] = DL00042      " Servo driver for assistance user constant set
point
00736 00595      OWB00A[L5_SW] = 6;      " Write fixed parameter
00737 00596      IOW IWB00A[L5_SW] == 6;
00738 00597      IOW IBB00B8[L5_SB] == 1;
00739 00598      OWB00A[L5_SW] = 0      " Servo SubCommand Clear
00740 00599      IOW IWB00A[L5_SW] == 0      " Servo SubCommand Clear Confirm
00741 00600      L5_PW = DW00048 * 2      " Parameter Index
00742
00743      " Travel distance per machine rotation
00744 00601      OWB05C[L5_SW] = 6      " Travel distance per machine rotation
00745 00602      OWB00A[L5_SW] = 5      " Read fixed parameter
00746 00603      IOW IWB00A[L5_SW] == 5;
00747 00604      IOW IBB00B8[L5_SB] == 1;
00748 00605      ML10400[L5_ML] = ILB056[L5_SL];
00749 00606      OWB00A[L5_SW] = 0      " Servo SubCommand Clear
00750 00607      IOW IWB00A[L5_SW] == 0      " Servo SubCommand Clear Confirm
00751
00752      " Rated motor speed
00753 00608      OWB05C[L5_SW] = 34      " Rated motor speed
00754 00609      OWB00A[L5_SW] = 5      " Read fixed parameter
00755 00610      IOW IWB00A[L5_SW] == 5;
00756 00611      IOW IBB00B8[L5_SB] == 1;
00757 00612      ML10600[L5_ML] = ILB056[L5_SL];
00758 00613      OWB00A[L5_SW] = 0      " Servo SubCommand Clear
00759 00614      IOW IWB00A[L5_SW] == 0      " Servo SubCommand Clear Confirm
00760
00761      " Servo motor gear ratio
00762 00615      OWB05C[L5_SW] = 8      " Rated motor speed
00763 00616      OWB00A[L5_SW] = 5      " Read fixed parameter
00764 00617      IOW IWB00A[L5_SW] == 5;
00765 00618      IOW IBB00B8[L5_SB] == 1;
00766 00619      ML11400[L5_ML] = ILB056[L5_SL];
00767 00620      OWB00A[L5_SW] = 0      " Servo SubCommand Clear
00768 00621      IOW IWB00A[L5_SW] == 0      " Servo SubCommand Clear Confirm
00769
00770      " Machine gear ratio
00771 00622      OWB05C[L5_SW] = 9      " Rated motor speed
00772 00623      OWB00A[L5_SW] = 5      " Read fixed parameter
00773 00624      IOW IWB00A[L5_SW] == 5;
00774 00625      IOW IBB00B8[L5_SB] == 1;
00775 00626      ML11600[L5_ML] = ILB056[L5_SL];
00776 00627      OWB00A[L5_SW] = 0      " Servo SubCommand Clear
00777 00628      IOW IWB00A[L5_SW] == 0      " Servo SubCommand Clear Confirm

```

```

00778 00629          OLB020[L5_SL] = 0          " NEAR signal output width
00779 00630          IEND;
00780 00631          DW00048 = DW00048 + 1          " Loop counter
00781 00632          EOX;
00782 00633          WEND;
00783 00634          JOINTO LabelX;
00784
00785          Line7: "CirCuit No8
00786 00635          DW00058 = 0;
00787 00636          WHILE DW00058 < 16          " Loop counter
00788 00637              IF MB100050[DW00058] == ON          " Line8 Servo Use
00789 00638                  L6_SW = DW00058 * 128          " Servo setting parameter Index
00790 00639                  L6_SL = DW00058 * 128 / 2          " Servo setting parameter Index
00791 00640                  L6_PW = DW00058 * 100          " Parameter Index
00792 00641                  L6_PL = DW00058 * 100 / 2          " Parameter Index
00793 00642                  L6_SB = DW00058 * 128 * 16          " Servo setting parameter BitIndex
00794 00643                  L6_ML = DW00058 + (16 * 5);
00795
00796 00644                  DL00050 = ML48094[L6_PL]          " AxisData SoftLimit+
00797 00645                  DL00052 = ML48098[L6_PL]          " AxisData SoftLimit-
00798
00799 00646                  IF DL00050 == 0;
00800 00647                      DL00050 = 2147483647;
00801 00648                  IEND;
00802 00649                  IF DL00052 == 0;
00803 00650                      DL00052 = -2147483648;
00804 00651                  IEND;
00805
00806 00652                  DL00054 = ML48004[L6_PL]          " AxisData ACC Setting
00807 00653                  DL00056 = ML48006[L6_PL]          " AxisData DCC Setting
00808 00654                  IF DL00054 < 1000;
00809 00655                      DL00054 = 1000;
00810 00656                  IEND;
00811 00657                  IF DL00056 < 1000;
00812 00658                      DL00056 = 1000;
00813 00659                  IEND;
00814
00815 00660                  OWB803[L6_SW] = 0200H;          " Function setting 1
00816 00661                  OWB83A[L6_SW] = MW48016[L6_PW];          " Filter time constant setting
00817 00662                  OLB822[L6_SL] = ML48014[L6_PL];          " Error count alarm detection
00818 00663                  OLB836[L6_SL] = DL00054;          " Acc setting
00819 00664                  OLB838[L6_SL] = DL00056;          " Dcc setting
00820
00821                  " ACC Setting
00822 00665                  OWB808[L6_SW] = 10;          " Change Acceleration Time
00823 00666                  IOW IWB808[L6_SW] == 10;
00824 00667                  IOW IBB8098[L6_SB] == 1;
00825 00668                  OWB808[L6_SW] = 0          " Servo Command Clear
00826 00669                  IOW IWB808[L6_SW] == 0          " Servo Command Clear Confirm
00827
00828                  " DCC Setting
00829 00670                  OWB808[L6_SW] = 11;          " Change Deceleration Time
00830 00671                  IOW IWB808[L6_SW] == 11;
00831 00672                  IOW IBB8098[L6_SB] == 1;
00832 00673                  OWB808[L6_SW] = 0          " Servo Command Clear
00833 00674                  IOW IWB808[L6_SW] == 0          " Servo Command Clear Confirm
00834
00835                  " Change Filter Time Constant
00836 00675                  OWB808[L6_SW] = 12;          " Change Filter Time Constant
00837 00676                  IOW IWB808[L6_SW] == 12;
00838 00677                  IOW IBB8098[L6_SB] == 1;
00839 00678                  OWB808[L6_SW] = 0          " Servo Command Clear
00840 00679                  IOW IWB808[L6_SW] == 0          " Servo Command Clear Confirm
00841
00842                  " Change Filter Type
00843 00680                  OWB808[L6_SW] = 13;          " Change Filter Type
00844 00681                  IOW IWB808[L6_SW] == 13;
00845 00682                  IOW IBB8098[L6_SB] == 1;
00846 00683                  OWB808[L6_SW] = 0          " Servo Command Clear
00847 00684                  IOW IWB808[L6_SW] == 0          " Servo Command Clear Confirm
00848
00849                  " SoftLimit+
00850 00685                  OWB854[L6_SW] = 12          " Servo driver for assistance user constant No
00851 00686                  OWB855[L6_SW] = 1          " Servo driver for assistance user constant Size
00852 00687                  OLB856[L6_SL] = DL00050          " Servo driver for assistance user constant set
00853 00688          point
00854 00689                  OWB80A[L6_SW] = 6;          " Write fixed parameter
00855 00690                  IOW IWB80A[L6_SW] == 6;
00856 00691                  IOW IBB80B8[L6_SB] == 1;
00857 00692                  OWB80A[L6_SW] = 0          " Servo SubCommand Clear
00858                  IOW IWB80A[L6_SW] == 0          " Servo SubCommand Clear Confirm
00859
00860 00693                  " SoftLimit-
00861 00694                  OWB854[L6_SW] = 14          " Servo driver for assistance user constant No
00862 00695                  OWB855[L6_SW] = 1          " Servo driver for assistance user constant Size
00862 00695                  OLB856[L6_SL] = DL00052          " Servo driver for assistance user constant set

```

point

		MPS110 : Servo Parameter Setting	P00010
--	--	----------------------------------	--------

```

00863 00696          OWB80A[L6_SW] = 6;                " Write fixed parameter
00864 00697          IOW IWB80A[L6_SW] == 6;
00865 00698          IOW IBB80B8[L6_SB] == 1;
00866 00699          OWB80A[L6_SW] = 0                    " Servo SubCommand Clear
00867 00700          IOW IWB80A[L6_SW] == 0            " Servo SubCommand Clear Confirm
00868
00869 00701          L6_PW = DW00058 * 2                " Parameter Index
00870          " Travel distance per machine rotation
00871 00702          OWB85C[L6_SW] = 6                    " Travel distance per machine rotation
00872 00703          OWB80A[L6_SW] = 5                    " Read fixed parameter
00873 00704          IOW IWB80A[L6_SW] == 5;
00874 00705          IOW IBB80B8[L6_SB] == 1;
00875 00706          ML10400[L6_ML] = ILB856[L6_SL];
00876 00707          OWB80A[L6_SW] = 0                    " Servo SubCommand Clear
00877 00708          IOW IWB80A[L6_SW] == 0            " Servo SubCommand Clear Confirm
00878
00879          " Rated motor speed
00880 00709          OWB85C[L6_SW] = 34                " Rated motor speed
00881 00710          OWB80A[L6_SW] = 5                " Read fixed parameter
00882 00711          IOW IWB80A[L6_SW] == 5;
00883 00712          IOW IBB80B8[L6_SB] == 1;
00884 00713          ML10600[L6_ML] = ILB856[L6_SL];
00885 00714          OWB80A[L6_SW] = 0                    " Servo SubCommand Clear
00886 00715          IOW IWB80A[L6_SW] == 0            " Servo SubCommand Clear Confirm
00887
00888          " Servo motor gear ratio
00889 00716          OWB85C[L6_SW] = 8                " Rated motor speed
00890 00717          OWB80A[L6_SW] = 5                " Read fixed parameter
00891 00718          IOW IWB80A[L6_SW] == 5;
00892 00719          IOW IBB80B8[L6_SB] == 1;
00893 00720          ML11400[L6_ML] = ILB856[L6_SL];
00894 00721          OWB80A[L6_SW] = 0                    " Servo SubCommand Clear
00895 00722          IOW IWB80A[L6_SW] == 0            " Servo SubCommand Clear Confirm
00896
00897          " Machine gear ratio
00898 00723          OWB85C[L6_SW] = 9                " Rated motor speed
00899 00724          OWB80A[L6_SW] = 5                " Read fixed parameter
00900 00725          IOW IWB80A[L6_SW] == 5;
00901 00726          IOW IBB80B8[L6_SB] == 1;
00902 00727          ML11600[L6_ML] = ILB856[L6_SL];
00903 00728          OWB80A[L6_SW] = 0                    " Servo SubCommand Clear
00904 00729          IOW IWB80A[L6_SW] == 0            " Servo SubCommand Clear Confirm
00905
00906          OLB820[L6_SL] = 0                    " NEAR signal output width
00907 00731          IEND;
00908 00732          DW00058 = DW00058 + 1                " Loop counter
00909 00733          EOX;
00910 00734          WEND;
00911 00735          JOINTO LabelX;
00912
00913          Line8: "CirCuit No9
00914 00736          DW00068 = 0;
00915 00737          WHILE DW00068 < 16
00916 00738              IF MB100060[DW00068] == ON;
00917 00739                  L7_SW = DW00068 * 128
00918 00740                  L7_SL = DW00068 * 128 / 2
00919 00741                  L7_PW = DW00068 * 100
00920 00742                  L7_PL = DW00068 * 100 / 2
00921 00743                  L7_SB = DW00068 * 128 * 16
00922 00744                  L7_ML = DW00068 + (16 * 4);
00923
00924 00745                  DL00060 = ML49694[L7_PL];
00925 00746                  DL00062 = ML49698[L7_PL];
00926 00747                  IF DL00060 == 0;
00927 00748                      DL00040 = 2147483647;
00928 00749                  IEND;
00929 00750                  IF DL00062 == 0;
00930 00751                      DL00042 = -2147483648;
00931 00752                  IEND;
00932
00933 00753                  DL00064 = ML49604[L7_PL];
00934 00754                  DL00066 = ML49606[L7_PL];
00935 00755                  IF DL00064 < 1000;
00936 00756                      DL00064 = 1000;
00937 00757                  IEND;
00938 00758                  IF DL00066 < 1000;
00939 00759                      DL00066 = 1000;
00940 00760                  IEND;
00941
00942 00761          OWC003[L7_SW] = 0200H;                " Function setting 1
00943 00762          OWC03A[L7_SW] = MW49616[L7_PW];      " Filter time constant setting
00944 00763          OLC022[L7_SL] = ML49614[L7_PL];        " Error count alarm detection
00945 00764          OLC036[L7_SL] = DL00064;              " Acc setting
00946 00765          OLC038[L7_SL] = DL00066;              " Dcc setting
00947
00948 00766          IEND;
00949 00767          DW00068 = DW00068 + 1                " Loop counter

```

```

00950 00768      EOX;
00951 00769      WEND;
00952 00770      JOINTO LabelX;
00953 00771      LabelX: PJOINT;
00954
00955 00772      MB000120 = 1;
00956 00773      IOW MB000039 == 1
00957
00958 00774      DW00108 = 0;
00959 00775      WHILE DW00108 < 96
00960 00776          IF MB100000[DW00108] == ON;
00961 00777              L1_PL = DW00108 * 50
00962 00778              DL00004 = ML40004[L1_PL]
00963 00779              DL00006 = ML40006[L1_PL]
00964
00965 00780              L1_ML = DW00108;
00966 00781              IF MB100100[DW00108] == OFF
00967                  " FMX
00968                  DF00082 = ML10400[L1_ML];
00969 00783                  DF00084 = ML10600[L1_ML];
00970 00784                  DF00000 = DF00082 * DF00084;
00971 00785                  DF00002 = ML11600[L1_ML] / ML11400[L1_ML];
00972 00786                  ML10800[L1_ML] = DF00000 * DF00002;
00973 00787              ELSE;
00974                  " FMX
00975 00788                  DF00080 = ML10600[L1_ML] * 60;
00976 00789                  DF00000 = DF00080 * 1000 * 100;
00977 00790                  ML10800[L1_ML] = DF00000;
00978 00791              IEND;
00979 00792              DF00010 = ML10800[L1_ML] / 60;
00980 00793              DF00010 = DF00010 / DL00004 * 1000;
00981 00794              DF00012 = ML10800[L1_ML] / 60;
00982 00795              DF00012 = DF00012 / DL00006 * 1000;
00983
00984              " ACC time
00985 00796              ML11000[L1_ML] = DF00010;
00986 00797              IF ML11000[L1_ML] > 32767;
00987 00798                  ML11000[L1_ML] = 32767;
00988 00799              IEND;
00989              " DCC time
00990 00800              ML11200[L1_ML] = DF00012;
00991 00801              IF ML11200[L1_ML] > 32767;
00992 00802                  ML11200[L1_ML] = 32767;
00993 00803              IEND;
00994 00804          IEND;
00995 00805      DW00108 = DW00108 + 1
00996 00806      EOX;
00997 00807      WEND;
00998
00999 00808      MB000120 = 0;
01000
01001 00809      RET;
01002

```

" Param2 Executing
 " All Axis Parameter Setting Comp.2
 " Loop counter
 " Parameter Index
 " Acc
 " Dcc
 " Rotary
 " Linear
 " Loop counter
 " Param1 Executing