

```

00001      ** DL Register Area - 120Word
00002      **
00003      ** DW00000 - DW00009 (PLS Use)
00004      ** DW00010 - DW00039 (Bit Use)
00005      ** DW00040 - DW00089 (Word Use)
00006      ** DW00090 - DW00119 (Timer)
00007      ****
00008
00009      "# Program Name      : Camera Alignment
00010      "# Functionior      :
00011      "# Call Program     : MPS195
00012      "# Sub Program      :
00013      "# Func Program      :
00014
00015      VAR;
00016
00017      END_VAR;
00018
00019      " Alignment Data Clear
00020 00000      ML15408 = 0;                                " 1 Camera Mode Alignment Count
00021 00001      DW00080 = 0;                                " Alignment Result Judge
00022 00002      MB214720 = 0;                                " Alignment Request Reset
00023 00003      MB214721 = 0;                                " Alignment Request Reset
00024 00004      MB214780 = 0;                                " L Camera Manual Alignment Request
00025 00005      MB214781 = 0;                                " R Camera Manual Alignment Request
00026 00006      MB214790 = 0;                                " L Camera Manual Align Force
00027 00007      MB214791 = 0;                                " R Camera Manual Align Force
00028 00008      MW04938 = 0;                                " Auto Alignment Search Flag
00029 00009      IF MB047361 == 1                                " Dummy Align Seach Flag
00030 00010          ML21360 = GL21192                            " Alignment Mark ID Writ
00031 00011      ELSE;
00032 00012          ML21360 = ML01116                                " Alignment Mark ID Write
00033 00013      IEND;
00034 00014      DW00003 = 0;
00035 00015      DW00004 = 0;
00036 00016      DW00010 = 0;
00037
00038      " Manual Alignment Cutter X JOG Moving Valume Write
00039 00017      DL00020 = 0;
00040 00018      DL00022 = 0;
00041
00042 00019      MSEE MPS194;                                " Alignment Position Move 1 Cycle
00043
00044 00020      TIM TMW26234;
00045
00046 00021      IF MB000023 == 1;
00047 00022          MB045159 = 1;                                " Step Mode Next Fla
00048 00023          IOW (!MB21684D | MB20544E) | MB045013 ==    " Step Mode
00049 00024          MB045159 = 0;                                " Step Mode Next Fla
00050 00025      IEND;
00051
00052      " Chuck Break Receive Complete Bit Set
00053 00026      IF MB000004 == 1
00054 00027          MB045130 = 1;
00055 00028      IEND;
00056
00057      " Manual PTP
00058 00029      DB000020 = 0;
00059 00030      DB000021 = 0;
00060 00031      IF ML01118 == 1                                " DUMMY ALIGN MODE (0: Unuse / 1: Use)
00061 00032          IF MB047361 == 0                                " Dummy Align Seach Flag
00062 00033              DB000020 = 1;
00063 00034              DB000021 = 1;
00064 00035          IEND;
00065 00036      IEND;
00066 00037      IF !MB000004 == 1;
00067 00038          IF MW00051 == 82                                " Manual_Alignment Position
00068 00039              DB000020 = 1;
00069 00040              DB000021 = 0;
00070 00041          IEND;
00071 00042      IEND;
00072 00043      IF MB000800 == 1                                " MCTAG_Idling
00073 00044          DB000020 = 1;
00074 00045          DB000021 = 0;
00075 00046      IEND;
00076
00077      " Alignment Valume Reset
00078 00047      ML23100 = 0;                                " Alignment Data (X1)
00079 00048      ML23102 = 0;                                " Alignment Data (Y1)
00080 00049      ML23104 = 0;                                " Alignment Data (X2)
00081 00050      ML23106 = 0;                                " Alignment Data (Y2)
00082
00083 00051      IF DB000020 == 0                                " Dummy Run Check Or Camera Align No Use
00084 00052      Mode
00085 00053          IF GL21028 == 0;
00086 00054          DW00001 = 1;
00087
00088      ELSE;

```



```

00164 00121          ML15104 = ML23102 * -1          " Alignment Data (Y1)
00165 00122          ML15408 = 1;
00166 00123      ELSE;
00167 00124          ML15106 = ML23100          " Alignment Data (X2)
00168 00125          ML15108 = ML23102 * -1          " Alignment Data (Y2)
00169 00126      IEND;
00170 00127          DB000800 = 1;          " Alignment O.K Judge
00171 00128      IEND;
00172
00173 00129      IF GW21040 <> 0;
00174 00130          MSEE MPS251;          " Align Mark Auto Search 1 Cycle
00175 00131          IF MB049380 | MB049381 == 0;
00176 00132              DB000800 = 1;          " Alignment O.K Judg

00177 00133              DB000801 = 0;          " Alignment N.G Judge
00178 00134          IEND;
00179 00135      IEND;
00180
00181 00136          MB214720 = 0;          " L Camera Alignment Request Reset
00182 00137          IOW MB205320 == 0;
00183 00138      IEND;
00184 00139      IEND;
00185      //      IF MB201000 | MB201001 == 1          " Manual Alignment Search Abort
00186      //          DB000801 = 0;          " Alignment N.G Judge
00187      //          MB000015 = 1;          "2023.05.08
00188      //          EOX;
00189      //      IEND;
00190 00140      DW000006 = 0;
00191
00192      //      IF DB000800 | DB000801 == 1;
00193      //          DW000010 = 0;
00194      //          " Alignment Data Zero Alarm
00195      //          IF ML23100 == 0          " Alignment Data (X1)
00196      //              IF ML23102 == 0          " Alignment Data (Y1)
00197      //                  IF ML23104 == 0          " Alignment Data (X2)
00198      //                      IF ML23106 == 0          " Alignment Data (Y2)

00199      //          DB000101 = 1;
00200      //          IEND;
00201      //          IEND;
00202      //          IEND;
00203      //          IEND;
00204      //
00205      //          IF DW000010 <> 0;
00206      //              " Alignment Data Check Alarm
00207      //              MB04539B = 1;
00208      //              MB000015 = 1;
00209      //              EOX;
00210      //          IEND;
00211      //          DW000010 = 0;
00212      //          IEND;
00213 00141      DW000001 = DW000001 + 1;
00214 00142      EOX;
00215 00143      WEND;
00216
00217 00144      IF DB000030 & DB000031 & DB000032 & DB000030 == 1;
00218      " Alignment Data Check Alarm
00219 00145          MB04539C = 1;
00220 00146          MB000015 = 1;
00221 00147          EOX;
00222 00148      IEND;
00223      " # Step.03 Manual Search
00224      " Manual Search Flag
00225 00149      IF DB000801 == 1          " Alignment Result NG
00226 00150          IOW MB205320 | MB205321 == 0;
00227 00151          IF GL21028 == 0;
00228 00152              DB000801 = 0;          " Alignment N.G Judge
00229 00153              DB000800 = 0;          " Alignment O.K Judg
00230 00154              DB000060 = 0;
00231 00155              DB000061 = 0;
00232 00156              DB000062 = 0;
00233 00157              DB000063 = 0;
00234
00235 00158          MB045726 = 0;
00236 00159          PFORK Line01 Line02;
00237
00238          Line01:
00239
00240 00160              IF MB049380 == 1;
00241 00161                  MB214720 = 0;          " L Camera Alignment Request On
00242 00162                  MB214780 = 0;          " L Camera Manual Alignment Request
00243 00163                  EOX;
00244 00164                  IF MB000842 == 1;
00245 00165                      MB045726 = 1;          " Manual Alignment Executing Flag
00246 00166                  IEND;
00247 00167                  DB000050 = 0;
00248 00168                  WHILE DB000050 == 0;

```

```

00249 00169                IF MB000842 == 0                " Alignment Jog Use
00250 00170                IF !MB214780 & MB205320 == 0    " L Camera Manual Alignment Sear
ching & L Camera Alignment Complete
00251 00171                MB214780 = 1;                " L Camera Manual Alignment Requ
est
00252 00172                EOX;
00253 00173                MB214720 = 1;                " L Camera Alignment Request ( 1
00254 00174                IEND;
00255
00256 00175                IF MB205320 == 1                " L Camera Manual Alignment Sear
ching & L Camera Alignment Complete
00257 00176                MB214720 = 0;                " L Camera Alignment Request ( 1
00258 00177                MB214780 = 0;                " L Camera Manual Alignment Requ
est
00259 00178                DB000050 = 1;
00260 00179                IEND;
00261 00180                ELSE;
00262 00181                IEND;
00263 00182                EOX;
00264 00183                WEND;
00265 00184                IEND;
00266
00267 00185                JOINTO Label0X;
00268
00269                Line02:
00270
00271 00186                IF MB049381 == 1;
00272 00187                MB214721 = 0;                " R Camera Alignment Request ( 1
00273 00188                MB214781 = 0;                " R Camera Manual Alignment Requ
est
00274 00189                EOX;
00275 00190                IF MB000842 == 1;
00276 00191                MB045726 = 1;                " Manual Alignment Executing Fla
g
00277 00192                IEND;
00278
00279 00193                DB000051 = 0;
00280 00194                WHILE DB000051 == 0;
00281 00195                IF MB000842 == 0                " Alignment Jog Use
00282 00196                IF !MB214781 & MB205321 == 0    " R Camera Manual Alignment Sear
ching & L Camera Alignment Complete
00283 00197                MB214781 = 1;                " R Camera Manual Alignment Requ
est
00284 00198                EOX;
00285 00199                MB214721 = 1;                " R Camera Alignment Request ( 1
00286 00200                IEND;
00287
00288 00201                IF MB205321 == 1                " R Camera Manual Alignment Sear
ching & L Camera Alignment Complete
00289 00202                MB214721 = 0;                " R Camera Alignment Request ( 1
00290 00203                MB214781 = 0;                " R Camera Manual Alignment Requ
est
00291 00204                DB000051 = 1;
00292 00205                IEND;
00293 00206                ELSE;
00294 00207                IEND;
00295 00208                EOX;
00296 00209                WEND;
00297 00210                IEND;
00298
00299 00211                JOINTO Label0X;
00300 00212                Label0X: PJOINT;
00301
00302 00213                DB000050 = 0;
00303 00214                DB000051 = 0;
00304
00305                " Manual Alignment Cutter X JOG Moving Valume Write
00306
00307 00215                MB045726 = 0;
00308
00309 00216                IF MB201000 | MB201001 == 1        " Manual Alignment Search Abort
00310 00217                MB04539F = 1;
00311 00218                DB000801 = 1;                " Alignment N.G Judge
00312 00219                EOX;
00313 00220                ELSE;
00314 00221                DB000800 = 1;                " Alignment O.K Judg
00315 00222                IEND;
00316
00317 00223                DW000010 = 0;
00318 00224                IF ML23100 == 0                " Alignment Data (X1)

```

```

00319 00225          DB000100 = 1;
00320 00226      IEND;
00321 00227      IF ML23102 == 0          " Alignment Data (Y1)
00322 00228          DB000101 = 1;
00323 00229      IEND;
00324 00230          IF ML23104 == 0          " Alignment Data (X2)
00325 00231          DB000102 = 1;
00326 00232      IEND;
00327 00233          IF ML23106 == 0          " Alignment Data (Y2)

00328 00234          DB000103 = 1;
00329 00235      IEND;
00330
00331 00236      IF DB000100 & DB000101 == 1;
00332          " Alignment N.G Judge
00333 00237          MB04539B = 1;
00334 00238          DB000801 = 1;
00335 00239          MB000015 = 1;
00336 00240          EOX;
00337 00241      IEND;
00338
00339 00242          IF DB000102 & DB000103 == 1;
00340          " Alignment N.G Judge
00341 00243          MB04539B = 1;
00342 00244          DB000801 = 1;
00343 00245          MB000015 = 1;
00344 00246          EOX;
00345 00247      IEND;
00346
00347          " Alignment BackUp Data and Current Data Check
00348 00248      IF ML23100 <> 0;
00349 00249          IF DL00040 == ML23100;
00350 00250              DB000030 = 1;
00351 00251          IEND;
00352 00252      IEND;
00353 00253      IF ML23102 <> 0;
00354 00254          IF DL00042 == ML23102;
00355 00255              DB000031 = 1;
00356 00256          IEND;
00357 00257      IEND;
00358 00258      IF ML23104 <> 0;
00359 00259          IF DL00044 == ML23104;
00360 00260              DB000032 = 1;
00361 00261          IEND;
00362 00262      IEND;
00363 00263      IF ML23106 <> 0;
00364 00264          IF DL00046 == ML23106;
00365 00265              DB000033 = 1;
00366 00266          IEND;
00367 00267      IEND;
00368
00369 00268      IF DB000030 & DB000031 & DB000032 & DB000030 == 1;
00370          " Alignment Data Check Alarm
00371 00269          MB04539C = 1;
00372 00270          MB000015 = 1;
00373 00271          EOX;
00374 00272      IEND;
00375
00376          //      DL00040 = ML23100          " Alignment Data (X1)
00377          //      DL00042 = ML23102 * -1      " Alignment Data (Y1)
00378          //      DL00044 = ML23104          " Alignment Data (X2)
00379          //      DL00046 = ML23106 * -1      " Alignment Data (Y2)
00380
00381          " Alignment O.K Judg
00382 00273      IF DB000800 == 1;
00383 00274          ML15102 = ML23100 + DL00020      " Alignment Data (X1)
00384 00275          ML15104 = ML23102 * -1          " Alignment Data (Y1)
00385 00276          ML15106 = ML23104 + DL00022      " Alignment Data (X2)
00386 00277          ML15108 = ML23106 * -1          " Alignment Data (Y2)
00387 00278      IEND;
00388
00389 00279      DW00010 = 0;
00390
00391 00280          DB000801 = 0;          " Alignment N.G Judge
00392 00281          DB000800 = 0;          " Alignment O.K Judge
00393
00394 00282          MB214780 = 0;          " L Camera Manual Alignment Request
00395 00283          MB214781 = 0;          " R Camera Manual Alignment Request
00396 00284          MB214720 = 0;          " L Camera Alignment Request On
00397 00285          MB214721 = 0;          " R Camera Alignment Request (

00398 00286      ELSE;
00399 00287          IF GL21028 == 1;
00400 00288              MB214780 = 1;          " L Camera Manual Alignment Request
00401 00289              MB214720 = 1;          " L Camera Alignment Request On
00402 00290              IOW MB201100 == 1      " L Camera Manual Alignment Searching
00403 00291              IOW MB205320 == 1      " L Camera Alignment Complete

```

```

00404
00405 00292      IF MB201100 == 1                      " Manual Alignment Search Abort
00406 00293          MB04539F = 1;
00407 00294          DB000801 = 1;
00408 00295          EOX;
00409 00296      ELSE;
00410 00297          DB000800 = 1;
00411 00298      IEND;
00412
00413 00299      DW00010 = 0;
00414 00300      IF ML23100 == 0                      " Alignment Data (X1)
00415 00301          DB000100 = 1;
00416 00302      IEND;
00417 00303      IF ML23102 == 0                      " Alignment Data (Y1)
00418 00304          DB000101 = 1;
00419 00305      IEND;
00420 00306      IF ML23104 == 0                      " Alignment Data (X2)
00421 00307          DB000102 = 1;
00422 00308      IEND;
00423 00309      IF ML23106 == 0                      " Alignment Data (Y2)
00424 00310          DB000103 = 1;
00425 00311      IEND;
00426
00427 00312      IF DB000100 & DB000101 == 1;
00428          " Alignment N.G Judge
00429 00313          MB04539B = 1;
00430 00314          DB000801 = 1;
00431 00315          MB000015 = 1;
00432 00316          EOX;
00433 00317      IEND;
00434
00435 00318      IF DB000102 & DB000103 == 1;
00436          " Alignment N.G Judge
00437 00319          MB04539B = 1;
00438 00320          DB000801 = 1;
00439 00321          MB000015 = 1;
00440 00322          EOX;
00441 00323      IEND;
00442
00443          " Alignment BackUp Data and Current Data Check
00444 00324      IF ML23100 <> 0;
00445 00325          IF DL000040 == ML23100;
00446 00326              DB000030 = 1;
00447 00327          IEND;
00448 00328      IEND;
00449 00329      IF ML23102 <> 0;
00450 00330          IF DL000042 == ML23102;
00451 00331              DB000031 = 1;
00452 00332          IEND;
00453 00333      IEND;
00454 00334      IF ML23104 <> 0;
00455 00335          IF DL000044 == ML23104;
00456 00336              DB000032 = 1;
00457 00337          IEND;
00458 00338      IEND;
00459 00339      IF ML23106 <> 0;
00460 00340          IF DL000046 == ML23106;
00461 00341              DB000033 = 1;
00462 00342          IEND;
00463 00343      IEND;
00464
00465 00344      IF DB000030 & DB000031 & DB000032 & DB000030 == 1;
00466          " Alignment Data Check Alarm
00467 00345          MB04539C = 1;
00468 00346          MB000015 = 1;
00469 00347          EOX;
00470 00348      IEND;
00471
00472          //      DL000040 = ML23100                      " Alignment Data (X1)
00473          //      DL000042 = ML23102 * -1                " Alignment Data (Y1)
00474          //      DL000044 = ML23104                      " Alignment Data (X2)
00475          //      DL000046 = ML23106 * -1                " Alignment Data (Y2)
00476
00477 00349      IF DB000800 == 1;
00478 00350          IF ML15408 == 0;
00479 00351              ML15102 = ML23100 + DL00002C      " Alignment Data (X1)
00480 00352              ML15104 = ML23102 * -1          " Alignment Data (Y1)
00481 00353              ML15408 = 1;
00482 00354          ELSE;
00483 00355              ML15106 = ML23100 + DL00002C      " Alignment Data (X1)
00484 00356              ML15108 = ML23102 * -1          " Alignment Data (Y1)
00485 00357          IEND;
00486 00358      IEND;
00487
00488 00359      DW00010 = 0;
00489

```

```

00490 00360          DB000801 = 0;          " Alignment N.G Judge
00491 00361          DB000800 = 0;          " Alignment O.K Judge
00492
00493 00362          MB214780 = 0;          " L Camera Manual Alignment Request
00494 00363          MB214781 = 0;          " R Camera Manual Alignment Request
00495 00364          MB214720 = 0;          " L Camera Alignment Request On
00496 00365          MB214721 = 0;          " R Camera Alignment Request ( 1
00497 00366          IEND;
00498 00367          IEND;
00499 00368          IEND;
00500
00501 00369          ML15112 = ML15102          " Alignment Data (X1)_Dummy
00502 00370          ML15114 = ML15104          " Alignment Data (Y1)_Dummy
00503 00371          ML15116 = ML15106          " Alignment Data (X2)_Dummy
00504 00372          ML15118 = ML15108          " Alignment Data (Y2)_Dummy
00505 00373          ELSE;
00506 00374              IF MB030035 == 1;
00507 00375                  ML15102 = 0;          " Alignment Data (X1)
00508 00376                  ML15104 = 0;          " Alignment Data (Y1)
00509 00377                  ML15106 = 0;          " Alignment Data (X2)
00510 00378                  ML15108 = 0;          " Alignment Data (Y2)
00511 00379                  IF DB000021 == 1
00512 00380                      ML15102 = ML15112          " Alignment Data (X1)
00513 00381                      ML15104 = ML15114          " Alignment Data (Y1)
00514 00382                      ML15106 = ML15116          " Alignment Data (X2)
00515 00383                      ML15108 = ML15118          " Alignment Data (Y2)
00516 00384                  IEND;
00517 00385              IEND;
00518 00386          IEND;
00519
00520          " Alignment BackUp Data and Current Data Check
00521 00387          IF ML15102 <> 0;
00522 00388              IF DL00040 == ML15102;
00523 00389                  DB000030 = 1;
00524 00390              IEND;
00525
00526 00391              DL00050 = ML15102 - DL00040;
00527 00392              IF DL00050 < 0;
00528 00393                  DL00050 = DL00050 * -1;
00529 00394              IEND;
00530 00395              IF DL00050 > ML26278;
00531 00396                  DB000040 = 1;
00532 00397              IEND;
00533 00398          IEND;
00534 00399          IF ML15104 <> 0;
00535 00400              IF DL00042 == ML15104;
00536 00401                  DB000031 = 1;
00537 00402              IEND;
00538
00539 00403              DL00052 = ML15104 - DL00042;
00540 00404              IF DL00052 < 0;
00541 00405                  DL00052 = DL00052 * -1;
00542 00406              IEND;
00543 00407              IF DL00052 > ML26278;
00544 00408                  DB000041 = 1;
00545 00409              IEND;
00546 00410          IEND;
00547 00411          IF ML15106 <> 0;
00548 00412              IF DL00044 == ML15106;
00549 00413                  DB000032 = 1;
00550 00414              IEND;
00551
00552 00415              DL00054 = ML15106 - DL00044;
00553 00416              IF DL00054 < 0;
00554 00417                  DL00054 = DL00054 * -1;
00555 00418              IEND;
00556 00419              IF DL00054 > ML26278;
00557 00420                  DB000042 = 1;
00558 00421              IEND;
00559 00422          IEND;
00560 00423          IF ML15108 <> 0;
00561 00424              IF DL00046 == ML15108;
00562 00425                  DB000033 = 1;
00563 00426              IEND;
00564
00565 00427              DL00056 = ML15108 - DL00046;
00566 00428              IF DL00056 < 0;
00567 00429                  DL00056 = DL00056 * -1;
00568 00430              IEND;
00569 00431              IF DL00056 > ML26278;
00570 00432                  DB000043 = 1;
00571 00433              IEND;
00572 00434          IEND;
00573
00574 00435          IF DB000030 & DB000031 & DB000032 & DB000033 == 1;
00575          " Alignment Data Check Alarm
00576 00436          MB04539C = 1;

```

```

00577 00437      MB000015 = 1;
00578 00438      EOX;
00579 00439      IEND;
00580
00581 00440      IF ML26278 <>0;
00582 00441          IF DB000040 | DB000041 | DB000042 | DB000043 == 1;
00583              " Alignment Data Check Alarm
00584 00442          MB04539A = 1;
00585 00443          MB000015 = 1;
00586 00444          EOX;
00587 00445          IEND;
00588 00446      IEND;
00589
00590 00447      IF ML15102 == 0              " Alignment Data (X1)
00591 00448          DB000100 = 1;
00592 00449      IEND;
00593 00450      IF ML15104 == 0              " Alignment Data (Y1)
00594 00451          DB000101 = 1;
00595 00452      IEND;
00596 00453      IF ML15106 == 0              " Alignment Data (X2)
00597 00454          DB000102 = 1;
00598 00455      IEND;
00599 00456      IF ML15108 == 0              " Alignment Data (Y2)

00600 00457          DB000103 = 1;
00601 00458      IEND;
00602
00603 00459      IF DB000100 & DB000101 == 1;
00604          " Alignment N.G Judge
00605 00460          MB04539B = 1;
00606 00461          MB000015 = 1;
00607 00462          EOX;
00608 00463      IEND;
00609
00610 00464      IF DB000102 & DB000103 == 1;
00611          " Alignment N.G Judge
00612 00465          MB04539B = 1;
00613 00466          DB000801 = 1;
00614 00467          MB000015 = 1;
00615 00468          EOX;
00616 00469      IEND;
00617
00618 00470      IF ML26276 <> 0;
00619 00471          MB045049 = 0;
00620 00472          MB045069 = 1;              " L_CHECK Start
00621 00473          IOW MB045059 == 1      " L_CHECK Comp
00622 00474          MB045069 = 0;      " L_CHECK End
00623
00624 00475          IF MB45049 == 1;
00625              " Alignment Data Check Alarm
00626 00476          MB045399 = 1;
00627 00477          MB000015 = 1;
00628 00478          EOX;
00629 00479          IEND;
00630 00480      IEND;
00631
00632 00481      IF !MB04539C & !MB04539B & !MB045399 & !MB04539A == 1;
00633 00482          DL00040 = ML15102              " Alignment Data (X1)
00634 00483          DL00042 = ML15104              " Alignment Data (Y1)
00635 00484          DL00044 = ML15106              " Alignment Data (X2)
00636 00485          DL00046 = ML15108              " Alignment Data (Y2)
00637 00486      IEND;
00638
00639 00487      IF MW00051 <> 82;
00640 00488          IF MB045013 == 0              " Cycle Stop Chec
00641 00489              IF MB047361 == 1      " Dummy Align Seach Flag
00642                  " Scribe Chuck Y
00643 00490              IF MB04524A == 0;
00644                  " Scribe Chuck Y Alignment Position
00645 00491                  IOW MW04518 == 0;
00646 00492                  MW04518 = 4;              " Scribe Scribe Chuck Command Code

00647 00493      Alignment Position      MB045190 = 1;              " Scribe Scribe Chuck Command Execu
00648 00494      te Bit ON                  IOW MB045191 == 1      " Scribe Scribe Chuck Command Compl
00649 00495      ete Bit ON                  MB045190 = 0;          " Scribe Scribe Chuck Command Execu
00650 00496      te Bit OFF                  IOW MB045191 == 0      " Scribe Scribe Chuck Command Compl
00651 00497      ete Bit ON
00652 00498          IEND;
00653 00499      IEND;
00654 00500      IEND;
00655
00656      " Alignment Execute 1 Cycle
00657 00501      IF MB000004 == 1

```



```
00658 00502      IF MB04539F == 0
00659 00503          MB045131 = 1;
00660 00504      IEND;
00661 00505      IEND;
00662 00506      RET;
```

" Manual Alignment Search Abort :
" Alignment Complete