

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : CZ Torque Setting
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG Axis_Pos = 0;
00018 00001 LONG Axis_IO = 0;
00019 00002 LONG Load_Tbl = 0;
00020 00003 LONG Load_Pos = 0
00021 CONST LONG IDX_CZ = 0; " Changes when copying to other 0origi
00022 END_VAR;
00023
00024 " Manual/Auto Select
00025 00004 DB00000 = 0; " Manual Data
00026 00005 IF MB00004 == 1 " AutoRunning
00027 00006 DB00000 = 1; " Recipe Data
00028 00007 ELSE;
00029 00008 IF MB225580 == 1 " Recipe Data
00030 00009 DB00000 = 1; " Recipe Data
00031 00010 IEND;
00032 00011 IEND;
00033
00034 00012 Axis_Pos = IDX_CZ * 50;
00035 00013 Axis_IO = IDX_CZ * 128 / 2;
00036 00014 Load_Tbl = IDX_CZ * 100;
00037 00015 Load_Pos = IDX_CZ * 100;
00038
00039 00016 DW00010 = MW15520 " Cutter Z1 Setting Torque
00040 00017 DW00011 = MW15525 " Cutter Z1 Setting Axis
00041
00042 "=====
00043 " Torque Setting
00044 "=====
00045 00018 SFORK DW00010 == 0 ? LBL000 " Setting Torque
00046 DW00010 == 1 ? LBL001 " Positioning Torque
00047 DW00010 == 2 ? LBL002 " 0 Level Detection Torque
00048 DW00010 == 3 ? LBL003 " Load Measurement Torque
00049 DW00010 == 4 ? LBL004 " Load Offset Torque
00050 DW00010 == 5 ? LBL005 " Roller Break Pushing Torque
00051 DW00010 == 7 ? LBL007 " Scribe Torque(2nd)
00052 DW00010 == 8 ? LBL008 " Scribe Torque(1st)
00053 DW00010 == 9 ? LBL009 " Load Calibration Torque
00054 DW00010 == 10 ? LBL010 " Offset Set Scribe Torque
00055 DW00010 == 11 ? LBL011 " Scribe Torque(3rd)
00056 DW00010 == 12 ? LBL012 " Scribe Torque(JustCut)
00057 DW00010 == 13 ? LBL013 " Wheel Change Align Torque
00058 DW00010 == 14 ? LBL014 " Scribe Torque(YCut Interpolation)
00059 DW00010 == 15 ? LBL015 " Scribe Torque(YCut)
00060 DW00010 == 16 ? LBL016 " Scribe Torque(JustCut Interpolation)
00061
00062 00019 LBL000:
00063
00064 00020 JOINTC LBL00X;
00065
00066 00021 LBL001: " Positioning Torque
00067
00068 00022 MW15500 = 10000;
00069 00023 MW15505 = 10000;
00070 00024 MW15510 = 10000;
00071 00025 MW15515 = 10000;
00072
00073 00026 JOINTC LBL00X;
00074
00075 00027 LBL002: " 0 Point Detect Torque
00076
00077 00028 UFC CM_TRQ ML23800, MA91000, DB00000F MW15500;
00078 00029 UFC CM_TRQ ML23800, MA91600, DB00000F MW15505;
00079 00030 UFC CM_TRQ ML23800, MA92200, DB00000F MW15510;
00080 00031 UFC CM_TRQ ML23800, MA92800, DB00000F MW15515;
00081
00082 00032 JOINTC LBL00X;
00083
00084 00033 LBL003: " Load Measurement Torque + Offset
00085
00086 00034 DL00002 = ML26500 + ML26520 " UPCZ
00087 00035 DL00004 = ML26500 + ML26544 " UPRZ

```

```

00088 00036      DL00006 = ML26500 + ML26532      " LOCZ
00089 00037      DL00008 = ML26500 + ML26556      " LORZ
00090 00038      UFC CM_TRQ DL00002, MA91000, DB00000F MW15500;
00091 00039      UFC CM_TRQ DL00004, MA91600, DB00000F MW15505;
00092 00040      UFC CM_TRQ DL00006, MA92200, DB00000F MW15510;
00093 00041      UFC CM_TRQ DL00008, MA92800, DB00000F MW15515;
00094
00095 00042      JOINTC LBL00X;
00096
00097 00043      LBL004:      " Load Measurement Torque
00098
00099 00044      DL00002 = ML26500;
00100 00045      DL00004 = ML26500;
00101 00046      DL00006 = ML26500;
00102 00047      DL00008 = ML26500;
00103 00048      UFC CM_TRQ DL00002, MA91000, DB00000F MW15500;
00104 00049      UFC CM_TRQ DL00004, MA91600, DB00000F MW15505;
00105 00050      UFC CM_TRQ DL00006, MA92200, DB00000F MW15510;
00106 00051      UFC CM_TRQ DL00008, MA92800, DB00000F MW15515;
00107
00108 00052      JOINTC LBL00X;
00109
00110 00053      LBL005:      " Upper Roller Z Load Setting
00111
00112      " Upper Roller Z Load Setting
00113 00054      DL00004 = ML01180;
00114 00055      IF MB45736 == 0      " RollerBreak(0:Manual Data, 1:Recipe Data)
00115 00056      DL00004 = ML21272;
00116 00057      IEND;
00117
00118 00058      MW15500 = 10000;
00119 00059      UFC CM_TRQ DL00004, MA91600, DB00000F MW15505;
00120 00060      MW15510 = 10000;
00121 00061      MW15515 = 10000;
00122
00123 00062      JOINTC LBL00X;
00124
00125 00063      LBL007:      " Scribe Torque(2nd)
00126
00127      " UPCZ
00128 00064      DL00002 = ML15256 + ML26520 + ML04864;
00129      " UPRZ
00130 00065      DL00004 = ML15258 + ML26544 + ML04866;
00131      " LOCZ
00132 00066      DL00006 = ML15260 + ML26532 + ML04868;
00133      " LORZ
00134 00067      DL00008 = ML15262 + ML26556 + ML04870;
00135
00136 00068      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00137 00069      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00138 00070      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00139 00071      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00140
00141      " Do Not Head Torque 100% Setting
00142 00072      IF ML01142 == 0;
00143      " UPRZ Torque 100%
00144 00073      MW15505 = 10000;
00145 00074      ELSE;
00146      " UPCZ Torque 100%
00147 00075      MW15500 = 10000
00148 00076      IEND;
00149 00077      IF ML01144 == 0;
00150      " LORZ Torque 100%
00151 00078      MW15515 = 10000;
00152 00079      ELSE;
00153      " LOCZ Torque 100%
00154 00080      MW15510 = 10000
00155 00081      IEND;
00156
00157 00082      JOINTC LBL00X;
00158
00159 00083      LBL008:      " Scribe Torque(1st)
00160
00161 00084      IF DB00000 == 1      " Recipe Data
00162      " Scribe Start Torque Setting
00163 00085      IF MB15200D == 1;      " JustCutMode On
00164      " UPCZ
00165 00086      DL00002 = GL21496 + ML26520 + ML04864;
00166      " UPRZ
00167 00087      DL00004 = GL21496 + ML26544 + ML04866;
00168      " LOCZ
00169 00088      DL00006 = GL21496 + ML26532 + ML04868;
00170      " LORZ
00171 00089      DL00008 = GL21496 + ML26556 + ML04870;
00172 00090      ELSE;
00173 00091      IF MW15292 <> 0      " 1st 속도 UPCX

```

```

00174          " UPCZ
00175 00092          DL00002 = MW15246 + ML26520 + ML04864;
00176          " UPRZ
00177 00093          DL00004 = MW15246 + ML26544 + ML04866;
00178 00094      ELSE;
00179          " UPCZ
00180 00095          DL00002 = ML15256 + ML26520 + ML04864;
00181          " UPRZ
00182 00096          DL00004 = ML15258 + ML26544 + ML04866;
00183 00097      IEND;
00184 00098      IF MW15294 <> 0          " 1st 속도 LOCX
00185          " LOCZ
00186 00099          DL00006 = MW15248 + ML26532 + ML04868;
00187          " LORZ
00188 00100          DL00008 = MW15248 + ML26556 + ML04870;
00189 00101      ELSE;
00190          " LOCZ
00191 00102          DL00006 = ML15260 + ML26532 + ML04868;
00192          " LORZ
00193 00103          DL00008 = ML15262 + ML26556 + ML04870;
00194 00104      IEND;
00195 00105      IEND;
00196 00106      ELSE;          " Manual Data
00197          " UPCZ
00198 00107          DL00002 = ML15256 + ML26520 + ML04864;
00199          " UPRZ
00200 00108          DL00004 = ML15258 + ML26544 + ML04866;
00201          " LOCZ
00202 00109          DL00006 = ML15260 + ML26532 + ML04868;
00203          " LORZ
00204 00110          DL00008 = ML15262 + ML26556 + ML04870;
00205 00111      IEND;
00206
00207 00112      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00208 00113      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00209 00114      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00210 00115      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00211
00212      " Do Not Head Torque 100% Settir
00213 00116      IF ML01142 == 0;
00214          " UPRZ Torque 100%
00215 00117          MW15505 = 10000;
00216 00118      ELSE;
00217          " UPCZ Torque 100%
00218 00119          MW15500 = 10000
00219 00120      IEND;
00220 00121      IF ML01144 == 0;
00221          " LORZ Torque 100%
00222 00122          MW15515 = 10000;
00223 00123      ELSE;
00224          " LOCZ Torque 100%
00225 00124          MW15510 = 10000
00226 00125      IEND;
00227
00228 00126      JOINTC LBL00X;
00229
00230 00127      LBL009:      " Load Calibration Torque
00231
00232          " Load Offset Table Torque Value ( % )
00233 00128      UFC CM_TQTBL MW23694, MA91000[Load_Pos], DB00000F MW155
00234 00129      UFC CM_TQTBL MW23694, MA91600[Load_Pos], DB00000F MW155
00235 00130      UFC CM_TQTBL MW23694, MA92200[Load_Pos], DB00000F MW15510;
00236 00131      UFC CM_TQTBL MW23694, MA92800[Load_Pos], DB00000F MW155
00237
00238 00132      JOINTC LBL00X;
00239
00240 00133      LBL010:      " Offset Set Scribe Torque
00241
00242 00134          DL00002 = GL21142;
00243 00135          DL00004 = GL21142;
00244 00136          DL00006 = GL21142;
00245 00137          DL00008 = GL21142;
00246 00138          UFC CM_TRQ DL00002, MA91000, DB00000F MW15500;
00247 00139          UFC CM_TRQ DL00004, MA91600, DB00000F MW15505;
00248 00140          UFC CM_TRQ DL00006, MA92200, DB00000F MW15510;
00249 00141          UFC CM_TRQ DL00008, MA92800, DB00000F MW15515;
00250
00251 00142      JOINTC LBL00X;
00252
00253 00143      LBL011:      " Scribe Torque(3rd)
00254
00255          " UPCZ
00256 00144          DL00002 = ML15250 + ML26520 + ML04864;
00257          " UPRZ
00258 00145          DL00004 = ML15250 + ML26544 + ML04866;
00259          " LOCZ
00260 00146          DL00006 = ML15252 + ML26532 + ML04868;

```

```

00261      " LORZ
00262 00147      DL00008 = ML15252 + ML26556 + ML04870;
00263
00264 00148      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00265 00149      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00266 00150      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00267 00151      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00268
00269      " Do Not Head Torque 100% Settir
00270 00152      IF ML01142 == 0;
00271          " UPRZ Torque 100%
00272 00153          MW15505 = 10000;
00273 00154      ELSE;
00274          " UPCZ Torque 100%
00275 00155          MW15500 = 10000
00276 00156      IEND;
00277 00157      IF ML01144 == 0;
00278          " LORZ Torque 100%
00279 00158          MW15515 = 10000;
00280 00159      ELSE;
00281          " LOCZ Torque 100%
00282 00160          MW15510 = 10000
00283 00161      IEND;
00284
00285 00162      JOINTC LBL00X;
00286
00287 00163      LBL012:      " Scribe Torque(JustCut)
00288
00289          " UPCZ
00290 00164          DL00002 = GL21496 + ML26520 + ML04864;
00291          " UPRZ
00292 00165          DL00004 = GL21496 + ML26544 + ML04866;
00293          " LOCZ
00294 00166          DL00006 = GL21496 + ML26532 + ML04868;
00295          " LORZ
00296 00167          DL00008 = GL21496 + ML26556 + ML04870;
00297
00298 00168          UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00299 00169          UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00300 00170          UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00301 00171          UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00302
00303      " Do Not Head Torque 100% Settir
00304 00172      IF ML01142 == 0;
00305          " UPRZ Torque 100%
00306 00173          MW15505 = 10000;
00307 00174      ELSE;
00308          " UPCZ Torque 100%
00309 00175          MW15500 = 10000
00310 00176      IEND;
00311 00177      IF ML01144 == 0;
00312          " LORZ Torque 100%
00313 00178          MW15515 = 10000;
00314 00179      ELSE;
00315          " LOCZ Torque 100%
00316 00180          MW15510 = 10000
00317 00181      IEND;
00318
00319 00182      JOINTC LBL00X;
00320
00321 00183      LBL013:      " Wheel Change Align Torqu :
00322
00323 00184          IF ML26250 <> 0;
00324 00185              DL00010 = ML26250          " Wheel Change Align Torque
00325 00186      ELSE;
00326 00187          DL00010 = ML26400          " 0 Level Detection Torque
00327 00188      IEND;
00328
00329 00189      DL00002 = DL00010;
00330 00190      DL00004 = DL00010;
00331 00191      DL00006 = DL00010;
00332 00192      DL00008 = DL00010;
00333
00334 00193      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00335 00194      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00336 00195      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00337 00196      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00338
00339 00197      JOINTC LBL00X;
00340
00341 00198      LBL014:      " Scribe Torque(YCut Interpolation)
00342
00343          " UPCZ
00344 00199          DL00002 = GL21588 + ML26520 + ML04864;
00345          " UPRZ
00346 00200          DL00004 = GL21588 + ML26544 + ML04866;
00347          " LOCZ

```

```

00348 00201      DL00006 = GL21588 + ML26532 + ML04868;
00349           " LORZ
00350 00202      DL00008 = GL21588 + ML26556 + ML04870;
00351
00352 00203      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00353 00204      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00354 00205      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00355 00206      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00356
00357           " Do Not Head Torque 100% Settir
00358 00207      IF ML01142 == 0;
00359           " UPRZ Torque 100%
00360 00208          MW15505 = 10000;
00361 00209      ELSE;
00362           " UPCZ Torque 100%
00363 00210          MW15500 = 10000
00364 00211      IEND;
00365 00212      IF ML01144 == 0;
00366           " LORZ Torque 100%
00367 00213          MW15515 = 10000;
00368 00214      ELSE;
00369           " LOCZ Torque 100%
00370 00215          MW15510 = 10000
00371 00216      IEND;
00372
00373 00217      JOINTC LBL00X;
00374
00375 00218      LBL015:      " Scribe Torque(YCut)
00376
00377           " UPCZ
00378 00219      DL00002 = GL21586 + ML26520 + ML04864;
00379           " UPRZ
00380 00220      DL00004 = GL21586 + ML26544 + ML04866;
00381           " LOCZ
00382 00221      DL00006 = GL21586 + ML26532 + ML04868;
00383           " LORZ
00384 00222      DL00008 = GL21586 + ML26556 + ML04870;
00385
00386 00223      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00387 00224      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00388 00225      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00389 00226      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00390
00391           " Do Not Head Torque 100% Settir
00392 00227      IF ML01142 == 0;
00393           " UPRZ Torque 100%
00394 00228          MW15505 = 10000;
00395 00229      ELSE;
00396           " UPCZ Torque 100%
00397 00230          MW15500 = 10000
00398 00231      IEND;
00399 00232      IF ML01144 == 0;
00400           " LORZ Torque 100%
00401 00233          MW15515 = 10000;
00402 00234      ELSE;
00403           " LOCZ Torque 100%
00404 00235          MW15510 = 10000
00405 00236      IEND;
00406
00407 00237      JOINTC LBL00X;
00408
00409 00238      LBL016:      " Scribe Torque (JustCut Interpolation)
00410
00411           " UPCZ
00412 00239      DL00002 = GL21498 + ML26520 + ML04864;
00413           " UPRZ
00414 00240      DL00004 = GL21498 + ML26544 + ML04866;
00415           " LOCZ
00416 00241      DL00006 = GL21498 + ML26532 + ML04868;
00417           " LORZ
00418 00242      DL00008 = GL21498 + ML26556 + ML04870;
00419
00420 00243      UFC CM_TRQ DL00002, MA91000[Load_Tbl], DB00000F MW15500;
00421 00244      UFC CM_TRQ DL00004, MA91600[Load_Tbl], DB00000F MW15505;
00422 00245      UFC CM_TRQ DL00006, MA92200[Load_Tbl], DB00000F MW15510;
00423 00246      UFC CM_TRQ DL00008, MA92800[Load_Tbl], DB00000F MW15515;
00424
00425           " Do Not Head Torque 100% Settir
00426 00247      IF ML01142 == 0;
00427           " UPRZ Torque 100%
00428 00248          MW15505 = 10000;
00429 00249      ELSE;
00430           " UPCZ Torque 100%
00431 00250          MW15500 = 10000
00432 00251      IEND;
00433 00252      IF ML01144 == 0;
00434           " LORZ Torque 100%

```

```

00435 00253      MW15515 = 10000;
00436 00254      ELSE;
00437      " LOCZ Torque 100%
00438 00255      MW15510 = 10000
00439 00256      IEND;
00440
00441 00257      JOINTC LBL00X;
00442 00258      LBL00X: SJOINT;
00443
00444 00259      SFORK   DW00011 == 1  ? LBL101      " UPCZ
00445              DW00011 == 2  ? LBL102      " UPRZ
00446              DW00011 == 3  ? LBL103      " LOCZ
00447              DW00011 == 4  ? LBL104      " LORZ
00448              DW00011 == 5  ? LBL105      " UPCZ & LOCZ
00449              DW00011 == 6  ? LBL106      " UPRZ & LORZ
00450              DW00011 == 7  ? LBL107      " UPCZ & LORZ
00451              DW00011 == 8  ? LBL108      " UPRZ & LOCZ
00452              DW00011 == 9  ? LBL109      " ALL Z
00453              DEFAULT      ? LBL200;
00454
00455 00260      LBL101:      " UPCZ
00456
00457 00261      OLA114 = MW15500;
00458
00459 00262      JOINTC LBL1X;
00460
00461 00263      LBL102:      " UPRZ
00462
00463              " OL8294 = MW15505;
00464
00465 00264      JOINTC LBL1X;
00466
00467 00265      LBL103:      " LOCZ
00468
00469              " OL8414 = MW15510;
00470
00471 00266      JOINTC LBL1X;
00472
00473 00267      LBL104:      " LORZ
00474
00475              " OL8494 = MW15515;
00476
00477 00268      JOINTC LBL1X;
00478
00479 00269      LBL105:      " UPCZ & LOCZ
00480
00481 00270      OLA114 = MW15500;
00482      " OL8414 = MW15510;
00483
00484 00271      JOINTC LBL1X;
00485
00486 00272      LBL106:      " UPRZ & LORZ
00487
00488              " OL8294 = MW15505;
00489              " OL8494 = MW15515;
00490
00491 00273      JOINTC LBL1X;
00492
00493 00274      LBL107:      " UPCZ & LORZ
00494
00495 00275      OLA114 = MW15500;
00496      " OL8494 = MW15515;
00497
00498 00276      JOINTC LBL1X;
00499
00500 00277      LBL108:      " UPRZ & LOCZ
00501
00502              " OL8294 = MW15505;
00503              " OL8414 = MW15510;
00504
00505 00278      JOINTC LBL1X;
00506
00507 00279      LBL109:      " ALL Z
00508
00509 00280      OLA114 = MW15500;
00510      " OL8294 = MW15505;
00511      " OL8414 = MW15510;
00512      " OL8494 = MW15515;
00513
00514 00281      JOINTC LBL1X;
00515
00516 00282      LBL200:
00517 00283      JOINTO LBL1X;
00518 00284      LBL1X: SJOINT;
00519
00520 00285      RET;
00521

```

			MPS253 : CZ Torque Setting	P00007
--	--	--	----------------------------	--------