

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Table Vacuum-Blow Operation
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 00000 DW00010 = MW04846 " Table Vacuum Code
00021 00001 DW00012 = MW04848 " Table Floating Code
00022
00023 00002 DW00014 = MW04946 " Table Vacuum Code (Sub)
00024 00003 DW00016 = MW04948 " Table Floating Code (Sub)
00025
00026 00004 DW00002 = 0; " Fix Table Timer Setting
00027 00005 DW00004 = 0; " Cutting Table Timer Setting
00028 00006 DW00006 = 0; " Break Table Timer Setting
00029
00030 00007 IF DW00010 == 1;
00031 00008 IF MB09019F == 1 " Cutting Table Vacuum On Check
00032 00009 DW00010 = 10;
00033 00010 IEND;
00034 00011 IEND;
00035 00012 IF DW00010 == 2;
00036 00013 IF !MB09019F == 1 " Cutting Table Vacuum Off Check
00037 00014 DW00010 = 10;
00038 00015 IEND;
00039 00016 IEND;
00040 00017 IF DW00010 == 3;
00041 00018 IF MB05684F == 1 " Break Table Vacuum On Check
00042 00019 DW00010 = 10;
00043 00020 IEND;
00044 00021 IEND;
00045 00022 IF DW00010 == 4;
00046 00023 IF MB05685F == 1 " Break Table Vacuum Off Check
00047 00024 DW00010 = 10;
00048 00025 IEND;
00049 00026 IEND;
00050 00027 IF DW00010 == 5;
00051 00028 IF MB09019F & MB05684F == 1 " Cutting Table Vacuum On Check, Bre
ak Table Vacuum On Check
DW00010 = 10;
IEND;
00052 00029 IEND;
00053 00030 IEND;
00054 00031 IF DW00010 == 6;
00055 00032 IF !MB09019F & MB05685F == 1 " Cutting Table Vacuum Off Check, Br
eak Table Vacuum Off Check
DW00010 = 10;
IEND;
00056 00033 IEND;
00057 00034 IF DW00010 == 7;
00058 00035 IF MB05684F & MB09023F == 1 " Break Table Vacuum On Check, Cutti
ng Table Vacuum Off Check
DW00010 = 10;
IEND;
00059 00036 IEND;
00060 00037 IF DW00010 == 8;
00061 00038 IF MB05585F & MB09019F == 1 " Break Table Vacuum On Check, Cutti
ng Table Vacuum Off Check
DW00010 = 10;
IEND;
00062 00039 IEND;
00063 00040 IF DW00012 == 1;
00064 00041 IF MB09027F | MB00800 | MB000808 == " Cutting Table Blow On Check
00065 00042 IEND;
00066 00043 IEND;
00067 00044 IF DW00012 == 2;
00068 00045 IF MB09031F == 1 " Cutting Table Blow Off Check
00069 00046 DW00012 = 10;
00070 00047 IEND;
00071 00048 IEND;
00072 00049 IF DW00012 == 3;
00073 00050 IF MB05686F == 1 " Break Table Blow On Check
00074 00051 DW00012 = 10;
00075 00052 IEND;
00076 00053 IEND;
00077 00054 IF DW00012 == 3;
00078 00055 IF MB05686F == 1 " Break Table Blow On Check
00079 00056 DW00012 = 10;
00080 00057 IEND;
00081 00058 IEND;
00082 00059 IEND;
00083 00060 IEND;

```

```

00084 00061      IF DW00012 == 4;
00085 00062          IF MB05687F== 1;                                " Break Table Blow Off Check
00086 00063              DW00012 = 10;
00087 00064          IEND;
00088 00065      IEND;
00089 00066      IF DW00012 == 5;
00090 00067          IF MB09027F & MB05686F == 1;                        " Cutting Table Blow On Check
00091 00068              DW00012 = 10;
00092 00069          IEND;
00093 00070      IEND;
00094 00071      IF DW00012 == 6;
00095 00072          IF MB09031F & MB05687F == 1;                        " Cutting Table Blow Off Check
00096 00073              DW00012 = 10;
00097 00074          IEND;
00098 00075      IEND;
00099 00076      IF DW00014 == 1;
00100 00077          IF MB09018F == 1;                                    " Fix Table Vacuum On Check
00101 00078              DW00014 = 10;
00102 00079          IEND;
00103 00080      IEND;
00104 00081      IF DW00014 == 2;
00105 00082          IF MB09022F == 1;                                    " Fix Table Vacuum Off Check
00106 00083              DW00014 = 10;
00107 00084          IEND;
00108 00085      IEND;
00109 00086      IF DW00016 == 1;
00110 00087          IF MB09027E == 1;                                    " Fix Table Blow On Check
00111 00088              DW00016 = 10;
00112 00089          IEND;
00113 00090      IEND;
00114 00091      IF DW00016 == 2;
00115 00092          IF MB09031E == 1;                                    " Fix Table Blow Off Check
00116 00093              DW00016 = 10;
00117 00094          IEND;
00118 00095      IEND;
00119
00120 00096      IF DW00014 == 1;
00121 00097          " [Action] Fix Table Vacuum On
00122 00098          IF !MB09018F == 1;
00123 00099              " Fix Table Vacuum On
00124 00096              MB09048F = 1;                                    " Fix Table Vacuum On Reques
00125 00099          IEND;
00126 00100      IEND;
00127 00101      IF DW00014 == 2;
00128 00102          " [Action] Fix Table Vacuum On
00129 00102          IF !MB09022F == 1;
00130 00103              " Fix Table Vacuum On
00131 00103              MB09052F = 1;                                    " Fix Table Vacuum Off Reques
00132 00104          IEND;
00133 00105      IEND;
00134 00106      IF DW00016 == 1;
00135 00107          " [Action] Fix Table Blow On
00136 00107          IF !MB09027E == 1;
00137 00108              " Fix Table Blow On
00138 00108              MB09057E = 1;                                    " Fix Table Blow On Reques
00139 00109          IEND;
00140 00110      IEND;
00141 00111      IF DW00016 == 2;
00142 00112          " [Action] Fix Table Blow Off
00143 00112          IF !MB09031E == 1;
00144 00113              " Fix Table Blow Off
00145 00113              MB09061E = 1;                                    " Fix Table Blow Off Reques
00146 00114          IEND;
00147 00115      IEND;
00148
00149 00116      PFORK Line01 Line02;
00150
00151          Line01:
00152              " Table Vacuun Type Select
00153 00117              IOW DW00010 <> 0;
00154
00155 00118              SFORK      DW00010 == 01 ? LBL01      " [Cutting] Table Vacuum On
00156 00118                  DW00010 == 02 ? LBL02      " [Cutting] Table Vacuum Off
00157 00118                  DW00010 == 03 ? LBL03      " [Break] Table Vacuum On
00158 00118                  DW00010 == 04 ? LBL04      " [Break] Table Vacuum Off
00159 00118                  DW00010 == 05 ? LBL05      " [Cutting, Break] Table Vacuum On
00160 00118                  DW00010 == 06 ? LBL06      " [Cutting, Break] Table Vacuum O
00161
00161                  DW00010 == 07 ? LBL07      " [Cutting] Table Vacuum Off, [Break] Table Vacuum O
00162
00162                  DW00010 == 08 ? LBL08      " [Cutting] Table Vacuum On, [Break] Table Vacuum Of
00163
00163                  DEFAULT      ? LBL100;
00164
00165 00119              LBL01:
00166 00119                  " [Action] Cutting Table Vacuum On
00167 00120                  IF !MB09019F == 1;

```

```

00168          " Cutting Table Vacuum On
00169 00121      MB09049F = 1;          " Cutting Table Vacuum On Re

quest
00170 00122      IEND;
00171 00123      IOW MB09019F | MB00800 | MB000808 ==      " Cutting Table Vacuum On Ch

eck
00172 00124      TIM TMW26206;
00173
00174          " Fix Table Timer Setting
00175 00125      DW00002 = 1;
00176 00126      JOINTO LBL0X;
00177
00178 00127      LBL02:
00179          " [Action] Cutting Table Vacuum Off
00180 00128      IF !MB09023F == 1;
00181          " Cutting Table Vacuum Off
00182 00129      MB09053F = 1;          " Cutting Table Vacuum Off R

equest
00183 00130      IEND;
00184 00131      IOW !MB09019F | MB00800 | MB000808 ==      " Cutting Table Vacuum Off C

heck
00185 00132      TIM TMW26206;
00186
00187          " Fix Table Timer Setting
00188 00133      DW00002 = 1;
00189 00134      JOINTO LBL0X;
00190
00191 00135      LBL03:
00192          " [Action] Break Table Vacuum On
00193 00136      IF !MB05684F == 1          " Break Table Vacuum On Stat

us
00194          " Break Table Vacuum On
00195 00137      MB05584F = 1;          " Break Table Vacuum On Requ

est
00196 00138      IEND;
00197 00139      IOW MB05684F | MB00800 | MB000808 ==      " Break Table Vacuum On Chec

k
00198 00140      TIM TMW26202;
00199
00200          " Fix Table Timer Setting
00201 00141      DW00002 = 2;
00202 00142      JOINTO LBL0X;
00203
00204 00143      LBL04:
00205          " [Action] Break Table Vacuum Off
00206 00144      IF !MB05685F == 1          " Break Table Vacuum Off Sta

tus
00207          " Break Table Vacuum Off
00208 00145      MB05585F = 1;          " Break Table Vacuum Off Req

uest
00209 00146      IEND;
00210 00147      IOW MB05685F | MB00800 | MB000808 ==      " Break Table Vacuum Off Che

ck
00211 00148      TIM TMW26202;
00212
00213          " Fix Table Timer Setting
00214 00149      DW00002 = 2;
00215 00150      JOINTO LBL0X;
00216
00217 00151      LBL05:
00218          " [Action] Cutting Table Vacuum On
00219 00152      IF !MB046889 | !MB09019F == 1;
00220          " Cutting Table Vacuum On
00221 00153      MB09049F = 1;          " Cutting Table Vacuum On Re

quest
00222 00154      IEND;
00223
00224          " [Action] Break Table Vacuum On
00225 00155      IF !MB05684F == 1          " Break Table Vacuum On Stat

us
00226          " Break Table Vacuum On
00227 00156      MB05584F = 1;          " Break Table Vacuum On Requ

est
00228 00157      IEND;
00229
00230 00158      IF GL21158 > MW15411;
00231 00159      IOW MB09019F | MB00800 | MB000808 ==      " Cutting Table Vacuum On Ch

eck
00232 00160      IEND;
00233 00161      IF MW04511 <> 3;
00234 00162      IOW MB09019F | MB00800 | MB000808 ==      " Cutting Table Vacuum On Ch

eck
00235 00163      IEND;
00236 00164      IOW MB05684F | MB00800 | MB000808 ==      " Break Table Vacuum On Chec

k
00237
00238 00165      IF MW26202 >= MW26206;

```

```

00239 00166          TIM TMW26202;
00240 00167      ELSE;
00241 00168          TIM TMW26206;
00242 00169      IEND;
00243
00244          " Fix Table Timer Setting
00245 00170      DW00002 = 3;
00246
00247 00171      JOINTO LBL0X;
00248
00249 00172      LBL06:
00250          " [Action] Cutting Table Vacuum Off
00251 00173      IF !MB09023F == 1;
00252          " Cutting Table Vacuum Off
00253 00174          MB09053F = 1;          " Cutting Table Vacuum Off R
equest
00254 00175      IEND;
00255
00256          " [Action] Break Table Vacuum Off
00257 00176      IF !MB05685F == 1          " Break Table Vacuum Off Sta
tus
00258          " Break Table Vacuum Off
00259 00177      MB05585F = 1;          " Break Table Vacuum Off Req
uest
00260 00178      IEND;
00261
00262 00179      IOW !MB09019F | MB00800 | MB000808 ==          " Cutting Table Vacuum Off C
heck
00263 00180      IOW MB05685F | MB00800 | MB000808 ==          " Break Table Vacuum Off Che
ck
00264 00181      IF MW26202 >= MW26206;
00265 00182          TIM TMW26202;
00266 00183      ELSE;
00267 00184          TIM TMW26206;
00268 00185      IEND;
00269
00270          " Fix Table Timer Setting
00271 00186      DW00002 = 3;
00272
00273 00187      JOINTO LBL0X;
00274
00275 00188      LBL07:
00276          " [Action] Break Table Vacuum On
00277 00189      IF !MB05684F == 1          " Break Table Vacuum On Stat
us
00278          " Break Table Vacuum On
00279 00190      MB05584F = 1;          " Break Table Vacuum On Requ
est
00280 00191      IEND;
00281          " [Action] Cutting Table Vacuum Off
00282 00192      IF !MB09023F == 1;
00283          " Cutting Table Vacuum Off
00284 00193      MB09053F = 1;          " Cutting Table Vacuum Off R
equest
00285 00194      IEND;
00286
00287 00195      IOW MB05684F | MB00800 | MB000808 ==          " Break Table Vacuum On Chec
k
00288 00196      IOW MB09023F | MB00800 | MB000808 ==          " Cutting Table Vacuum Off C
heck
00289 00197      IF MW26202 >= MW26206;
00290 00198          TIM TMW26202;
00291 00199      ELSE;
00292 00200          TIM TMW26206;
00293 00201      IEND;
00294
00295          " Fix Table Timer Setting
00296 00202      DW00002 = 3;
00297
00298 00203      JOINTO LBL0X;
00299
00300 00204      LBL08:
00301          " [Action] Break Table Vacuum Off
00302 00205      IF !MB05685F == 1          " Break Table Vacuum Off Sta
tus
00303          " Break Table Vacuum Off
00304 00206      MB05585F = 1;          " Break Table Vacuum Off Req
uest
00305 00207      IEND;
00306          " [Action] Cutting Table Vacuum On
00307 00208      IF !MB09019F == 1;
00308          " Cutting Table Vacuum On
00309 00209      MB09049F = 1;          " Cutting Table Vacuum On Re
quest
00310 00210      IEND;
00311
00312 00211      IOW MB05585F | MB00800 | MB000808 ==          " Break Table Vacuum On Chec

```

```

k
00313 00212      IOW MB09019F | MB00800 | MB000808 ==      " Cutting Table Vacuum Off C
heck
00314 00213      IF MW26202 >= MW26206;
00315 00214          TIM TMW26202;
00316 00215      ELSE;
00317 00216          TIM TMW26206;
00318 00217      IEND;
00319
00320          " Fix Table Timer Setting
00321 00218      DW00002 = 3;
00322 00219      JOINTO LBL0X;
00323
00324 00220      LBL100:
00325 00221          JOINTO LBL0X;
00326 00222      LBL0X: SJOINT;
00327
00328 00223      JOINTO Label0X;
00329
00330      Line02:
00331          " Table Blow Motion Type Sele
00332 00224      IOW DW00012 <> 0;
00333
00334 00225      SFORK    DW00012 == 01 ? LBL21      " [Cutting] Table Blow On
00335          DW00012 == 02 ? LBL22      " [Cutting] Table Blow Off
00336          DW00012 == 03 ? LBL23      " [Break] Table Blow On
00337          DW00012 == 04 ? LBL24      " [Break] Table Blow Off
00338          DW00012 == 05 ? LBL25      " [Cutting, Break] Table Blow On
00339          DW00012 == 06 ? LBL26      " [Cutting, Break] Table Blow Off
00340          DW00012 == 07 ? LBL27      "
00341          DW00012 == 08 ? LBL28      "
00342          DEFAULT ? LBL102;
00343
00344 00226      LBL21:
00345          " Cutting Table Blow On
00346 00227      MB09057F = 1;      " Cutting Table Blow On Requ
est
00347 00228      IOW MB09027F | MB00800 | MB000808 ==      " Cutting Table Blow On Chec
k
00348 00229      TIM TMW26216;
00349
00350          " Cutting Table Timer Setting
00351 00230      DW00004 = 1;
00352 00231      JOINTO LBL2X;
00353
00354 00232      LBL22:
00355          " Cutting Table Blow Off
00356 00233      MB09061F = 1;      " Cutting Table Blow Off Requ
uest
00357 00234      IOW MB09031F | MB00800 | MB000808==      " Cutting Table Blow Off Che
ck
00358 00235      TIM TMW26216;
00359
00360          " Fix Table Timer Setting
00361 00236      DW00004 = 1;
00362
00363 00237      JOINTO LBL2X;
00364
00365 00238      LBL23:
00366          " Break Table Blow On
00367 00239      MB05586F = 1;      " Break Table Blow On Reques
t
00368 00240      IOW MB05686F | MB00800 | MB000808 ==      " Break Table Blow On Chec
00369 00241      TIM TMW26212;
00370
00371          " Fix Table Timer Setting
00372 00242      DW00004 = 2;
00373 00243      JOINTO LBL2X;
00374
00375 00244      LBL24:
00376          " Break Table Blow Off
00377 00245      MB05587F = 1;      " Break Table Blow Off Reque
st
00378 00246      IOW MB05687F | MB00800 | MB000808==      " Break Table Blow Off Check
00379 00247      TIM TMW26212;
00380
00381          " Fix Table Timer Setting
00382 00248      DW00004 = 2;
00383 00249      JOINTO LBL2X;
00384
00385 00250      LBL25:
00386          " Cutting Table Blow On
00387 00251      MB09057F = 1;      " Cutting Table Blow On Requ
est
00388
00389          " Break Table Blow On

```

```

00390 00252          MB05586F = 1;                                " Break Table Blow On Reques
t
00391
00392 00253          IOW MB09027F | MB00800 | MB000808 ==      " Cutting Table Blow On Chec
k
00393 00254          IOW MB05686F | MB00800 | MB000808 ==      " Break Table Blow On Check
00394
00395 00255          IF MW26202 >= MW26206;
00396 00256              TIM TMW26212;
00397 00257          ELSE;
00398 00258              TIM TMW26216;
00399 00259          IEND;
00400
00401          " Fix Table Timer Setting
00402 00260          DW00004 = 3;
00403 00261          JOINTO LBL2X;
00404
00405 00262          LBL26:
00406          " Cutting Table Blow Off
00407 00263          MB09061F = 1;                                " Cutting Table Blow Off Req
uest
00408
00409          " Break Table Blow Off
00410 00264          MB05587F = 1;                                " Break Table Blow Off Reque
st
00411
00412 00265          IOW MB09031F | MB00800 | MB000808 ==      " Cutting Table Blow Off Che
ck
00413 00266          IOW MB05687F | MB00800 | MB000808 ==      " Break Table Blow Off Check
00414 00267          IF MW26202 >= MW26206;
00415 00268              TIM TMW26212;
00416 00269          ELSE;
00417 00270              TIM TMW26216;
00418 00271          IEND;
00419
00420          " Fix Table Timer Setting
00421 00272          DW00004 = 3;
00422
00423 00273          JOINTO LBL2X;
00424
00425 00274          LBL27:
00426 00275              JOINTO LBL2X;
00427
00428 00276          LBL28:
00429 00277              JOINTO LBL2X;
00430
00431
00432 00278          LBL102:
00433 00279              JOINTO LBL2X;
00434 00280          LBL2X: SJOINT;
00435
00436 00281          JOINTO Label0X;
00437 00282          Label0X: PJOINT;
00438
00439 00283          IF DW00014 == 1;
00440          " [Action] Fix Table Vacuum On
00441 00284          IOW MB09018F | MB00800 | MB000808 ==      " Fix Table Vacuum On Check
00442 00285          IEND;
00443 00286          IF DW00014 == 2;
00444          " [Action] Fix Table Vacuum On
00445 00287          IOW MB09022F | MB00800 | MB000808 ==      " Fix Table Vacuum Off Check
00446 00288          IEND;
00447 00289          IF DW00016 == 1;
00448          " [Action] Fix Table Blow On
00449 00290          IOW MB09027E | MB00800 | MB000808 ==      " Fix Table Blow On Check
00450 00291          IEND;
00451 00292          IF DW00016 == 2;
00452          " [Action] Fix Table Blow Off
00453 00293          IF CW00099 == 1;
00454          //          IOW MB09031E | MB00800 | MB000808 ==      " Fix Table Blow Off Check
00455          ELSE;
00456 00295          IOW MB09031E | MB00800 | MB000808 ==      " Fix Table Blow Off Check
00457 00296          IEND;
00458 00297          IEND;
00459
00460 00298          IF DW00014 <> 10;                                " Fix Table Vacuum Not Command
00461 00299          IF DW00016 <> 10                                " Fix Table Blow Not Command
00462 00300          IF MW26200 >= MW26210                        " Fix Table Vacuum - Blow Delay Chec
k
00463 00301          DW00006 = 1;                                " Vacuum Delay Command
00464 00302          ELSE;
00465 00303          DW00006 = 2;                                " Blow Delay Command
00466 00304          IEND;
00467 00305          ELSE;
00468 00306          DW00006 = 1;                                " Vacuum Delay Command
00469 00307          IEND;

```

```

00470 00308     ELSE;
00471 00309         IF DW00016 <> 10                " Fix Table Blow Not Command
00472 00310             DW00006 = 2;                " Blow Delay Command
00473 00311     ELSE;
00474 00312         DW00006 = 0;                " Fix Table Vacuum and Blow Not Comm
and
00475 00313         IEND;
00476 00314     IEND;
00477
00478 00315     IF DW00006 == 1                " Vacuum Delay Command
00479 00316         IF DW00010 == 10;
00480 00317             TIM TMW26200;                " Fix Table Vacuum Delay
00481 00318     ELSE;
00482 00319         IF DW00002 == 1                " Cutting Vacuum Command
00483 00320             IF MW26200 > MW26202;
00484 00321                 DW00020 = MW26200 - MW26202;                " Fix Table Vacuum Delay - Cutting T
able Vacuum Delay
00485 00322             TIM TDW00020;
00486 00323         IEND;
00487 00324     IEND;
00488 00325         IF DW00002 == 2                " Break Vacuum Command
00489 00326             IF MW26200 > MW26206;
00490 00327                 DW00020 = MW26200 - MW26206;                " Fix Table Vacuum Delay - Break Tab
le Vacuum Delay
00491 00328             TIM TDW00020;
00492 00329         IEND;
00493 00330     IEND;
00494 00331         IF DW00002 == 3                " Cutting, Break Vacuum Command
00495 00332             IF MW26202 > MW26206;
00496 00333                 IF MW26200 > MW26202;
00497 00334                     DW00020 = MW26200 - MW26202;                " Fix Table Vacuum Delay - Cutting T
able Vacuum Delay
00498 00335             TIM TDW00020;
00499 00336         IEND;
00500 00337     ELSE;
00501 00338         IF MW26200 > MW26206;
00502 00339             DL00020 = MW26200 - MW26206;                " Fix Table Vacuum Delay - Break Tab
le Vacuum Delay
00503 00340             TIM TDW00020;
00504 00341         IEND;
00505 00342     IEND;
00506 00343         IEND;
00507 00344     IEND;
00508 00345         IEND;
00509
00510 00346         IF DW00006 == 2                " Blow Delay Command
00511 00347             IF DW00010 == 10;
00512 00348                 TIM TMW26210;                " Fix Table Blow Delay
00513 00349         ELSE;
00514 00350             IF DW00004 == 1                " Cutting Blow Command
00515 00351                 IF MW26210 > MW26212;
00516 00352                     DW00020 = MW26210 - MW26212;                " Fix Table Blow Delay - Cutting Tab
le Blow Delay
00517 00353             TIM TDW00020;
00518 00354         IEND;
00519 00355     IEND;
00520 00356         IF DW00004 == 2                " Break Blow Command
00521 00357             IF MW26210 > MW26216;
00522 00358                 DW00020 = MW26210 - MW26216;                " Fix Table Blow Delay - Break Table
Blow Delay
00523 00359             TIM TDW00020;
00524 00360         IEND;
00525 00361     IEND;
00526 00362         IF DW00004 == 3                " Cutting, Break Blow Command
00527 00363             IF MW26212 > MW26216;
00528 00364                 IF MW26210 > MW26212;
00529 00365                     DW00020 = MW26210 - MW26212;                " Fix Table Blow Delay - Cutting Tab
le Blow Delay
00530 00366             TIM TDW00020;
00531 00367         IEND;
00532 00368     ELSE;
00533 00369         IF MW26210 > MW26216;
00534 00370             DL00020 = MW26210 - MW26216;                " Fix Table Blow Delay - Break Table
Blow Delay
00535 00371             TIM TDW00020;
00536 00372         IEND;
00537 00373     IEND;
00538 00374         IEND;
00539 00375     IEND;
00540 00376         IEND;
00541
00542 00377     RET;

```