

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Pusher Bar Receive Before (Unuse)
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKPB1 = 64;
00018 00001 LONG IDX_BKPB2 = 65;
00019 00002 LONG IDX_BKPBZ1 = 66;
00020 00003 LONG IDX_BKPBZ2 = 67;
00021 END_VAR;
00022
00023 00004 MSEE MPS270; " Break Pusher Bar Speed, Position Updat
e Set
00024
00025 " Break Pusher Bar Y Standby Position Safe Area
00026 00005 DL00020 = ML72802 - 1000 " Break Pusher Bar Y Don't Interference
Position
00027 00006 DL00022 = ML73202 - 1000 " Break Pusher Bar T Don't Interference
- Limit Positio:
00028
00029 00007 DW00002 = 0;
00030 00008 DB00010 = 0;
00031 00009 WHILE DB00010 == 0;
00032 00010 EOX;
00033 " Break Pusher Bar Y Don't Interference
00034 00011 IF ILB016 > DL00020;
00035 00012 DB00020 = 1;
00036 00013 IEND;
00037
00038 " Break Pusher Bar Z Don't Interference
00039 00014 IF ILB116 > DL00022;
00040 00015 DB00021 = 1;
00041 00016 IEND;
00042
00043 " Break Pusher Bar & Break Table Don't Comma i
00044 00017 DB00023 = 1;
00045
00046 00018 IF DB00020 & DB00021 & DB00023 == 1;
00047 00019 DB00010 = 1;
00048 00020 IEND;
00049 00021 WEND;
00050
00051 " Break Pusher Bar No Commanc
00052 00022 IOW MB050694 == 1;
00053
00054 " Cutter X Standby Position
00055 00023 IOW MB046000 == 1;
00056
00057 00024 IOW MB050790 & MB050791 == 1 " Break Pusher Bar Interference Che
00058
00059 00025 IF MB000023 == 1;
00060 00026 MB045159 = 1; " Step Mode Next Fla
00061 00027 IOW (!MB21684D | MB20544E) | MB045013 == " Step Mode
00062 00028 MB045159 = 0; " Step Mode Next Fla
00063 00029 IEND;
00064
00065 00030 MSEE MPS270; " Break Pusher Bar Speed, Position Updat
e Set
00066
00067 00031 IOW MB050761 == 1 " Break Pusher Bar Y Receive Before Posi
tion Moving Permission
00068
00069 00032 ML16128 = ML72806 " Break Pusher Bar Moving Y Position Wri
te
00070 00033 ML16132 = ML73206 " Break Pusher Bar Moving Z Position Wri
te
00071
00072 00034 MOV [BKPB1]ML16128 [BKPB2]ML16128 [BKPBZ1]ML16132 [BKPBZ2]ML16132;
00073
00074 00035 RET;

```