

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Pusher Bar Clean Start
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKPB1 = 64;
00018 00001 LONG IDX_BKPB2 = 65;
00019 00002 LONG IDX_BKPBZ1 = 66;
00020 00003 LONG IDX_BKPBZ2 = 67;
00021 END_VAR;
00022
00023 00004 MSEE MPS270; " Break Pusher Bar Speed, Position Updat
e Set
00024
00025 " Break Pusher Bar No Commanc
00026 00005 IOW MB050694 == 1;
00027
00028 " Head X Wait
00029 //IOW MB045741 == 1;
00030
00031 " SCHY Non Interference Check
00032 00006 DL00020 = ML27820 + ML72802 - ML27826;
00033 00007 IOW ILA816 < DL00020;
00034
00035 " Inner Bit Reset
00036 00008 DW00001 = 0;
00037 00009 PFORK BKPB1 BKPBZ1;
00038
00039 BKPB1:
00040
00041 00010 ML16128 = ML72842 " BKPB1 Clean Start Positic
00042
00043 00011 IOW MB5076A == 1 " Break Puhser Bar Y Clean Start Positio
n Moving Permissio
00044
00045 00012 MOV [BKPB1]ML16128 [BKPB2]ML1612; " Break Puhser Bar Y Pos. Movir
00046 00013 IOW MB5100A == 1 " Break Puhser Bar Y Clean Start Positio
n Complete Chec
00047
00048 00014 JOINTO LabelX;
00049
00050 BKPBZ1:
00051 " Break Pusher Bar Z
00052
00053 // IF !MB090102 | !MB090103 == 1;
00054 // " Cutting Table Brush Brush Down Status
00055 // MB090442 = 0;
00056 // MB090443 = 0;
00057 //// TIM T100;
00058 // MB090402 = 1;
00059 // MB090403 = 1;
00060 // IOW MB090102 & MB090103 == 1;
00061 // IEND;
00062
00063 " Cutting Table Brush Down Status
00064 00015 IF !MB09010E == 1;
00065 " Cutting Table Brush Brush Down Status
00066 00016 MB09044E = 0;
00067 00017 MB09040E = 1;
00068 00018 IOW MB09010E == 1;
00069 00019 IEND;
00070
00071 "Break Pusher Bar Z Clean Position
00072 00020 ML16132 = ML73242 " Break Puhser Bar Z1 Moving Position Wr
ite
00073
00074 00021 IOW MB05077A == 1
00075 00022 MOV [BKPBZ1]ML16132 [BKPBZ2]ML1613; " Break Puhser Bar Z Pos. Moving
00076 00023 IOW MB05102A == 1 " Break Puhser Bar Z Clean Position Comp
lete Check
00077
00078 00024 JOINTO LabelX;
00079
00080 00025 LabelX: PJOINT;
00081

```

P00002 MPS272 : Break Pusher Bar Clean Start

00082 00026 RET;

			MPS272 : Break Pusher Bar Clean Start	P00002
--	--	--	---------------------------------------	--------