

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Table Execute
00011 "# Function :
00012 "# Call Program : MPM05
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKTY1 = 69;
00018 00001 LONG IDX_BKTY2 = 70;
00019 00002 LONG IDX_BKTZ1 = 72;
00020 00003 LONG IDX_BKTZ2 = 73;
00021 00004 LONG IDX_BKTZ3 = 74;
00022 00005 LONG IDX_BKTT1 = 75;
00023 00006 LONG IDX_BKTT2 = 76;
00024 END_VAR;
00025
00026 00007 MSEE MPS310; " Break Table Speed, Position Update Set
00027
00028 " Table Break Interloc
00029 00008 DW00004 = 0;
00030 00009 DB00012 = 0;
00031 00010 WHILE DB00012 == 0;
00032 00011 EOX;
00033 " Table Break Y Don't Interference
00034 00012 IF MB056003 | (CB000130 & MB046084) == 1;
00035 00013 DB00041 = 1;
00036 00014 IEND;
00037 00015 IF DB00041 == 1;
00038 00016 DB00012 = 1;
00039 00017 IEND;
00040 00018 WEND;
00041
00042 " Head X Waiting Position
00043 // IOW MB045741 == 1;
00044
00045 " CZ Waiting Position
00046 00019 IOW MB045740 | MB045740 == 1;
00047
00048 00020 IF MB000023 == 1;
00049 00021 MB045159 = 1; " Step Mode Next Fla
00050 00022 IOW (!MB21684D | MB20544E) | MB045013 == " Step Mode
00051 00023 MB045159 = 0; " Step Mode Next Fla
00052 00024 IEND;
00053
00054 " Break Table Vacuum On
00055 00025 IF !MB05684F | !MB09019F == 1:
00056 00026 MB05584F = 1; " Break Table Vacuum On
00057 00027 MB09049F = 1; " Cutting Table Vacuum On
00058 00028 IOW MB05684F | MB00800 == 1 " Break Table Vacuum On Check
00059 00029 IOW MB09019F | MB00800 == 1 " Cutting Table Vacuum On Check
00060 00030 TIM TMW26202; " Break Table Vacuum On Delay Time
00061 00031 IEND;
00062
00063 00032 IOW MB05684F | MB00800 == 1 " Break Table Vacuum On Check
00064 00033 IOW MB09019F | MB00800 == 1 " Cutting Table Vacuum On Check
00065
00066 " Interlock
00067 00034 IOW MB055764 & MB055774 == 1;
00068
00069 " Parameter Readin
00070 " [RECIPE] Break Degree Data Setting
00071 00035 DF00000 = ML5940 / 1000;
00072 " [RECIPE] Break Acc Data Setting
00073 00036 DL00060 = ML5934;
00074 " [RECIPE] Break Dcc Data Setting
00075 00037 DL00062 = ML5932;
00076 " [RECIPE] Break Speed Data Setting
00077 00038 DL00064 = ML5930;
00078
00079 " [Parameter] Deg Center ~ Break Table Upper + Break Table Exposure Volume
00080 00039 DL00002 = ML27620 + ML05812 + GL25022;
00081
00082 " Y Moving Volume
00083 00040 DF00030 = DL00002 * COS(DF00000);
00084 00041 DL00032 = DL00002 - DF00030;
00085
00086 00042 IF DF00000 < 0;
00087 00043 DF00034 = ML27622 * SIN(DF00000);

```

```

00088 00044      DL00036 = DF00034;
00089 00045      ELSE;
00090 00046      DF00034 = (GL21004 + ML27622) * SIN(DF00000);
00091 00047      DL00036 = DF00034;
00092 00048      IEND;
00093
00094      // IF ML05936 < 0;
00095      //      ML05936 = 0;
00096      // IEND;
00097
00098      // DL00020 = ML73814 + DL00032 + DL00036 + ML05936;
00099      // DL00020 = ML73814 - DL00032 + DL00036;
00100 00049      DL00020 = ML73814 - DL00032 + DL00036 + ML05936;      "2024.12.06 Add By YMW
00101
00102      // IF CW00013 == 1;
00103      //      DL00054 = ML01168 - ML01164;      "Break Pos Moving Volume
00104      //      DL00020 = ML73814 + DL00032 + DL00036 + ML05936 + DL00054;
00105      // IEND;
00106
00107      " Z Moving Valume
00108 00050      IF DF00000 < 0;
00109 00051      DF00040 = DL00002 * SIN(DF00000);
00110 00052      DL00042 = DF00040;
00111
00112 00053      DF00044 = ML27622 * COS(DF00000);
00113 00054      DL00046 = ML27622 - DF00044;
00114 00055      ELSE;
00115 00056      DF00040 = DL00002 * SIN(DF00000);
00116 00057      DL00042 = DF00040;
00117
00118 00058      DF00044 = (GL21004 + ML27622) * COS(DF00000);
00119 00059      DL00046 = (GL21004 + ML27622) - DF00044;
00120 00060      IEND;
00121
00122      // DL00022 = ML74414 + DL00042 + DL00046 + ML05938;
00123 00061      DL00022 = ML74414 + DL00042 + DL00046;
00124
00125      " T Moving Valume
00126 00062      DL00006 = ML05940 * ML27626;
00127 00063      DL00024 = ML75014 + (DL00006 / 1000);
00128
00129      " Break Table Y,Z,T Max Speed Reading
00130 00064      DL00070 = ML10800[IDX_BKTT1]
00131 00065      DL00072 = DL00070 / 60 / DL00060 * 100
00132 00066      DL00074 = DL00070 / 60 / DL00062 * 1000;
00133
00134      " Acc Set Data < 10 mm/s^2 ==> 10 mm/s^2 Force Sett:ng
00135 00067      IF DL00072 < 10;
00136 00068      DL00072 = 10;
00137 00069      IEND;
00138 00070      IF DL00072 > 32767;
00139 00071      DL00072 = 32767;
00140 00072      IEND;
00141      " Dcc Set Data < 10 mm/s^2 ==> 10 mm/s^2 Force Sett:ng
00142 00073      IF DL00074 < 10;
00143 00074      DL00074 = 10;
00144 00075      IEND;
00145 00076      IF DL00074 > 32767;
00146 00077      DL00074 = 32767;
00147 00078      IEND;
00148
00149      " Break Table Speed Calc
00150 00079      DL00080 = DL00020 - ILB296;
00151 00080      DL00082 = ILB416 - DL00022;
00152 00081      DL00084 = DL00024 - ILB596;
00153
00154 00082      DF00090 = DL00080 * DL00080;
00155 00083      DF00092 = DL00082 * DL00082;
00156 00084      DF00094 = DL00084 * DL00084;
00157
00158 00085      DF00096 = DF00090 + DF00092 + DF00094 + DF00095
00159 00086      DF00098 = SQT(DF00096);
00160
00161 00087      IF DF00090 >= DF00094;
00162 00088      IF DF00090 >= DF00092;
00163 00089      DF00050 = DF00090;
00164 00090      ELSE;
00165 00091      DF00050 = DF00092;
00166 00092      IEND;
00167 00093      ELSE;
00168 00094      IF DF00094 >= DF00092;
00169 00095      DF00050 = DF00094;
00170 00096      ELSE;
00171 00097      DF00050 = DF00092;
00172 00098      IEND;
00173 00099      IEND;
00174

```

```

00175 00100      DF00052 = SQT(DF00050);
00176
00177 00101      IF DF00098 == 0;
00178 00102          DF00098 = 1;
00179 00103      IEND;
00180 00104      IF DF00052 == 0;
00181 00105          DF00052 = 1;
00182 00106      IEND;
00183
00184 00107      DF00120 = DL00064 * DF00098 / DF00052 * 60;
00185 00108      DL00100 = DF00120;
00186
00187 00109      EOX;
00188
00189 00110      ML16138 = DL00020
00190 00111      ML16144 = DL00022
00191 00112      ML16150 = DL00024
00192
00193      " Break Table Y, Z, T Execute Permission
00194 00113      IOW MB055764 & MB055774 == 1;
00195
00196      " Sync On Command Set
00197 00114      MB055701 = 1;
00198
00199 00115      IOW MB055703 & MB055707 == 1
00200 00116      IOW MB055705 & MB055709 == 1
00201
00202 00117      PLD [VBKTY][VBKTZ][BKTT1][BKTT2];
00203
00204      " Max Speed Set, Acc/Dcc Set
00205 00118      FMX tDL00070;
00206 00119      IAC tDL00072;
00207 00120      IDC tDL00074;
00208
00209      " Chcuk Break Start Flag Bit On
00210 00121      MB055728 = 1;
00211 00122      IF CW00099 == 1;
00212 00123          ML16138 = ML16138 + ML05936
00213 00124          ML16144 = ML16144 + ML05936
00214
00215 00125      MVS [VBKTY]ML16138 [VBKTZ]ML16144 [BKTT1]ML16150 [BKTT2]ML16150 FDL00100 PFN;
00216 00126      ELSE;
00217 00127      MVS [VBKTY]ML16138 [VBKTZ]ML16144 [BKTT1]ML16150 [BKTT2]ML16150 FDL00100 PFN;
00218 00128      EOX;
00219
00220 00129      ML16138 = ML16138 + ML05936 * 0.1
00221
00222 00130      MVS [VBKTY]ML16138;
00223
00224 00131      ML16138 = ML16138 + ML05936 * 0.1
00225 00132      ML16144 = ML16144 + ML05936
00226 00133      ML16150 = ML75002
00227
00228 00134      MVS [VBKTY]ML16138 [VBKTZ]ML16144 [BKTT1]ML16150 [BKTT2]ML16150 FDL00100;
00229 00135      IEND;
00230 00136      ABS;
00231
00232 00137      IF CW00099 == 1;
00233 00138          MB002484 = 1;
00234 00139      IEND;
00235
00236 00140      ML73818 = ML16138;
00237 00141      ML74418 = ML16144;
00238 00142      ML75018 = ML16150;
00239
00240      " Chcuk Break Start Flag Bit Off
00241 00143      MB055728 = 0;
00242
00243      " Sync Off Command Reset
00244 00144      MB055701 = 0;
00245 00145      IOW MB055701 == 0;
00246
00247 00146      IOW MB055702 & MB055706 == 1
00248 00147      IOW MB055704 & MB055708 == 1
00249 00148      IOW MB055705 & MB055709 == 1
00250
00251 00149      IF CW00099 == 1;
00252 00150          IF !MB030036 == 1;
00253 00151              MB002484 = 1;
00254 00152          IEND;
00255 00153      ELSE;

```

```

00256 00154      MB002484 = 1;
00257 00155      IEND;
00258 00156      IOW MB030036 == 1;
00259
00260      // IF MB000004 == 1      " Automatic Driving
00261      " Breaking Execute Complet
00262 00157      MB04513D = 1;
00263 00158      MB05572F = 1;      " Table Breaking Executing Complete
00264      // IEND;
00265
00266 00159  RET;

```

			MPS303 : Break Table Execute	P00004
--	--	--	------------------------------	--------