

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_MTRX = 5;
00018 END_VAR;
00019
00020 00000     PLD [MTRX];
00021 00001     VEL [MTRX]ML40512;
00022
00023 00002     DW00030 = MW07342                                " Main Transfer X Motion Code Setting
00024
00025 00003     SFORK    DW00030 == 1 ? LBL01                    " Main Transfer X Stand By Pos
00026                     DW00030 == 2 ? LBL02                    "
00027                     DW00030 == 3 ? LBL03                    " Main Transfer X Carry In Pos
00028                     DW00030 == 4 ? LBL04                    " Main Transfer X Carry Out Pos
00029                     DW00030 == 5 ? LBL05                    " Main Transfer X PreAlign Pos
00030                     DW00030 == 6 ? LBL06                    " Main Transfer X MCR Pos
00031                     DW00030 == 7 ? LBL07                    "
00032                     DW00030 == 8 ? LBL08                    "
00033                     DEFAULT ? LBL100;
00034
00035 00004     LBL01:
00036
00037 00005         IOW MB070770 == 1                                " Unit7 Motor IL:Main Transfer X Standby
00038         Pos Enable
00039 00006         ML16010 = ML40530                                " Axis2 Move Data:Main Transfer X StandB
00040         y Pos
00041         MOV [MTRX]ML16010;
00042 00008         IOW MB071010 == 1                                " Main Transfer X Pos Moving Comp Check
00043
00044 00009         JOINTO LBL0X;
00045
00046 00010     LBL02:
00047
00048 00011         JOINTO LBL0X;
00049
00050 00012     LBL03:
00051
00052 00013         IOW MB070772 == 1                                " Unit7 Motor IL:Main Transfer X Carry I
00053         n Pos Enable
00054 00014         ML16010 = ML61006                                " Axis2 Move Data:Main Transfer X Carry
00055         In Pos
00056         MOV [MTRX]ML16010;
00057 00016         IOW MB071012 == 1                                " Main Transfer X Pos Moving Comp Check
00058
00059 00017         JOINTO LBL0X;
00060
00061 00018     LBL04:
00062
00063 00019         IOW MB070773 == 1                                " Unit7 Motor IL:Main Transfer X Carry O
00064         ut Pos Enable
00065 00020         ML16010 = ML61010                                " Axis2 Move Data:Main Transfer X Carry
00066         Out Pos
00067         MOV [MTRX]ML16010;
00068 00022         IOW MB071013 == 1                                " Main Transfer X Pos Moving Comp Check
00069
00070 00023         JOINTO LBL0X;
00071
00072 00024     LBL05:
00073
00074 00025         IOW MB070774 == 1                                " Unit7 Motor IL:Main Transfer X PreAli
00075         n Pos Enable
00076 00026         ML16010 = ML40542                                " Axis2 Move Data:Main Transfer X PreAli
00077         gn Pos
00078         MOV [MTRX]ML16010;
00079 00028         IOW MB071014 == 1                                " Main Transfer X Pos Moving Comp Check

```

```
00080
00081 00029      JOINTO LBL0X;
00082
00083 00030      LBL06:
00084
00085 00031      IOW MB070775 == 1          " Unit7 Motor IL:Main Transfer X MCR Pos
Enable
00086
00087 00032      ML16010 = ML61018          " Axis2 Move Data:Main Transfer X MCR Po
s
00088 00033      MOV [MTRX]ML16010;
00089
00090 00034      IOW MB071015 == 1          " Main Transfer X Pos Moving Comp Check
00091
00092 00035      JOINTO LBL0X;
00093
00094 00036      LBL07:
00095
00096 00037      JOINTO LBL0X;
00097
00098 00038      LBL08:
00099
00100 00039      JOINTO LBL0X;
00101
00102 00040      LBL100:
00103 00041      JOINTO LBL0X;
00104 00042      LBL0X: SJOINT;
00105
00106 00043      DW00030 = 0;              " Unit7 Main Transfer X Motion Code Rese
t
00107 00044      MW07342 = 0;              " Unit7 Main Transfer X Code Reset
00108
00109 00045      RET;
```