

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG Axis_MPALX = 10;
00018     CONST LONG Axis_MPARX = 11;
00019     CONST LONG Axis_MMCRX = 12
00020 END_VAR;
00021
00022 00000     PLD [MPALX][MPARX][MMCRX];
00023 00001     VEL [MPALX]ML41012 [MPARX]ML41112 [MMCRX]ML41212;
00024
00025 00002     DW00030 = MW07348                                " Vision & MCR Motion Code Setting
00026
00027 00003     SFORK    DW00030 == 1 ? LBL01                    " Main PreAlign LX Stand By Pos
00028                  DW00030 == 2 ? LBL02                    " Main PreAlign LX PreAlign Pos
00029                  DW00030 == 3 ? LBL03                    " Main PreAlign RX StandBy Pos
00030                  DW00030 == 4 ? LBL04                    " Main PreAlign RX PreAlign Pos
00031                  DW00030 == 5 ? LBL05                    " Main MCR X StandBy Pos
00032                  DW00030 == 6 ? LBL06                    " Main MCR X MCR Pos
00033                  DW00030 == 7 ? LBL07                    "
00034                  DW00030 == 8 ? LBL08                    "
00035                  DEFAULT ? LBL100;
00036
00037 00004     LBL01:
00038
00039 00005         IOW MB070790 == 1                                " Main PreAlign LX Standby Pos Enable
00040
00041 00006         ML16020 = ML41030                                " Move Data:Main PreAlign LX StandBy Pos
00042 00007         MOV [MPALX]ML16020;
00043
00044 00008         IOW MB071040 == 1                                " Main PreAlign LX Standby Pos Moving Co
mp Check
00045
00046 00009         JOINTO LBL0X;
00047
00048 00010     LBL02:
00049
00050 00011         IOW MB070791 == 1                                " Main PreAlign LX PreAlign Pos Enable
00051
00052 00012         ML16020 = ML62006                                " Move Data:Main PreAlign LX PreAlign Po
s
00053 00013         MOV [MPALX]ML16020;
00054
00055 00014         IOW MB071041 == 1                                " Main PreAlign LX PreAlign Pos Moving C
omp Check
00056
00057 00015         JOINTO LBL0X;
00058
00059 00016     LBL03:
00060
00061 00017         IOW MB070792 == 1                                " Main PreAlign RX StandBy Pos Enable
00062
00063 00018         ML16022 = ML41130                                " Move Data:Main PreAlign RX StandBy Pos
00064 00019         MOV [MPARX]ML16022;
00065
00066 00020         IOW MB071050 == 1                                " Main PreAlign RX StandBy Pos Moving Co
mp Check
00067
00068 00021         JOINTO LBL0X;
00069
00070 00022     LBL04:
00071
00072 00023         IOW MB070793 == 1                                " Main PreAlign RX PreAlign Pos Enable
00073
00074 00024         ML16022 = ML62206                                " Move Data:Main PreAlign RX PreAlign Po
s
00075 00025         MOV [MPARX]ML16022;
00076
00077 00026         IOW MB071051 == 1                                " Main PreAlign RX PreAlign Pos Moving C
omp Check
00078
00079 00027         JOINTO LBL0X;
00080
00081 00028     LBL05:

```

```

00082
00083 00029      JOINTO LBL0X;
00084
00085 00030      LBL06:
00086
00087 00031      JOINTO LBL0X;
00088
00089 00032      LBL07:
00090
00091 00033      JOINTO LBL0X;
00092
00093 00034      LBL08:
00094
00095 00035      JOINTO LBL0X;
00096
00097 00036      LBL100:
00098 00037      JOINTO LBL0X;
00099 00038      LBL0X: SJOINT;
00100
00101
00102 00039      SFORK   DW00030 == 9   ? LBL09      " Main MCR X Stand By Pos
00103              DW00030 == 10  ? LBL10      " Main MCR X MCR Pos
00104              DW00030 == 11  ? LBL11      "
00105              DW00030 == 12  ? LBL12      "
00106              DW00030 == 13  ? LBL13      " [1Cycle] Main PreAlign Camera Standby
00107      Pos      DW00030 == 14  ? LBL14      " [1Cycle] Main PreAlign Camera PreAlign
00108      Pos
00109              DW00030 == 15  ? LBL15      "
00110              DW00030 == 16  ? LBL16      " MPAX,MCR X All Standby Pos
00111              DEFAULT      ? LBL101;
00112 00040      LBL09:
00113
00114 00041      IOW MB070798 == 1      " Main MCR X Standby Pos Enable
00115
00116 00042      ML16024 = ML41230      " Move Data:Main MCR X StandBy Pos
00117 00043      MOV [MMCRX]ML16024;
00118
00119 00044      IOW MB071060 == 1      " Main MCR X Standby Pos Moving Comp Che
00120      ck
00121 00045      JOINTO LBL1X;
00122
00123 00046      LBL10:
00124
00125 00047      IOW MB070799 == 1      " Main MCR X MCR Pos Enable
00126
00127 00048      ML16024 = ML62406      " Move Data:Main MCR X MCR Pos
00128 00049      MOV [MMCRX]ML16024;
00129
00130 00050      IOW MB071061 == 1      " Main MCR X MCR Pos Moving Comp Check
00131
00132 00051      JOINTO LBL1X;
00133
00134 00052      LBL11:
00135
00136 00053      JOINTO LBL1X;
00137
00138 00054      LBL12:
00139
00140 00055      JOINTO LBL1X;
00141
00142 00056      LBL13:
00143
00144 00057      IOW MB070790 & MB070792 == 1      " Main PreAlign LX RX Standby Pos Enable
00145 00058      ML16020 = ML41030      " Move Data:Main PreAlign LX StandBy Pos
00146 00059      ML16022 = ML41130      " Move Data:Main PreAlign RX StandBy Pos

00147 00060      MOV [MPALX]ML16020 [MPARX]ML1602;
00148 00061      IOW MB071040 & MB071050 == 1      " Main PreAlign LX RX Standby Pos Moving
00149      Comp Check
00150 00062      JOINTO LBL1X;
00151
00152 00063      LBL14:
00153
00154 00064      IOW MB070791 & MB070793 == 1      " Main PreAlign LX RX PreAlign Pos Enabl
00155 00065      ML16020 = ML62006      " Move Data:Main PreAlign LX PreAlign Po
00156 00066      ML16022 = ML62206      " Move Data:Main PreAlign RX PreAlign Po
00157 00067      MOV [MPALX]ML16020 [MPARX]ML1602;
00158 00068      IOW MB071041 & MB071051 == 1      " Main PreAlign LX RX PreAlign Pos Movin
00159      g Comp Check

```

```
00160
00161 00069      JOINTO LBL1X;
00162
00163 00070      LBL15:
00164
00165 00071      JOINTO LBL1X;
00166
00167 00072      LBL16:
00168
00169 00073      IOW MB070790 & MB070792 & MB070798 ==      " MPALX,MPARX,MCRX Standby Pos Enable
00170
00171 00074      ML16020 = ML41030      " Move Data:Main PreAlign LX StandBy Pos
00172 00075      ML16022 = ML41130      " Move Data:Main PreAlign RX StandBy Pos
00173 00076      ML16024 = ML41230      " Move Data:Main MCR X StandBy P
00174
00175 00077      MOV [MPALX]ML16020 [MPARX]ML16022 [MMCRX]ML16024;
00176
00177 00078      IOW MB071040 & MB071050 & MB071060 ==      " MPALX,MPARX,MCRX Standby Pos Moving Co
      mp Chec
00178
00179 00079      JOINTO LBL1X;
00180
00181 00080      LBL101:
00182 00081      JOINTO LBL1X;
00183 00082      LBL1X: SJOINT;
00184
00185 00083      DW00030 = 0;      " Unit7 Vision & MCR Motion Code Reset
00186 00084      MW07348 = 0;      " Unit7 Vision & MCR Motion Code Reset
00187
00188 00085      RET;
```