

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG Axis_MTRY1 = 3;
00018     CONST LONG Axis_MTRY2 = 4;
00019     CONST LONG Axis_MTRX  = 5;
00020     CONST LONG Axis_MTRZ1 = 6;
00021     CONST LONG Axis_MTRZ2 = 7;
00022     CONST LONG Axis_MTRT  = 8;
00023     CONST LONG Axis_MPALX = 10;
00024     CONST LONG Axis_MPARX = 11
00025 END_VAR;
00026
00027 00000     PLD [MTRY1][MTRY2][MTRX][MTRZ1][MTRZ2][MTRT][MPALX][MPARX];
00028
00029 00001     DW00000 = 0;
00030 00002     DL00010 = 5000;
00031
00032 00003     IF ILAE96 > ML46130;
00033 00004         DL00020 = ILAE96 - ML46130;
00034 00005     ELSE;
00035 00006         DL00020 = ML46130 - ILAE96;
00036 00007     IEND;
00037
00038 00008     IF DL00020 > DL00010
00039 00009         DB000000 = 1;
00040 00010     IEND;
00041
00042 00011     IF !MB071020 == 1                                " Main Transfer Z St
andby Pos
00043 00012         MW07344 = 1;
00044 00013         MSEE MPS412;
00045 00014     IEND;
00046
00047 00015     IF !MB071010 == 1                                " Main Transfer X St
andby Pos
00048 00016         MW07342 = 1;
00049 00017         MSEE MPS411;
00050 00018     IEND;
00051
00052 00019     IF !MB071038 == 1                                " Main Transfer T Pr
eAlign Pos
00053 00020         IF DB000000 == 1
00054 00021             MSEE MPS416;                                " Main Transfer Turn
Pos
00055 00022             IEND;
00056 00023             IEND;
00057
00058 00024     PFORK MTRY MTRX MTRT MPALX MPARX;
00059
00060     MTRY:
00061
00062 00025         IOW MB071038 == 1                                " Main Transfer T Pr
eAlign Pos Check
00063
00064 00026         IF !MB071004 == 1                                " Main Transfer Y Pr
eAlign Pos
00065 00027             IOW MB070764 == 1                                " Main Transfer Y Pr
eAlign Pos Enabl
00066
00067 00028         ML16006 = ML60626                                " Move Data:Main Tra
nsfer Y PreAlign Pos
00068 00029         MOV [MTRY1]ML16006 [MTRY2]ML16006;
00069 00030         IOW MB071004 == 1                                " Main Transfer Y Pr
eAlign Pos Moving Comp Chec
00070 00031             IEND;
00071
00072 00032         JOINTO Label0X;
00073
00074     MTRX:
00075
00076 00033         IOW MB071038 == 1                                " Main Transfer T Pr
eAlign Pos Check
00077

```

```

00078 00034      IF !MB071014 == 1                                " Main Transfer X Pr
eAlign Pos:
00079 00035      IOW MB070774 == 1                                " Main Transfer X Pr
eAlign Pos Enable
00080
00081 00036      ML16010 = ML40542                                " Move Data:Main Tra
nsfer X PreAlign Pos
00082 00037      MOV [MTRX]ML16010;
00083
00084 00038      IOW MB071014 == 1                                " Main Transfer X Pr
eAlign Pos Moving Comp Check
00085 00039      IEND;
00086
00087 00040      JOINTO Label0X,
00088
00089      MTRT:
00090
00091 00041      IF !MB071038 == 1                                " Main Transfer T Pr
eAlign Pos
00092 00042      IOW MB070788 == 1                                " Main Transfer T Pr
eAlign Pos Enable
00093
00094 00043      ML16016 = ML46158                                " Move Data:Main Tra
nsfer T PreAlign Pos
00095 00044      MOV [MTRT]ML16016;
00096
00097 00045      IOW MB071038 == 1                                " Main Transfer T Pr
eAlign Pos Moving Comp Check
00098 00046      IEND;
00099
00100 00047      JOINTO Label0X;
00101
00102
00103      MPALX:
00104
00105 00048      IF !MB071041 == 1                                " Main PreAlign Came
ra LX PreAlign Pos
00106 00049      IOW MB070791 == 1                                " Main PreAlign Came
ra LX PreAlign Pos Enable
00107
00108 00050      ML16020 = ML62006                                " Move Data:Main Pre
Align Camera LX PreAlign Pos
00109 00051      MOV [MPALX]ML16020;
00110
00111 00052      IOW MB071041 == 1                                " Main PreAlign Came
ra LX PreAlign Pos Moving Comp Check
00112 00053      IEND;
00113
00114 00054      JOINTO Label0X,
00115
00116      MPARX:
00117
00118 00055      IF !MB071051 == 1                                " Main PreAlign Came
ra RX PreAlign Pos
00119 00056      IOW MB070793 == 1                                " Main PreAlign Came
ra RX PreAlign Pos Enable
00120
00121 00057      ML16022 = ML62206                                " Move Data:Main Pre
Align Camera RX PreAlign Pos
00122 00058      MOV [MPARX]ML16022;
00123
00124 00059      IOW MB071051 == 1                                " Main PreAlign Came
ra RX PreAlign Pos Moving Comp Check
00125 00060      IEND;
00126
00127 00061      JOINTO Label0X,
00128
00129 00062      Label0X: PJOINT;
00130
00131
00132 00063      IF !MB071024 == 1                                " Main Transfer Z Pr
eAlign Pos:
00133 00064      MW07344 = 5;
00134 00065      MSEE MPS412;
00135 00066      IEND;
00136
00137
00138 00067      MB071372 = 0;                                " Unit7 Cycle1 Move
Check
00139
00140 00068      RET;

```