

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     BOOL MTR_ALIGN_L_REQ      %MB214722;
00018     BOOL MTR_ALIGN_R_REQ      %MB214723;
00019
00020     BOOL MTR_ALIGN_L_RESP     %MB205322;
00021     BOOL MTR_ALIGN_R_RESP     %MB205323;
00022
00023     BOOL MTR_ALIGN_L_NG       %MB201002;
00024     BOOL MTR_ALIGN_R_NG       %MB201003;
00025
00026     BOOL MTR_ALIGN_L_MANUAL_RE %MB214782;
00027     BOOL MTR_ALIGN_R_MANUAL_RE %MB214783;
00028
00029     BOOL MTR_ALIGN_L_MANUALSTC %MB201102;
00030     BOOL MTR_ALIGN_R_MANUALSTC %MB201103;
00031
00032     BOOL MTR_ALIGN_MANUALSTOP_ALARM %MB070381;
00033     BOOL MTR_ALIGN_MARK_DISTANCE_ALARM %MB070382;
00034     BOOL MTR_ALIGN_ZERO_VAL_ALARM %MB070383;
00035
00036     LONG MTR_ALIGN_L_RESULT_XDATA %ML23108;
00037     LONG MTR_ALIGN_L_RESULT_YDATA %ML23110;
00038     LONG MTR_ALIGN_R_RESULT_XDATA %ML23112;
00039     LONG MTR_ALIGN_R_RESULT_YDATA %ML23114;
00040
00041 END_VAR;
00042
00043
00044 00000     CLR DW00050 W20;
00045 00001     ML07394 = 0; " PreAlign Auto Mark Search X Of
00046 00002     fset Result ML07398 = 0; " PreAlign Auto Mark Search Y Of
00047 00003     fset Result ML07402 = 0; " PreAlign Auto Mark Search T Of
00048     fset Result
00049 00004     MTR_ALIGN_L_REQ = 0 " Alignment Request OFF(Left)
00050 00005     MTR_ALIGN_R_REQ = 0 " Alignment Request OFF(Right)
00051
00052 00006     IF MW00056 <> 83; " Turn Center Cal
00053 00007         IF !MB071324 == 1;
00054 00008             IF !MB071020 == 1;
00055 00009                 MW07344 = 1;
00056 00010                 MSEE MPS412;
00057 00011             IEND;
00058
00059 00012             MSEE MPS421; " Alignment Po:
00060 00013             TIM TMW30230;
00061 00014             IEND;
00062 00015             IEND;
00063
00064 00016     IOW MTR_ALIGN_L_RESP | MTR_ALIGN_R_RESP == 0;
00065
00066 // IF !MB000800 == 1 " No-Load Operation
00067 00017     DB00020 = 0;
00068 00018     DB00021 = 0;
00069 00019     DW00020 = 0;
00070
00071 00020     WHILE DW00020 < MW30240;
00072 00021         IF MTR_ALIGN_L_MANUAL_REQ | MTR_ALIGN_R_MANUAL_REQ == " MTR Manual Alignment Re
00073
00074 00022             MTR_ALIGN_L_REQ = 1 " Alignment Request ON(Left)
00075 00023
00076 00024             IF MW00056 <> 83;
00077                 MTR_ALIGN_R_REQ = 1 " Alignment Request ON(Right)
00078
00079 )
00077 00025     IEND;
00078 00026     IOW MTR_ALIGN_L_RESP == 1 " Alignment Respons O
00079 00027     IF MW00056 <> 83;
00080 00028         IOW MTR_ALIGN_R_RESP == 1 " Alignment Respons ON

```

```

00081 00029          IEND;
00082
00083 00030          IF MTR_ALIGN_L_NG == 0
00084 00031              ML07310 = MTR_ALIGN_L_RESULT_XDAT;          " Alignment Data X1
00085 00032              ML07312 = (MTR_ALIGN_L_RESULT_YDATA * -1    " Alignment Data Y1
00086 00033              DB00020 = 1;
00087 00034          IEND;
00088 00035          IF MTR_ALIGN_R_NG == 0;
00089 00036              ML07314 = MTR_ALIGN_R_RESULT_XDAT;          " Alignment Data X2
00090 00037              ML07316 = (MTR_ALIGN_R_RESULT_YDATA * -1    " Alignment Data Y2
00091 00038              DB00021 = 1;
00092 00039          IEND;
00093
00094 00040          MB07360A = MTR_ALIGN_L_NG;
00095 00041          MB07360B = MTR_ALIGN_R_NG
00096
00097 00042          MTR_ALIGN_L_REQ = 0          " Alignment Request OFF(Left
)
00098 00043          MTR_ALIGN_R_REQ = 0          " Alignment Request OFF(Righ
t)
00099 00044          IOW MTR_ALIGN_L_RESP == 0          " Alignment Respons ON
00100 00045          IOW MTR_ALIGN_R_RESP == 0          " Alignment Respons ON
00101 00046          IEND;
00102 00047          IF DB00020 & DB00021 == 1;
00103 00048              DW00020 = MW30240 + 1;
00104 00049              IF CW00053 == 1;
00105 00050                  MB07360A = 0;
00106 00051                  MB07360B = 0;
00107 00052          IEND;
00108 00053          ELSE;
00109 00054              DW00020 = DW00020 + 1;
00110 00055              TIM T100;
00111 00056          IEND;
00112 00057          WEND;
00113
00114 00058          IF GL49044 == 0          " T Auto Mark Search (0:Use 1:Un
use)
00115 00059              IF (MB07360A | MB07360B) == 1
00116 00060                  IF !MB073606 == 1          " Auto Mark Seach Complete
00117 00061                      MSEE MPS428;
00118 00062              IEND;
00119 00063          IEND;
00120 00064          IEND;
00121
00122 00065          IF GL49020 == 0          " X,Y Auto Mark Search (0:Use 1:
Unuse)
00123 00066              IF (MB07360A | MB07360B) == 1
00124 00067                  IF !MB073606 == 1          " Auto Mark Seach Complete
00125 00068                      MSEE MPS426;
00126 00069              IEND;
00127 00070          IEND;
00128 00071          IEND;
00129
00130          " Manual Search Flag
00131 00072          IF MB07360A | MB07360B == 1;
00132
00133 00073              DB000000 = 0;
00134 00074              DB000010 = 0;
00135 00075              DB000011 = 0;
00136
00137 00076              WHILE DB000000 == 0
00138
00139 00077                  IOW MTR_ALIGN_L_RESP | MTR_ALIGN_R_RESP ==          " Wait Alignment Respons OFF
00140 00078                  MTR_ALIGN_L_MANUAL_REQ = MB07360;          " L Camera Manual Alignment
Request
00141 00079                  MTR_ALIGN_R_MANUAL_REQ = MB07360;          " R Camera Manual Alignment
Request
00142 00080                  MB07360C = 1;          " Warning Alarm : Manual Sea
rch Dialog Notice
00143 00081                  EOX;
00144
00145 00082                  PFORK Line1 Line2;
00146                  Line1:
00147 00083                      IF MTR_ALIGN_L_MANUAL_REQ == 1;
00148 00084                          MTR_ALIGN_L_REQ = 1          " Alignment Request ON(Left)
00149 00085                      IOW MTR_ALIGN_L_RESP == 1;
00150 00086                      IEND;
00151 00087                      JOINTO LabelX1;
00152
00153                  Line2:
00154 00088                      IF MTR_ALIGN_R_MANUAL_REQ == 1;
00155 00089                          MTR_ALIGN_R_REQ = 1          " Alignment Request ON(Right
)
00156 00090                      IOW MTR_ALIGN_R_RESP == 1;
00157 00091                      IEND;

```

```

00158 00092          JOINTO LabelX1;
00159 00093          LabelX1: PJOINT
00160
00161      //          IF (MTR_ALIGN_L_MANUALSTOP | MTR_ALIGN_R_MANUALSTOP) == 1;
00162 00094          IF (MTR_ALIGN_L_NG | MTR_ALIGN_R_NG) == 1;
00163 00095              MB000015 = 1;                                " Cycle Stop
00164 00096              MTR_ALIGN_MANUALSTOP_ALARM = 1;              " Alignment Resp NG
00165 00097              MTR_ALIGN_L_MANUAL_REQ = 0;
00166 00098              MTR_ALIGN_R_MANUAL_REQ = 0;
00167 00099              DB000000 = 1;
00168 00100              EOX;
00169 00101          IEND;
00170
00171      //          IF MTR_ALIGN_L_NG | !MTR_ALIGN_L_MANUAL_REQ == 0;
00172 00102          IF !MTR_ALIGN_L_NG == 1;
00173 00103              ML07310 = MTR_ALIGN_L_RESULT_XDATA;            " Alignment Data X1
00174 00104              ML07312 = (MTR_ALIGN_L_RESULT_YDATA * -1;      " Alignment Data Y1
00175 00105              MB07360A = 0;                                " L Alignment NG (0:OK 1:NG)
00176 00106              MTR_ALIGN_L_MANUAL_REQ = 0;                    " L Camera Manual Alignment
Request
00177 00107          IEND;
00178      //          IF MTR_ALIGN_R_NG | !MTR_ALIGN_R_MANUAL_REQ == 0;
00179 00108          IF !MTR_ALIGN_R_NG == 1;
00180 00109              ML07314 = MTR_ALIGN_L_RESULT_XDATA;            " Alignment Data X2
00181 00110              ML07316 = (MTR_ALIGN_R_RESULT_YDATA * -1;    " Alignment Data Y2
00182 00111              MB07360B = 0;                                " R Alignment NG (0:OK 1:NG)
00183 00112              MTR_ALIGN_R_MANUAL_REQ = 0;                    " R Camera Manual Alignment
Request
00184 00113          IEND;
00185
00186 00114          MTR_ALIGN_L_REQ = 0;                                " L Camera Manual Alignment
Request OFF
00187 00115          MTR_ALIGN_R_REQ = 0;                                " R Camera Manual Alignment
Request OFF
00188 00116          IOW MTR_ALIGN_L_RESP | MTR_ALIGN_R_RESP ==
00189
00190 00117          IF MB07360A | MB07360B == 0;
00191 00118              DB000000 = 1;
00192 00119          IEND;
00193 00120          EOX;
00194 00121          WEND;
00195 00122          IEND;
00196 00123          IF MTR_ALIGN_L_NG | MTR_ALIGN_R_NG ==
00197 00124              IF ML07310 == 0;                                " Alignment ZeroValue Check
00198 00125              IF ML07312 == 0;
00199 00126                  IF ML07314 == 0;                            " Alignment ZeroValue Check
00200 00127                      IF ML07316 == 0;
00201 00128                          MTR_ALIGN_ZERO_VAL_ALARM = 1;      " Alignment ZeroValue Alarm
00202 00129                          EOX;
00203 00130                      IEND;
00204 00131                  IEND;
00205 00132              IEND;
00206 00133          IEND;
00207
00208 00134          DF000050 = IL8516 + ML07310;                        " Left Mark Real X Po
00209 00135          DF000052 = IL8596 + ML07314;                        " Right Mark Real X Pos
00210 00136          DF000054 = ML07312 - ML07316;                      " L,R Mark Y Distance
00211 00137          DL000056 = GL49016;                                " Align Mark Pos D
00212 00138          DF000058 = DF000052 - DF000050;
00213
00214 00139          DF000060 = (DF000058 * DF000058) + (DF000054 * DF000054);
00215 00140          DF000062 = SQT(DF000060);
00216 00141          DL000064 = DL000056 - DF000062;
00217
00218 00142          IF DL000064 < 0;                                      " Find Mark Distance Check
00219 00143              DL000064 = -DL000064;
00220 00144          IEND;
00221
00222 00145          IF DL000064 > ML30234;
00223 00146              MTR_ALIGN_MARK_DISTANCE_ALARM = 1;
00224 00147          IEND;
00225
00226 00148          IEND;
00227
00228      // ELSE;
00229      //     ML07310 = 0;                                " Alignment Data X1
00230      //     ML07312 = 0;                                " Alignment Data Y1
00231      //     ML07314 = 0;                                " Alignment Data X2
00232      //     ML07316 = 0;                                " Alignment Data Y
00233      // IEND;
00234
00235 00149  RET;

```