

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      : MCR Read 1 Cycle
00011 "# Function      :
00012 "# Call Program   :
00013 "# Sub Program    :
00014 "# Func Program   :
00015
00016 VAR;
00017     BOOL MTR_MCR_DIALOG_REQ      %MB21463E;
00018     BOOL MTR_MCR_DIALOG_RESP     %MB20523E;
00019     BOOL MTR_MCR_READ_REQ        %MB21463F;
00020     BOOL MTR_MCR_READ_RES        %MB20523F;
00021     LONG MTR_MCR_READ_RESUL      %ML23580;
00022
00023
00024 END_VAR;
00025
00026 00000     PLD [MTRY1] [MTRY2] [MTRX] [MTRZ1] [MTRZ2] [MTRT] [MMCRX];
00027
00028 00001     DB00010 = 0;
00029 00002     ML07330 = 0;                                " MCR Read Stick Count
00030 00003     ML07332 = 0;                                " MCR Read Cell Count
00031 00004     MB070138 = 0;                                " MCR Key In Flag
00032 00005     DW00020 = 19279                            " MCR Key In Result (19279: OK)
00033 00006     DW00021 = 18254                            " MCR Key In Result (18254: NC)
00034 00007
00035 00008     ML23580 = 0;
00036
00037 00009     IF MB071025 == 1                                " Main Transfer MCR Z MCR Pc
00038 00010         MSEE MPS422;                                " Main Transfer MCR Pos
00039 00011     ELSE;
00040 00012         MW07344 = 1;
00041 00013         MSEE MPS412;                                " Main Transfer Z Standby Pos
00042
00043 00014         MSEE MPS422;                                " Main Transfer MCR Po
00044 00015
00045
00046 00016     DL00080 = 0;                                " MCR Repeat Count
00047
00048 00017     MTR_MCR_DIALOG_REQ = 0                            " Dialog Display Req
00049 00018     IOW MTR_MCR_DIALOG_RESP == 0                        " Dialog Display Resp
00050 00019     MTR_MCR_READ_REQ = 0                                " MCR Read Req
00051 00020     IOW MTR_MCR_READ_RESP == 0                            " MCR Read Resp
00052
00053 00021     IF !MB000800 == 1
00054
00055 00022         IF MW129424 <> 2                                " VCR Reading Mode(0:VCR On Dig On/1
:VCR On Dig Skip/2:VCR Off Dig On/3:VCR Off Dig Off)
00056 00023             WHILE DL00080 <= ML30218                    " MCR Repeat Count
00057 00024                 MTR_MCR_READ_REQ = 1;
00058 00025                 IOW MTR_MCR_READ_RESP == 1;
00059
00060                 " MCR Read Result OK/NG Judge
00061 00026                 IF MTR_MCR_READ_RESULT == 1            " MCR Read Result(1: OK, 2: NG 4: Ti
meout 8:Exception)
00062 00027                     TIM T50;
00063 00028                     IF MB1342022 == 1                    " MCR ID Match
00064 00029                         DW00030 = 1;
00065 00030                         DL00080 = ML30218 + 1;
00066 00031                     ELSE;
00067 00032                         DW00030 = 2;
00068 00033                         DL00080 = DL00080 + 1;
00069 00034                     IEND;
00070 00035                     ELSE;
00071 00036                         DW00030 = 2;
00072 00037                         DL00080 = DL00080 + 1;
00073 00038                     IEND;
00074
00075 00039                     MTR_MCR_READ_REQ = 0                " MCR Read Req
00076 00040                     IOW MTR_MCR_READ_RESP == 0        " MCR Read Resp
00077
00078 00041                     EOX;
00079 00042                     WEND;
00080
00081 00043                     IF DW00030 == 2;

```

```

00082 00044          IF MW129424 == 0;                                " VCR Reading Mode(0:VCR On Dig On/1
:VCR On Dig Skip/2:VCR Off Dig On/3:VCR Off Dig Off)
00083 00045          MB070581 = 1;                                " Warning Alarm : Dialog Display Not
ice
00084 00046          MTR_MCR_DIALOG_REQ = 1;                          " Dialog Display Req
00085 00047          IOW MTR_MCR_DIALOG_RESP == 1;                  " Dialog Display Resp
00086
00087          //          TIM T50;
00088
00089 00048          IOW MW129999 <> 8224                            " Dialog Key In Check
00090
00091 00049          IF MW129999 == DW00020                            " MCR Key In Result (4B4F: OK 474E:
NG)
00092 00050          MB070138 = 1;                                " MCR Key In Flag
00093 00051          MTR_MCR_DIALOG_REQ = 0;
00094 00052          IOW MTR_MCR_DIALOG_RESP == (
00095 00053          ELSE;
00096 00054          IF MTR_MCR_READ_RESULT == 2                            " MCR Read Result(1: OK, 2: NG 4: Ti
meout 8: Exception)
00097 00055          MB070388 = 1;
00098 00056          IEND;
00099 00057          IF MTR_MCR_READ_RESULT == 4                            " MCR Read Result(1: OK, 2: NG 4: Ti
meout 8: Exception)
00100 00058          MB070389 = 1;
00101 00059          IEND;
00102 00060          IF MTR_MCR_READ_RESULT == 8                            " MCR Read Result(1: OK, 2: NG 4: Ti
meout 8: Exception)
00103 00061          MB07038A = 1;
00104 00062          IEND;
00105 00063          MTR_MCR_DIALOG_REQ = 0;
00106 00064          IOW MTR_MCR_DIALOG_RESP == (
00107 00065          IEND;
00108 00066          IEND;
00109 00067          IEND;
00110 00068          IEND;
00111
00112
00113 00069          IF MW129424 == 2                                " VCR Reading Mode(0:VCR On Dig On/1
:VCR On Dig Skip/2:VCR Off Dig On/3:VCR Off Dig Off)
00114 00070          MTR_MCR_DIALOG_REQ = 1;                          " Dialog Display Req
00115 00071          MB070581 = 1;                                " Warning Alarm : Dialog Display Not
ice
00116 00072          TIM T50;
00117 00073          IOW MW129999 <> 8224                            " Dialog Key In Check
00118
00119 00074          IF MW129999 == DW00020                            " MCR Key In Result (4B4F: OK 474E:
NG)
00120 00075          MB070138 = 1;                                " MCR Key In Flag
00121 00076          MTR_MCR_DIALOG_REQ = 0;
00122 00077          IOW MTR_MCR_DIALOG_RESP == (
00123 00078          ELSE;
00124 00079          MB070388 = 1;                                " MCR Read Fail Alarm
00125 00080          MTR_MCR_DIALOG_REQ = 0;
00126 00081          IOW MTR_MCR_DIALOG_RESP == (
00127 00082          IEND;
00128 00083          IEND;
00129 00084          IEND;
00130
00131 00085          MB071370 = 0;                                " Unit7 Cycle1 Move Check
00132
00133 00086          RET;

```