QFCAPX

Approximates QFC with triangle inequation, norming is pulled out to input stage kernel is feeded with norm vectors or scalars instead of matrices.

Syntax

```
K = QFCAPX(ax, bx, ay, by, theta)
```

Description

K = QFCAPX(ax, bx, ay, by, theta) computes quadratic distances bewtween data points and parametrize it with height and length scales. Computes distance with quadratic euclidian norm.

Input Argurments

ax vector of cosine simulation components.

bx vector of cosine simulation components.

ay vector of sine simulation components.

by vector of sine simulation components.

theta vector of kernel parameters.

Output Argurments

K noise free covarianc matrix.

Requirements

- Other m-files required: None
- Subfunctions: None
- MAT-files required: None

See Also

- initQFCAPX
- meanPolyQFCAPX

Created on February 15. 2021 by Tobias Wulf. Copyright Tobias Wulf 2021.

```
function K = QFCAPX(ax, bx, ay, by, theta)
    arguments
    % validate data as real vector of same size
    ax (:,:,:) double {mustBeReal}
    bx (:,:,:) double {mustBeReal, mustBeFitSize(ax,bx)}
    ay (:,:,:) double {mustBeReal, mustBeFitSize(ax,ay)}
    by (:,:,:) double {mustBeReal, mustBeFitSize(ax,by)}
    % validate kernel parameters as 1x2 vector
    theta (1,2) double {mustBeReal}
end

% get number of observations for each dataset, cosine and sine
    M = length(ax);
    N = length(bx);
```

```
\ensuremath{\mbox{\$}} expand covariance parameters, variance and lengthscale
    c2 = 2 * theta(2)^2; % 2*s1^2
    c1 = theta(1) * c2; % s2f * c
    % allocate memory for K
    K = zeros(M, N);
    \ensuremath{\$} loop through observation points and compute the covariance for each
    % observation against another
    for m = 1:M
        for n = 1:N
            % get distance between m-th and n-th observation
            \ensuremath{\text{\%}} compute distance with quadratic frobenius normed vectors
            r2 = (ax(m) - bx(n))^2 + (ay(m) - by(n))^2;
            % engage lengthscale and variance on distance
            K(m,n) = c1 / (c2 + r2);
    end
end
function mustBeFitSize(a, b)
    % Test for equal size
    if ~isequal(size(a,1,2), size(b,1,2))
        eid = 'Size:notEqual';
        msg = 'Sizes of are not fitting.';
        throwAsCaller(MException(eid,msg))
    end
end
```

Published with MATLAB® R2020b