```
0306
        BF
             PHI
                   RF
        F8
             LDI
  C7
  C8
        FF
  C9
        AF
             PLO
                   RF
                         ;Store FE; next available address @ 02FF
  CA
        F8
             LDI
  CB
        FE
        5F
  CC
             STR
                   RF
  CD
        D5
             SEP
                   R5
                     SET LINK ADDRESS
03CE
        F8
             LDI
  CF
        02
  D<sub>0</sub>
        BD
             PHI
                   RD
                         RD.1 = 02 = Page address Link Table
  D1
        F8
             LDI
  D2
       FF
  D3
D4
        AD
             PLO
                   RD
                         RD = 02FF = Storage for address next table
        OD
             LDN
                         Get address next table entry
                   RD
  D5
D6
        AD
             PLO
                         ;Put in RD.0
                   RD
        2D
             DEC
                   RD
                         Then decrement to point to the 2-byte link
  D7
        D5
             SEP
                   R5
                                                                   address
                         Return
                   SET LINK TABLE BACK
03D8
        F8
             LDI
        02
  D9
  DA
        BF
             PHI
                         RF = 02FF = Last byte Link Table
                   RF
  DB
        F8
             LDI
  DC
        FF
        AF
  DD
             PLO
                   RF
        OF
  DE
             LDN
                   RF
  DF
        FF
             SMI
                         Subtract two to contents to point to
        02
03E0
                         Next table entry end
                         Then return new value to table
        5F
             STR
                   RF
  E1
        D5
  E2
             SEP
                   R5
                         Return
                       OUTPUT MANAGER
                   R4
03E3
        D4
             SEP
  E4
        01
                         :Call Symbol Table Rearranger
        56
D4
  E5
  E6
                   R4
             SEP
  E7
        01
                         ; Call Output Link Table
  E8
        DA
        9B
             GHI
                   RB
  E9
        B6
             PHI
                   R6
  EA
        F8
             LDI
  EB
        07
A6
  EC
                         :R6 is destination address for Display Digit
             PLO
                   R6
  ED
```