## WRITE BYTE @ ADDRESS

```
01AF
       D4
             SEP
                   R4
  BO
       02
                        ; Call Function display
  B1
       AF
       57
D4
  B2
           52 49
                 54 45 20 42 59 54 45 00
                                              ("Write Byte")
  BD
             SEP
                  R4
  BE
       03
                        Call Position R7 R9 for keyboard entry
       E4
  BF
       D4
01C0
             SEP
                  R4
  C1
       02
                        ; Call Keyboard entry
  C2
       CO
  C3
C4
       04
                        Pass loop value - 4 for an address
       D4
             SEP
                   R4
  05
06
       01
                        Call Displacement/RA boundary check
       6F
                        RF = 00 = yes RF = 01 no, not in bounds)
  C7
       8F
             GLO
                  RF
  C8
       3A
64
             BNZ
                        ; If RA not in bounds, branch to Error-Retry
  C9
                        ;In Show From sub @ 0164
  CA
       19
             INC
                  R9
                        ;R9 + 1 to create space after displayed address
       D4
                  R4
  CB
             SEP
  CC
       02
                        ; Call Keyboard entry (Answer in RF.1)
  CD
       CO
  CE
                        ; Pass loop value - 2 for a single byte
       02
  CF
       9F
             GHI
                  RF
01 DO
       BE
             PHI
                  RE
                        Store byte in temporary register RE.1
       DC
  D1
             SEP
                  RC
                        Do keyboard scan
  D2
       \mathbf{F}\mathbf{B}
             XRI
  D3
       OE
                        :Test if key "E" pressed, if not,
  D4
       3A
             BNZ
                        Branch to recycle for new entry @ 01AF.
  D5
D6
       AF
                        (Could branch to exit)
       9E
                        :Get the saved byte
             GHI
                  RE
  D7
       5A
             STR
                  RA
                        ;Store in data area
  D8
       D4
                  R4
             SEP
  D9
       03
                        ; Call Adjust RA RD to avoid displaying in
                        The middle of a data byte
  DA
       BA
       D5
                  R5
  DB
             SEP
                        :Return
                  TAPE READ/WRITE - CONTROL ROUTINE
                  R4
01DC
       D4
             SEP
       02
                        :Call Function display
  DD
  DE
       AF
        52 45 41 44 2F 57 52 49 54 45 3F 00
                                                  ("Read/Write?")
  DF
        F8
             LDI
01EB
        81
                        Initialize RC to Key scan ROM routine
  EC
        BC
  ED
             PHI
                   RC
  EE
       F8
             LDI
                        ;Initialize RC to Key scan ROM routine
  EF
        95
```