Robot Hardware Map

Every device, the subsystem that owns it, and where it plugs in. Ports shown are as wired on 11/5 and are **still being checked on the robot**. **Fill any blanks in pencil** as you wire: circle **CH** (Control Hub) or **EH** (Expansion Hub) and write the **Port #**. The **config name** must match the Driver Station config **exactly** (capital letters too). Then copy the ports into `hardware-config.md`.

Subsystem	Config name (Driver Station)	Device	Config type	Hub (circle)	Port type	Port #	Notes
Drivetrain	**`frontLeftDrive`**	goBILDA 5203 Yellow Jacket	goBILDA 5203 Series	**CH**	Motor	**0**	Direction REVERSE
Drivetrain	**`backLeftDrive`**	goBILDA 5203 Yellow Jacket	goBILDA 5203 Series	**CH**	Motor	**1**	Direction REVERSE
Drivetrain	**`frontRightDrive`**	goBILDA 5203 Yellow Jacket	goBILDA 5203 Series	**EH**	Motor	**0**	
Drivetrain	**`backRightDrive`**	goBILDA 5203 Yellow Jacket	goBILDA 5203 Series	**EH**	Motor	**1**	
Odometry	**`pinpoint`**	goBILDA Pinpoint + 2 pods	goBILDA Pinpoint	**EH**	I2C bus	**3**	Not bus 0 (built-in IMU)
Odometry	**`imu`**	Control Hub built-in IMU	(built in)	**CH**	I2C bus	**0**	Built in, can't move
Intake	**`intakeServo`**	Servo (continuous)	Continuous Rotation Servo	**EH**	Servo	**2**	Pulls game elements in
Intake	**`waterWheelMotor`**	goBILDA 5203-2402-0051 (117 RPM)	goBILDA 5203 Series	**CH**	Motor	**3**	~~Water wheel: up to the launcher.~~ Was a servo (EH servo 1) until 11/11
Intake	**`nectarDetectorLeftSwitch`**	goBILDA micro limit switch	Digital Device	**EH**	Digital	**0-1**	Channel 1. Either one = NECTAR
Intake	**`nectarDetectorRightSwitch`**	goBILDA micro limit switch	Digital Device	**EH**	Digital	**2-3**	Channel 3. Either one = NECTAR
Launcher	**`launcherMotor`**	goBILDA 5203 Yellow Jacket	goBILDA 5203 Series	**CH**	Motor	**2**	The flywheel
Launcher	**`launcherTriggerServo`**	Servo	Servo	**EH**	Servo	**4**	REST / FIRE
Turret	**`turretRotateServo`**	goBILDA 2000 25-3 Speed (continuous)	Continuous Rotation Servo	**EH**	Servo	**0**	Signal 1000-2000 us
Turret	**`turretEncoder`**	ELC Encoder V2, "D" cable	Motor (never powered)	**EH**	Encoder	**2**	Motor port 2 must stay empty
Turret	**`turretHomeSwitch`**	REV Magnetic Limit Switch	Digital Device	**CH**	Digital	**0-1**	At 90 deg LEFT. Channel 1
Turret	**`turretHoodServo`**	Servo	Servo	**CH**	Servo	**0**	Planned, not wired yet. Tilts the launch up/down
Camera	**`limelight`**	Limelight 3A	Limelight 3A	**CH**	USB	**USB 3.0**	Must be the USB 3.0 port
FlowerFlipper	**`flowerFlipperServo`**	Servo	Servo	**EH**	Servo	**5**	Shakes back and forth
Lights	**`leftIndicatorLight`**	goBILDA RGB Indicator Light	Servo	**CH**	Servo	**3**	Black wire to ground mark
Lights	**`rightIndicatorLight`**	goBILDA RGB Indicator Light	Servo	**EH**	Servo	**3**	Black wire to ground mark

Port types: Motor = 4 per hub (0-3). **Encoder** = the small 4-pin socket next to each motor port, same number. **Servo** = 6 per hub (0-5). **Digital** = 4 sockets per hub, each with 2 channels (0-1, 2-3, 4-5, 6-7): write the **channel** the config uses. **I2C bus** = 4 per hub (0-3). **Config type** = what to pick in the Driver Station when adding the device.

Reminders: the Expansion Hub connects with the RS485 **3-pin** cable plus XT30 power. The turret encoder goes on Expansion Hub encoder port 2, so motor port 2 must stay **empty**. Drive motor encoders and the flywheel encoder use their own motor's encoder port. Nothing may move during INIT (G304.H).