## **Business Continuity Manual**

**Business Continuity Plan: A5** 

## **Fixed Ground Power**

|             |                                    | Signature | Revision | Effective<br>Date |
|-------------|------------------------------------|-----------|----------|-------------------|
| Updated By  | Assistant<br>General Manager<br>AD | Albert Ho |          |                   |
| Reviewed By | Senior Manager<br>BCP, SSBC        | Emily Chu | 29       | Dec 2021          |
| Approved By | General Manager<br>SSBC            | David Jea |          |                   |

# Airport Authority Hong Kong Business Continuity Manual: BCP – A5. Fixed Ground Power

Blank Page

## Airport Authority Hong Kong

## Business Continuity Manual: BCP – A5. Fixed Ground Power

## **BCP - A5. Fixed Ground Power Table of Contents**

| <u>ITEM</u> | SUBJECT MATTER  |      |
|-------------|---|------|
| Α           | System Description  | A5.5 |
| В           | Physical System Risk  | A5.5 |
| С           | Contingency Procedures for Fixed Ground Power                     | A5.6 |
| D           | Contingency Procedures during the Tropical Cyclones               | A5.7 |
| Е           | Interface with Other Operational Organizations during Contingency | A5.8 |

# Airport Authority Hong Kong Business Continuity Manual: BCP – A5. Fixed Ground Power

Blank Page

### A. System Description

#### 1.0 Introduction

- 1.1 Fixed Ground Power are installed on all the frontal and remote stands of passenger apron and cargo stands in cargo apron to facilitate aircraft to use ground power after docking.
- 1.2 Most frontal parking stands at T1 and T1M are equipped with two nos. of FGP power plug outlet with rating 90kVA FGP power plug each at inner airbridge and outer airbridge.
- 1.3 Among the frontal stands at T1 and T1M, those designed for A380 parking are supplied with additional 90kVA plug(s) which is either bridgemount type or pit type to cater for A380 operation. The typical A380 airbridges are equipped with two no. of FGP power plug outlet each with rating 90kVA.
- 1.4 All parking stands of the T1S are equipped with one no. of FGP power plug outlet with rating 90kVA each.
- 1.5 Most remote parking stands are equipped with two nos. of FGP power plug outlet with rating 90kVA each for the main centerline. For left or right auxiliary centerline, one no. of 90kVA FGP power plug is equipped.
- 1.6 Most cargo parking stands are equipped with two no. of FGP power plug outlet with rating 90kVA each. Serving the aircraft via pit system.

#### B Physical System Risk

| Risk  | Description  | Mitigation   |
|---|--|--|
| Loss of power<br>supply to FGP<br>Plantroom 1 /<br>Plantroom 2                            | Loss of power supply from upstream LV Switchroom 'C3' or 'C7' supplying FGP Plantroom 1 or Plantroom 2 respectively. | <ul> <li>Carry out manual<br/>switching to restore the<br/>backup supply from LV<br/>Switchroom 'C2' or 'C6'<br/>with a de-rated total<br/>system capacity.</li> </ul> |
| Failure of<br>380V/960V step<br>up transformer<br>at FGP<br>Plantroom 1 /<br>Plantroom 2  | Failure of the duty<br>380V/960V step up<br>transformer at FGP<br>Plantroom 1 or Plantroom 2                         | <ul> <li>Carry out manual<br/>switching to restore the<br/>FGP circuits to be<br/>supplied by backup<br/>transformer.</li> </ul>                                       |
| Loss of 50 Hz<br>power supply to<br>the switch<br>board inside Y1<br>or Y2<br>substation. | Loss of Fixed Ground<br>Power to cargo stands.   | <ul> <li>Informed Line         Maintenance to mobilize         Ground Power Unit to         serve the aircraft as         necessary.</li> </ul>                        |

#### Airport Authority Hong Kong

Business Continuity Manual: BCP – A5. Fixed Ground Power

| ·    |                                      | T ===                                |
|------|--------------------------------------|--------------------------------------|
| Fire | Damage to FGP equipment              | <ul><li>FGP plant room and</li></ul> |
|      | inside FGP plant room or substation. | substations are protected by smoke   |
|      |                                      | detector.                            |

### C Contingency Planning for Fixed Ground Power Mal-functions

- 1.0 Criteria for activating contingency plan
  - 1.1 Upon detecting any irregularity on the Fixed Ground Power (FGP) units inside FGP plant room 1 & 2 or substations Y1 & Y2.
- 2.0 Services and manpower involved
  - 2.1 Handling of FGP equipment shall be provided by trained line maintenance operator.
- 3.0 Contingency Procedures
  - 3.1 When irregularities are detected in any one or both FGP plant rooms
    - i. When irregularities are discovered at any one or more of the centralized frequency converter inside the FGP plant room(s), the fault shall be immediately reported to FRTMO. FRTMO should immediate inform FRT. FRT shall inform maintenance contractor to attend the fault and take corrective action on the faulty FGP unit.
    - ii. When irregularities are discovered at the main FGP switchboards or 380V/960V step up transformers inside the FGP plantroom(s), the fault should immediately report to IAC-ACC and FRTMO. FRT shall immediately inform maintenance contractor to attend the fault and take corrective action on the fault FGP unit. FRT shall report the affected parking stands under the irregularities found to IAC-ACC.
  - 3.2 When irregularities are detected in any one or both of Y1 & Y2 substation.
    - i. When irregularities are discovered at the 50 Hz switch board insideY1 or Y2 substation, the fault shall be immediately reported to FRTMO. FRTMO should immediate inform FRT. FRT shall inform maintenance contractor to attend the fault and take corrective action on the faulty FGP unit. FRT shall report the affected parking stands under the irregularities found to IAC-ACC.
    - ii The Line Maintenance Operator is responsible to ensure that the FGP unit is withdrawn from use if malfunction has occurred

\_\_\_\_\_

- 4.0 Interface with other operational organizations during contingency
  - 4.1 Line Maintenance
  - 4.2 TSI

## D Contingency Procedures during the passage of Tropical Cyclones

- 1.0 Contingency Procedures
  - 1.1 When typhoon signal no. 1 or above is hoisted, maintenance contractor shall be alerted by TSI Typhoon Duty Superintendent or FRT Senior Operation Officer for performing the typhoon precautionary work for all the Fixed Ground Power equipment as when instructed.
  - 1.2 Under the instruction from IAC-ACC, FRT Senior Operation Officer shall notify TSI Typhoon Duty Superintendent and maintenance contractor to perform typhoon precautionary work including tying up and securing the remote crocodile units to anchor points by appropriate equipment and any other precautionary work of FGP deemed necessary by the Employer.
  - 1.3 TSI Typhoon Duty Superintendent shall coordinate with maintenance contractor to provide sufficient manpower as stipulated in the maintenance contract, with all necessary tools and equipment to perform the typhoon precautionary work in a safe and efficient manner.
  - 1.4 After the lowering of typhoon signal no. 3 or under any circumstances considered necessary by IAC-ACC, FRT Senior Operation Officer or TSI Typhoon Duty Superintendent shall instruct the maintenance contractor to untie and reinstate the crocodile units back to the original conditions.
  - 1.5 After lowering of the typhoon signal and completion of the reinstating of all FGP equipment to their normal working condition, TSI Typhoon Duty Superintendent or FRT Senior Operation Officer may official dismiss maintenance contractor's typhoon precautionary team.

## Airport Authority Hong Kong

Business Continuity Manual: BCP – A5. Fixed Ground Power

\_\_\_\_\_

## E. Interface with Other Operational Organizations during Contingency

- 1. Ramp Handling Franchisees;
- 2. Airlines;
- 3. Line Maintenance Franchisees;
- 4. AA TSI

End of BCP - A5