

Fahrzeugnummer: 4734-118				Fzg. ID: 18				Wagen: A - 100				
Switch	Switchport	Usage	VLAN ID	Port Type	IP Adress			IPID	PoE	[W]	Beschriftung TS	Comment
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	Service FIS / CCTV	2	Access	172	17	9	120	120			
	e1-0	Überw. Kamera A7	5	Access	172	18	137	10	10	y	5,0	
	e1-1	Überw. Kamera A2	5	Access	172	18	137	11	11	y	5,0	
	e1-2	Überw. Kamera A1	5	Access	172	18	137	12	12	y	5,0	
	e1-3	Überw. Kamera A5	5	Access	172	18	137	13	13	y	5,0	
	e1-4	Überw. Kamera A9	5	Access	172	18	137	14	14	y	5,0	
	e1-5	AFZ A1	8	Access	172	20	9	5	5	y	10,0	
	e1-6	AFZ A2	8	Access	172	20	9	6	6	y	10,0	
	e1-7				-	-	-	-	-			
	e1-8	Sprechstelle A1	9	Access	172	20	137	5	5	y	7,5	
	e1-9				-	-	-	-	-			
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box A5	90	Access	-	-	-	-	-			
	e1-13	Future use box A6	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige A1	3	Access	172	17	137	25	25			
	e1-15	Seitenanzeige A3	3	Access	172	17	137	26	26			
	e2-0	Bildschirm A7	3	Access	172	17	137	50	50			
	e2-1	Bildschirm A5	3	Access	172	17	137	51	51			
	e2-2	Bildschirm A1	3	Access	172	17	137	52	52			
	e2-3	Bildschirm A3	3	Access	172	17	137	53	53			
	e2-4	ADU A	9	Access	172	20	137	3	3			
	e2-5	Audio Amp. A1	9	Access	172	20	137	21	21			
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2				-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-	-			
	e1-0	Überw. Kamera A8	5	Access	172	18	137	15	15	y	5,0	
	e1-1	Überw. Kamera A4	5	Access	172	18	137	16	16	y	5,0	
	e1-2	Überw. Kamera A3	5	Access	172	18	137	17	17	y	5,0	
	e1-3	Überw. Kamera A6	5	Access	172	18	137	18	18	y	5,0	
	e1-4	Überw. Kamera A10	5	Access	172	18	137	19	19	y	5,0	
	e1-5	AFZ A3	8	Access	172	20	9	7	7	y	10,0	
	e1-6	AFZ A4	8	Access	172	20	9	8	8	y	10,0	
	e1-7	NVR A	5	Access	172	18	137	5	5			
	e1-8	Sprechstelle A2	9	Access	172	20	137	6	6	y	7,5	
	e1-9	Sprechstelle AIR	9	Access	172	20	137	5	5	y	7,5	Redundanz A1
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box A2	90	Access	-	-	-	-	-			
	e1-13	Future use box A4	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige A2	3	Access	172	17	137	27	27			
	e1-15	Seitenanzeige A4	3	Access	172	17	137	28	28			
	e2-0	Bildschirm A8	3	Access	172	17	137	54	54			
	e2-1	Bildschirm A6	3	Access	172	17	137	55	55			
	e2-2	Bildschirm A2	3	Access	172	17	137	56	56			
	e2-3	Bildschirm A4	3	Access	172	17	137	57	57			
	e2-4				-	-	-	-	-			
	e2-5	Audio Amp. A2	9	Access	172	20	137	22	22			
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-	-			
	e1-0	Rücksehkamera A1	5	Access	172	18	137	80	80	y	5,0	
	e1-1	Rücksehkamera A2	5	Access	172	18	137	81	81	y	5,0	
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e1-3				-	-	-	-	-			
	e1-4	Firewall	2	Trunk	172	17	9	1	1			Kein DHCP Statische Konfiguration STADLER
			3		172	17	137	1				
			5		172	18	137	1				
			6		172	19	9	1				
			7		172	19	137	1				
			8		172	20	9	1				
			9		172	20	137	1				
			12		172	22	9	1				
	e1-5				-	-	-	-	-			
	e1-6				-	-	-	-	-			
	e1-7				-	-	-	-	-			
	e1-8				-	-	-	-	-			
	e1-9	Sprechstelle A2R	9	Access	172	20	137	6	6	y	7,5	Redundanz A2
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box A1	90	Access	-	-	-	-	-			
	e1-13	Future use box A3	90	Access	-	-	-	-	-			
	e1-14	Frontanzeige A	3	Access	172	17	137	23	23			
	e1-15				-	-	-	-	-			
	e2-0				-	-	-	-	-			
	e2-1				-	-	-	-	-			
	e2-2				-	-	-	-	-			
	e2-3				-	-	-	-	-			
	e2-4	ADU AR	9	Access	172	20	137	3	3			
	e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127			

G1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202 7	Trunk	-	-	-	-	-				
					172	19	137	2	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	9	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	137	30	30	y	5,0		
	e1-1	Überw. Kamera D2	5	Access	172	18	137	31	31	y	5,0		
	e1-2	Überw. Kamera D1	5	Access	172	18	137	32	32	y	5,0		
	e1-3	Überw. Kamera D5	5	Access	172	18	137	33	33	y	5,0		
	e1-4	Überw. Kamera D9	5	Access	172	18	137	34	34	y	5,0		
	e1-5	AFZ D1	8	Access	172	20	9	14	14	y	10,0		
	e1-6	AFZ D2	8	Access	172	20	9	15	15	y	10,0		
	e1-7	AFZ D5	8	Access	172	20	9	16	16	y	10,0		
	e1-8	Sprechstelle D1	9	Access	172	20	137	10	10	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
e1-14	Seitenanzeige D1	3	Access	172	17	137	33	33					
e1-15	Seitenanzeige D3	3	Access	172	17	137	34	34					
e2-0	Bildschirm D7	3	Access	172	17	137	68	68					
e2-1	Bildschirm D5	3	Access	172	17	137	69	69					
e2-2	Bildschirm D1	3	Access	172	17	137	70	70					
e2-3	Bildschirm D3	3	Access	172	17	137	71	71					
e2-4	Bildschirm D	3	Access	172	17	137	72	72					
e2-5	Audio Amp. D1	9	Access	172	20	137	25	25					
G2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	137	35	35	y	5,0		
	e1-1	Überw. Kamera D4	5	Access	172	18	137	36	36	y	5,0		
	e1-2	Überw. Kamera D3	5	Access	172	18	137	37	37	y	5,0		
	e1-3	Überw. Kamera D6	5	Access	172	18	137	38	38	y	5,0		
	e1-4	Überw. Kamera D10	5	Access	172	18	137	39	39	y	5,0		
	e1-5	AFZ D3	8	Access	172	20	9	17	17	y	10,0		
	e1-6	AFZ D4	8	Access	172	20	9	18	18	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	137	11	11	y	7,5		
	e1-9	Sprechstelle D1R	9	Access	172	20	137	10	10	y	7,5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	137	35	35				
e1-15	Seitenanzeige D4	3	Access	172	17	137	36	36					
e2-0	Bildschirm D8	3	Access	172	17	137	73	73					
e2-1	Bildschirm D6	3	Access	172	17	137	74	74					
e2-2	Bildschirm D2	3	Access	172	17	137	75	75					
e2-3	Bildschirm D4	3	Access	172	17	137	76	76					
e2-4	Bildschirm D11	3	Access	172	17	137	77	77					
e2-5	Audio Amp. D2	9	Access	172	20	137	26	26					
G3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202 7	Trunk	-	-	-	-	-				
					172	19	137	2	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	137	84	84	y	5,0		
	e1-1	Rücksehkamera D2	5	Access	172	18	137	85	85	y	5,0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	137	11	11	y	7,5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2				-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	Service FIS / CCTV	2	Access	172	17	9	123	123			
	e1-0	Überw. Kamera E7	5	Access	172	18	137	40	40	y	5,0	
	e1-1	Überw. Kamera E2	5	Access	172	18	137	41	41	y	5,0	
	e1-2	Überw. Kamera E1	5	Access	172	18	137	42	42	y	5,0	
	e1-3	Überw. Kamera E5	5	Access	172	18	137	43	43	y	5,0	
	e1-4	Überw. Kamera E9	5	Access	172	18	137	44	44	y	5,0	
	e1-5	AFZ E1	8	Access	172	20	9	19	19	y	10,0	
	e1-6	AFZ E2	8	Access	172	20	9	20	20	y	10,0	
	e1-7	AFZ E5	8	Access	172	20	9	21	21	y	10,0	
	e1-8	Sprechstelle E1	9	Access	172	20	137	12	12	y	7,5	
	e1-9				-	-	-	-	-			
	e1-10	Sprechstelle PRM E1	9	Access	172	20	137	13	13	y	7,5	
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	137	16	16	y	7,5	Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-			
	E2	e1-13	Future use box E7	90	Access	-	-	-	-	-		
e1-14		Seitenanzeige E1	3	Access	172	17	137	37	37			
e1-15		Seitenanzeige E3	3	Access	172	17	137	38	38			
e2-0		Bildschirm E7	3	Access	172	17	137	78	78			
e2-1		Bildschirm E5	3	Access	172	17	137	79	79			
e2-2		Bildschirm E1	3	Access	172	17	137	80	80			
e2-3		Bildschirm E3	3	Access	172	17	137	81	81			
e2-4		Bildschirm E	3	Access	172	17	137	82	82			
e2-5		Audio Amp. E1	9	Access	172	20	137	27	27			
e0-0		FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
e0-1		FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
e0-2					-	-	-	-	-			
e0-3					-	-	-	-	-			
e0-4		Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
e0-5		reserved			-	-	-	-	-			
e1-0		Überw. Kamera E8	5	Access	172	18	137	45	45	y	5,0	
e1-1		Überw. Kamera E4	5	Access	172	18	137	46	46	y	5,0	
e1-2		Überw. Kamera E3	5	Access	172	18	137	47	47	y	5,0	
e1-3		Überw. Kamera E6	5	Access	172	18	137	48	48	y	5,0	
E3		e1-4				-	-	-	-	-		
	e1-5	AFZ E3	8	Access	172	20	9	22	22	y	10,0	
	e1-6	AFZ E4	8	Access	172	20	9	23	23	y	10,0	
	e1-7	AFZ E6	8	Access	172	20	9	24	24	y	10,0	
	e1-8	Sprechstelle E2	9	Access	172	20	137	14	14	y	7,5	
	e1-9	Sprechstelle E1R	9	Access	172	20	137	12	12	y	7,5	Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	137	15	15	y	7,5	
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	137	13	13	y	7,5	Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-			
	e1-13	Future use box E4	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige E2	3	Access	172	17	137	39	39			
	e1-15	Seitenanzeige E4	3	Access	172	17	137	40	40			
	e2-0	Bildschirm E8	3	Access	172	17	137	83	83			
	e2-1	Bildschirm E6	3	Access	172	17	137	84	84			
	e2-2	Bildschirm E2	3	Access	172	17	137	85	85			
	e2-3	Bildschirm E4	3	Access	172	17	137	86	86			
	e2-4	Bildschirm E11	3	Access	172	17	137	87	87			
	e2-5	Audio Amp. E2	9	Access	172	20	137	28	28			
	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
e0-2				-	-	-	-	-				
e0-3				-	-	-	-	-				
e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
e0-5	reserved			-	-	-	-	-				
e1-0	Rücksehkamera E1	5	Access	172	18	137	86	86	y	5,0		
e1-1	Rücksehkamera E2	5	Access	172	18	137	87	87	y	5,0		
e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
e1-3				-	-	-	-	-				
e1-4				-	-	-	-	-				
e1-5				-	-	-	-	-				
e1-6				-	-	-	-	-				
e1-7				-	-	-	-	-				
e1-8				-	-	-	-	-				
e1-9	Sprechstelle E2R	9	Access	172	20	137	14	14	y	7,5	Redundanz E2	
e1-10	Sprechstelle PRM WC	9	Access	172	20	137	16	16	y	7,5		
e1-11	Sprechstelle PRM E2R	9	Access	172	20	137	15	15	y	7,5	Redundanz E2	
e1-12	Future use box E1	90	Access	-	-	-	-	-				
e1-13	Future use box E3	90	Access	-	-	-	-	-				
e1-14				-	-	-	-	-				
e1-15				-	-	-	-	-				
e2-0	Energiezähler E	12	Access	172	22	9	3	3				
e2-1				-	-	-	-	-				
e2-2				-	-	-	-	-				
e2-3				-	-	-	-	-				
e2-4				-	-	-	-	-				
e2-5				-	-	-	-	-				

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	9	125	125				
	e1-0	Überw. Kamera B7	5	Access	172	18	137	59	59	y	5,0		
	e1-1	Überw. Kamera B2	5	Access	172	18	137	60	60	y	5,0		
	e1-2	Überw. Kamera B1	5	Access	172	18	137	61	61	y	5,0		
	e1-3	Überw. Kamera B5	5	Access	172	18	137	62	62	y	5,0		
	e1-4	Überw. Kamera B9	5	Access	172	18	137	63	63	y	5,0		
	e1-5	AFZ B1	8	Access	172	20	9	30	30	y	10,0		
	e1-6	AFZ B2	8	Access	172	20	9	31	31	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle B1	9	Access	172	20	137	19	19	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11	ZFR R	2	Access	172	17	9	2	2				
	e1-12	Future use box B5	90	Access	-	-	-	-	-				
	e1-13	Future use box B6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B1	3	Access	172	17	137	45	45				
	e1-15	Seitenanzeige B3	3	Access	172	17	137	46	46				
	e2-0	Bildschirm B7	3	Access	172	17	137	98	98				
	e2-1	Bildschirm B5	3	Access	172	17	137	99	99				
	e2-2	Bildschirm B1	3	Access	172	17	137	100	100				
e2-3	Bildschirm B3	3	Access	172	17	137	101	101					
e2-4	ADU B	9	Access	172	20	137	4	4					
e2-5	Audio Amp. B1	9	Access	172	20	137	31	31					
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera B8	5	Access	172	18	137	64	64	y	5,0		
	e1-1	Überw. Kamera B4	5	Access	172	18	137	65	65	y	5,0		
	e1-2	Überw. Kamera B3	5	Access	172	18	137	66	66	y	5,0		
	e1-3	Überw. Kamera B6	5	Access	172	18	137	67	67	y	5,0		
	e1-4	Überw. Kamera B10	5	Access	172	18	137	68	68	y	5,0		
	e1-5	AFZ B3	8	Access	172	20	9	32	32	y	10,0		
	e1-6	AFZ B4	8	Access	172	20	9	33	33	y	10,0		
	e1-7	NVR B	5	Access	172	18	137	6	6				
	e1-8	Sprechstelle B2	9	Access	172	20	137	20	20	y	7,5		
	e1-9	Sprechstelle B1R	9	Access	172	20	137	19	19	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box B2	90	Access	-	-	-	-	-				
	e1-13	Future use box B4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B2	3	Access	172	17	137	47	47				
	e1-15	Seitenanzeige B4	3	Access	172	17	137	48	48				
	e2-0	Bildschirm B8	3	Access	172	17	137	102	102				
	e2-1	Bildschirm B6	3	Access	172	17	137	103	103				
	e2-2	Bildschirm B2	3	Access	172	17	137	104	104				
e2-3	Bildschirm B4	3	Access	172	17	137	105	105					
e2-4				-	-	-	-	-					
e2-5	Audio Amp. B2	9	Access	172	20	137	32	32					
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera B1	5	Access	172	18	137	90	90	y	5,0		
	e1-1	Rücksehkamera B2	5	Access	172	18	137	91	91	y	5,0		
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle B2R	9	Access	172	20	137	20	20	y	7,5		Redundanz B2
	e1-10				-	-	-	-	-				
	e1-11	ZFR	2	Access	172	17	9	2	2				
	e1-12	Future use box B1	90	Access	-	-	-	-	-				
	e1-13	Future use box B3	90	Access	-	-	-	-	-				
	e1-14	Frontanzeige B	3	Access	172	17	137	24	24				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
e2-3				-	-	-	-	-					
e2-4	ADU BR	9	Access	172	20	137	4	4					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					
Firewall		RCU	2	N/A	172	17	9	126	126			IP festgehalten fuer die RCU.	
			3	N/A	172	17	137	126	126			Diese ist mit der Firewall verbunden.	
			9	N/A	172	20	137	126	126			Anforderung von STADLER	