

Easily 8 Bit Hexa Calculator

จัดทำโดย

นายขวัญชัย	กล่อมเมฆ	09601340
นายปวีณ	สุวรรณสถาน	09601416
นายวิศว	เกตุสุมา	09601464
นายศุภวิชญ์	บุรารักษ์	09601471

เสนอ

อาจารย์ ดร.ณพงศ์ ปณิธานธรรม

รายงานนี้เป็นส่วนหนึ่งของรายวิชาระบบคอมพิวเตอร์และสมองกลฝังตัว (618354-2560)
คณะวิศวกรรมศาสตร์และเทคโนโลยีอุตสาหกรรม สาขาวิชาอิเล็กทรอนิกส์และระบบคอมพิวเตอร์
มหาวิทยาลัยศิลปากร วิทยาเขตพระราชวังสนามจันทร์


ขอบเขตโครงงาน


เครื่องคิดเลขฐาน 16 ขนาด 8 บิต โดยแสดงผลอยู่ในรูปของเลขฐาน 16 สูงสุดจำนวน 2 หลัก โดยมี ฟังก์ชันบวก ลบ คูณ ชิฟซ้าย ชิฟขวาและออน/ซี


อุปกรณ์ (Hardware)


เครื่องคิดเลขฐาน 16 ขนาด 8 บิตประกอบไปด้วยอุปกรณ์ดังนี้


- 1. Microcontroller P16F877A
- 2. Keypad Hex Calculator
- 3. LCD LM016L










































สรุปผลการทำงาน

จากการทำงานของโปรแกรม Easily Hex Calculator จะเริ่มจากการตรวจสอบการกดปุ่ม หากมีการกด ปุ่ม ทางโปรแกรมจะทำการนำตัวเลขที่ได้ไปเก็บไว้เป็นตัวเลข 4 บิตล่างหรือ LOWER1 และเก็บไว้ใน RESULT_L เพื่อรองรับการกระทำฟังก์ชันประเภทชิฟ หลังจากนั้นโปรแกรมจะทำการรอการกดปุ่มอีกครั้ง หากมีการกดปุ่มครั้ง ที่สองสามารถกดเป็นตัวเลขหรือฟังก์ชันใด ๆ ก็ได้ หากเป็นการกดตัวเลขทางโปรแกรมจะนำตัวเลข 4 บิตล่างขึ้น ไปเป็น 4 บิตบนหรือ UPPER1 และเก็บไว้ใน RESULT_H แล้วนำตัวเลขที่รับมาใหม่เก็บเป็น 4 บิตล่างหรือ LOWER1 และเก็บไว้ใน RESULT_L แทน หลังจากนั้นรวมตัวเลขระหว่าง 4 บิตล่างและ 4 บิตเก็บไว้ในตัวแปร NUM1 เมื่อกระทำการเสร็จสิ้น ทางโปรแกรมจะกลับมารอการกดปุ่มอีกครั้ง โดยครั้งนี้จะต้องเป็นการกดเฉพาะปุ่ม ฟังก์ชันเท่านั้น เพื่อให้โปรแกรมเก็บตัวเลขชุดต่อไปไว้ในตัวแปร LOWER2, UPPER2 หรือ NUM2 หากทำการกด ตัวเลขโดยไม่ทำการกดปุ่มฟังก์ชันก่อน โปรแกรมจะไม่สามารถใช้งานได้ หรือ ERROR ทันที โดยข้อเสียของ โปรแกรมนี้ ถ้าหากมีการบวกกันแล้วมีผลลัพธ์เกินจำนวน 8 บิตจะทำให้โปรแกรมแสดงผลลัพธ์ไม่ถูกต้อง รวมถึง การลบกันแล้วเกิด overflow แบบกลับหลัง

```
; HEX_CALCULATOR
```

LIST P=16F877A #INCLUDE "P16F877A.INC"

; CREATE VARIABLE

UPPER1	EQU	0X50
LOWER1	EQU	0X51
UPPER2	EQU	0X52
LOWER2	EQU	0X53
NUM1	EQU	0X54
NUM2	EQU	0X55
TEMP_NUM2	EQU	0X56
RESULT_U	EQU	0X57
RESULT_L	EQU	0X58
SIGN	EQU	0X59
DL_M	EQU	0X60
DL_N	EQU	0X61

; SET VARIABLE

CALL CLEAR VARIABLE

; CONFIGURING AS INPUT AND OUTPUT PORTS

; SELECT BANK1

BSF STATUS, RP0

; FOR KEYPAD CONFIG

BSF TRISC, 0 BSF TRISC, 1 BSF TRISC, 2 BSF TRISC, 3

MOVLW 0XC0 MOVWF TRISB

; FOR LCD CONFIG

BCF TRISC, 5 BCF TRISC, 6 BCF TRISC, 7

; FOR LCD OUTPUT

MOVLW 0X00 MOVWF TRISD

; SELECT BANKO

BCF STATUS, RP0

; MAIN FUNCTION

MAIN CALL CHECK KEYPAD

GOTO MAIN

CHECK KEYPAD

; SCAN THE 1ST COLUMN OF KEYS

BSF PORTB, 0

; HAS THE 0 KEY BEEN PRSSED?

BTFSC PORTC, 0
CALL ZERO

; HAS THE 4 KEY BEEN PRESSED?

BTFSC PORTC, 1
CALL FOUR

; HAS THE 8 KEY BEEN PRESSED?

BTFSC PORTC, 2 CALL EIGHT

; HAS THE 12 KEY BEEN PRESSED?

BTFSC PORTC, 3
CALL TWELVE

BCF PORTB, 0 ; SCAN THE 2ND COLUMN OF KEYS PORTB, 1 BSF ; HAS THE 1 KEY BEEN PRSSED? BTFSC PORTC, 0 ONE ; HAS THE 5 KEY BEEN PRESSED? BTFSC PORTC, 1 CALL **FIVE** ; HAS THE 9 KEY BEEN PRESSED? BTFSC PORTC, 2 CALL NINE ; HAS THE 13 KEY BEEN PRESSED? BTFSC PORTC, 3 CALL THIRTEEN BCF PORTB, 1 ; SCAN THE 3RD COLUMN OF KEYS **BSF** PORTB, 2 ; HAS THE 2 KEY BEEN PRSSED? BTFSC PORTC, 0 CALL TWO ; HAS THE 6 KEY BEEN PRESSED? BTFSC PORTC, 1 CALL SIX ; HAS THE 10 KEY BEEN PRESSED? BTFSC PORTC, 2 CALL TEN

; HAS THE 14 KEY BEEN PRESSED? BTFSC PORTC, 3 CALL FOURTEEN BCF PORTB, 2 ; SCAN THE 4TH COLUMN OF KEYS **BSF** PORTB, 3 ; HAS THE 3 KEY BEEN PRSSED? **BTFSC** PORTC, 0 CALL THREE ; HAS THE 7 KEY BEEN PRESSED? **BTFSC** PORTC, 1 CALL SEVEN ; HAS THE 11 KEY BEEN PRESSED? **BTFSC** PORTC, 2 **CALL** ELEVEN ; HAS THE 15 KEY BEEN PRESSED? BTFSC PORTC, 3 CALL FIFTEEN **BCF** PORTB, 3 ; SCAN THE 5TH COLUMN OF KEYS **BSF** PORTB, 4 ; HAS THE * KEY BEEN PRSSED ? BTFSC PORTC, 0 CALL MUL ; HAS THE LEFT-SHIFT KEY BEEN PRESSED? BTFSC PORTC, 1 CALL LSHIFT

; HAS THE PLUS KEY BEEN PRESSED? BTFSC PORTC, 2 **CALL** PLUS ; HAS THE PLUS KEY BEEN PRESSED? BTFSC PORTC, 3 CALL PLUS BCF PORTB, 4 ; SCAN THE 6TH COLUMN OF KEYS **BSF** PORTB, 5 ; HAS THE ON/OFF KEY BEEN PRSSED? **BTFSC** PORTC, 0 CALL ON ; HAS THE RIGHT-SHIFT KEY BEEN PRESSED? **BTFSC** PORTC, 1 **CALL** RSHIFT ; HAS THE MINUS KEY BEEN PRESSED? BTFSC PORTC, 2 CALL MINUS ; HAS THE EQUAL KEY BEEN PRESSED? BTFSC PORTC, 3
CALL EQUAL **BCF** PORTB, 5 **RETURN**; RETURN TO MAIN FUNCTION ; KEY FUNCTION MOVLW 0X00 ZERO CALL STORE_DATA

D	ISF	LAY	ZERO

MOVLW 0X30 ; ASCII '0'
CALL DISPLAY_DIGIT
RETURN

ONE **MOVLW** 0X01

CALL STORE DATA

DISPLAY ONE

MOVLW 0X31 ; ASCII '1'
CALL DISPLAY_DIGIT
RETURN

TWO MOVLW 0X02

CALL STORE_DATA

DISPLAY TWO

MOVLW 0X32 ; ASCII '2'
CALL DISPLAY_DIGIT
RETURN

THREE MOVLW 0X03

CALL STORE DATA

DISPLAY THREE

MOVLW 0X33 ; ASCII '3'
CALL DISPLAY_DIGIT
RETURN

FOUR **MOVLW** 0X04

CALL STORE_DATA

DISPLAY_FOUR

MOVLW 0X34 ; ASCII '4'
CALL DISPLAY_DIGIT
RETURN

FIVE **MOVLW** 0X05

CALL STORE_DATA

DISPLAY_FIVE

MOVLW 0X35 ; ASCII '5'
CALL DISPLAY_DIGIT
RETURN

SIX	MOVLW CALL	0X06 STORE_DATA
DISPLAY_SIX	MOVLW CALL RETURN	0X36 ; ASCII '6' DISPLAY_DIGIT
SEVEN	MOVLW CALL	0X07 STORE_DATA
DISPLAY_SEVE	MOVLW CALL RETURN	0X37 ; ASCII '7' DISPLAY_DIGIT
EIGHT	MOVLW CALL	0X08 STORE_DATA
DISPLAY_EIGH	T MOVLW CALL RETURN	0X38 ; ASCII '8' DISPLAY_DIGIT
NINE	MOVLW CALL	0X09 STORE_DATA
DISPLAY_NINE	MOVLW CALL RETURN	0X39 ; ASCII '9' DISPLAY_DIGIT
TEN	MOVLW CALL	0X0A STORE_DATA
DISPLAY_TEN	MOVLW CALL RETURN	0X41 ; ASCII 'A' DISPLAY_DIGIT
ELEVEN	MOVLW CALL	0X0B STORE_DATA
DISPLAY_ELEV	EN Movlw Call	0X42 ; ASCII 'B' DISPLAY_DIGIT

RETURN

TWELVE	MOVLW CALL	0X0C STORE_DATA
DISPLAY_TWEL	_VE MOVLW CALL RETURN	0X43; ASCII 'C' DISPLAY_DIGIT
THIRTEEN	MOVLW CALL	0X0D STORE_DATA
DISPLAY_THIR	TEEN MOVLW CALL RETURN	0X44 ; ASCII 'D' DISPLAY_DIGIT
FOURTEEN	MOVLW CALL	0X0E STORE DATA
DISPLAY_FOUF	RTEEN MOVLW CALL RETURN	- 0X45 ; ASCII 'E' DISPLAY_DIGIT
FIFTEEN	MOVLW CALL	0X0F STORE DATA
DISPLAY_FIFTE	EN MOVLW CALL RETURN	OX46; ASCII 'F' DISPLAY_DIGIT
•		
; FUNCTION PLUS	MOVLW MOVWF MOVLW CALL RETURN	0X10 ; 'xxx1 xx00' SIGN 0X2B ; ASCII '+' DISPLAY_DIGIT
MINUS	MOVLW	0X11 ; 'xxx1 xx01'

	MOVWF MOVLW CALL RETURN	
MUL	MOVLW MOVWF MOVLW CALL RETURN	SIGN
LSHIFT	MOVLW CALL	0X3C DISPLAY_DIGIT
	BCF RLF BTFSC BSF BCF RLF BCF	STATUS, C RESULT_L, 4
	MOVF CALL MOVF CALL BCF RETURN	DIGIT_N RESULT_L, W
RSHIFT	MOVLW CALL	0X3E DISPLAY_DIGIT
	BCF RRF BTFSC BSF BCF RRF BCF	STATUS, C RESULT_U, F STATUS, C RESULT_L, 4 STATUS, C RESULT_L, F STATUS, C

	MOVF CALL	RESULT_U, W DIGIT_N	
		RESULT_L, W	
	CALL	_	
	RETURN	STATUS, C	
FOLIAL	MOVIA	0.72.0	
EQUAL	MOVLW CALL	DISPLAY_DIGIT	
		CONDITION	
	RETURN		
ON	MOVLW	0X01	
		DISPLAY	
	CALL RETURN	CLEAR_VARIABLE	
	KETOKK		
;======================================			
,=======			
;====== CLEAR_VARI	ABLE		
,	ABLE CLRF	UPPER1	
,	ABLE CLRF CLRF	UPPER1 LOWER1	
,	ABLE CLRF CLRF CLRF	UPPER1	
,	ABLE CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1	
,	ABLE CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2	
,	ABLE CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2	
,	ABLE CLRF CLRF CLRF CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2 RESULT_U RESULT_L	
,	ABLE CLRF CLRF CLRF CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2 RESULT_U RESULT_L SIGN	
,	ABLE CLRF CLRF CLRF CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2 RESULT_U RESULT_L SIGN DL_M	
,	ABLE CLRF CLRF CLRF CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2 RESULT_U RESULT_L SIGN	
,	ABLE CLRF CLRF CLRF CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2 RESULT_U RESULT_L SIGN DL_M	
,	ABLE CLRF CLRF CLRF CLRF CLRF CLRF CLRF CLRF	UPPER1 LOWER1 UPPER2 LOWER2 NUM1 NUM2 TEMP_NUM2 RESULT_U RESULT_L SIGN DL_M	

DIGIT_N PCL, F **ADDWF** DISPLAY_ZERO **GOTO** DISPLAY_ONE **GOTO** DISPLAY_TWO **GOTO**

GOTO	DISPLAY_THREE
GOTO	DISPLAY_FOUR
GOTO	DISPLAY_FIVE
GOTO	DISPLAY_SIX
GOTO	DISPLAY_SEVEN
GOTO	DISPLAY_EIGHT
GOTO	DISPLAY_NINE
GOTO	DISPLAY_TEN
GOTO	DISPLAY_ELEVEN
GOTO	DISPLAY_TWELVE
GOTO	DISPLAY_THIRTEEN
GOTO	DISPLAY_FOURTEEN
GOTO	DISPLAY FIFTEEN

CONDITION BTFSS SIGN, 1

GOTO PLUS_MINUS_FN

GOTO MUL_FN

PLUS_MINUS_FN

BTFSS SIGN, 0
GOTO PLUS_FN
GOTO MINUS_FN

PLUS_FN **MOVF** LOWER2, W

ADDWF LOWER1, W RESULT_L RESULT L, 4

INCF UPPER2, F
BCF RESULT_L, 4
MOVF UPPER2, W

ADDWF UPPER1, W

MOVWF RESULT_U CALL DIGIT N

MOVF RESULT_L, W

CALL DIGIT_N

CALL NEW DATA

RETURN

MINUS_FN	SUBWF MOVWF	RESULT_L RESULT_L, 7 UPPER1, F 0X0F RESULT_L, F; CLEAR BIT7 - BIT4 UPPER2, W
	CALL	RESULT_U DIGIT_N RESULT_L, W DIGIT_N
	CALL RETURN	NEW_DATA
MUL_FN	MOVWF	TEMP_NUM2 UPPER1, W RESULT_U LOWER1, W
LOOP_LO	DECF BTFSC GOTO ADDWF BTFSC INCF BCF GOTO	_ ,
	MOVF MOVWF MOVF ; W = UPPE	UPPER1, W

LOOP_UP	DECF BTFSC GOTO ADDWF GOTO	\$+3
	MOVF CALL MOVF CALL	RESULT_U, W DIGIT_N RESULT_L, W DIGIT_N
	CALL RETURN	NEW_DATA
;=======	=======	=======================================
STORE_DATA	BTFSS GOTO GOTO	SIGN, 4 NUM1_FN NUM2_FN
NUM1_FN	BTFSS GOTO GOTO	SIGN, 7 LOWER1_FN UPPER1_FN
NUM2_FN	BTFSS GOTO GOTO	SIGN, 6 LOWER2_FN UPPER2_FN
LOWER1_FN	MOVWF MOVWF MOVWF BSF RETURN	NUM1
UPPER1_FN		UPPER1 RESULT_U RESULT_L, W

	SWAPF IORWF MOVWF BCF RETURN	LOWER1, W
LOWER2_FN	MOVWF MOVWF MOVWF BSF RETURN	NUM2
UPPER2_FN	MOVWF MOVWF MOVWF MOVF MOVWF	LOWER2, W UPPER2 RESULT_U RESULT_L, W
	SWAPE	HPPER2 W

SWAPF UPPER2, W IORWF LOWER2, W

MOVWF NUM2 **BCF** SIGN, 6

RETURN

NEW_DATA **MOVF** RESULT_U, W

MOVWF UPPER1

MOVF RESULT_L, W

MOVWF LOWER1
CLRF SIGN

RETURN

; DISPLAY THE DIGIT IN THE 7SEGMENT ; IF

; RS=0 INSTRUCTION COMMAND CODE REGISTER IS SELECTED, ALLOWING USER TO SEND COMMAND

; RS=1 DATA REGISTER IS SELECTED ALLOWING TO SEND DATA THAT HAS TO BE DISPLAYED.

; R\W=0 READING ; R\W=1 WRITING

: E- ENABLE

; THE ENABLE PIN IS USED BY THE LCD TO LATCH INFORMATION AT ITS DATA PINS. WHEN DATA IS SUPPLIED TO DATA PINS.

; A HIGH TO LOW PULSE MUST BE APPLIED TO THIS PIN IN ORDER FOR THE LCD TO LATCH THE DATA PRESENT IN THE DATA PINS.

; E SHOULD TOGGLE

; DATA MODE: RS=1, R\W=0, E=1\0

DISPLAY DIGIT

BSF PORTC, 5 ; CONTROL SIGNAL TO RS
BCF PORTC, 6 ; CONTROL SIGNAL TO R/W

BSF PORTC, 7; CONTROL SIGNAL TO ENABLE

CALL DISPLAY

MOVLW 0X38 ; INITIALISES THE DISPLAY

CALL DISPLAY

MOVLW 0X0E; DON'T BLINK THE CURSOR

CALL DISPLAY

BSF PORTC, 5

RETURN

DISPLAY MOVWF PORTD

; SEND DATA TO DATA PINS

BCF PORTC, 7
CALL DELAY

BSF PORTC, 7
CALL DELAY

; SELECT COMMAND REGISTER

BCF PORTC, 5

RETURN

DELAY	MOVLW	0X0D; VERY SMALL DELAY
	MOVWF	DL_N
	MOVLW	0XFB
	MOVWF	DL_M
LOOP	DECFSZ	DL_M
	GOTO	LOOP
	DECFSZ	DL_N
	GOTO	LOOP
	RETURN	
	END	