Z21: Zentrale => PC

2.7	NotAus()	LAN_X_BC_TRACK_POWER_OFF	`0x61 0x00`	
2.8	AllesAn()	LAN_X_BC_TRACK_POWER_ON	`0x61 0x01`	
2.9	ProgrammierMode()	LAN_X_BC_PROGRAMMING_MODE	`0x61 0x02`	
2.10	ProgrammierinfoKurzschluss()	LAN_X_BC_TRACK_SHORT_CIRCUIT	`0x61 0x08`	
2.11	Logfile.Warnings "Befehl in Zentrale nicht vorhanden"	LAN_X_UNKNOWN_COMMAND	`0x61 0x82`	
2.12	NotHalt() / NotAus() / ProgrammierMode() / Logfile.Errors "Ram Check Fehler"	LAN_X_STATUS_CHANGED	`0x62 0x22 Status`	
2.14	NotHalt()	LAN_X_BC_STOPPED	`0x81 0x00`	
4.4	Z21Lokinfo(ByVal Address As Integer, ByVal Besetzt As Boolean, ByVal Speedsteps As Integer, ByVal Speed As Integer, ByVal Forward As Boolean, ByVal F0_F4 As Byte, ByVal F5_F8 As Byte, ByVal F9_F12 As Byte, ByVal F13_F20 As Byte, ByVal F21_F28 As Byte)	LAN_X_LOCO_INFO	`0xEF Lokinfo`	`Length klopt niet`
5.3	SwitchFeedback(ByVal address As Integer, ByVal ttBits As Byte, ByVal iBit As Byte, ByVal data As Byte)	LAN_X_TURNOUT_INFO	`0x43 FAdrMSB FAdrLSB 000000ZZ`	
5.6	ExtendedAccessoryInfo(ByVal address As Integer, ByVal Value As Byte, ByVal Status As Byte)	LAN_X_EXT_ACCESSORY_INFO	`0x44 FAdrMSB FAdrLSB DDDDDDDD Status`	
6.3	ProgrammierinfoKurzschluss()	LAN_X_CV_NACK_SC	`0x61 0x12`	
6.4	ProgrammierinfoDatenNichtGefunden()	LAN_X_CV_NACK	`0x61 0x13`	
6.5	ProgrammierinfoCV(ByVal CV As Integer, ByVal Value As Byte)	LAN_X_CV_RESULT	`0x64 0x14 CVAdr_MSB CVAdr_LSB Value`	
2.3	ZentraleVersion(ByVal version As String)	Antwort auf LAN_X_GET_VERSION	`0x63 0x21 XBUS_VER CMDST_ID`	
2.15	z21FirmwareVersion(ByVal version As String)	Antwort auf LAN_X_GET_FIRMWARE_VERSION	`0xF3 0x0A V_MSB V_LSB`	