

UnitInputData Attribute Documentation



Version: GPC.EU Customer 2026.1-310 (64 Bit)

	Name	UsedUnit	InfoText	Datatype	Group
1	AdjustableFlapWithDrive	None	Indicates whether a louvre, also known as a defrost flap made of galvanized steel and with drive is required as an accessory.	Int32	Options
	<i>0</i> <i>Indicates that the louvre is not necessarily needed.</i> <i>1</i> <i>Indicates that the louvre is definitely needed.</i>				
2	AirBlowOffType	None	Specifies the air blow direction (only relevant for Downblow Accessory)	Int32	Options
	<i>0</i> <i>no restrictions</i> <i>1</i> <i>vertically up</i> <i>2</i> <i>horizontally</i> <i>3</i> <i>45° down</i> <i>4</i> <i>vertically down</i>				
3	AirDuct	None	Indicates whether an air duct is required as an accessory.	Int32	Options
	<i>0</i> <i>Indicates that the air duct is not necessarily needed.</i> <i>1</i> <i>Indicates that the air duct is definitely needed.</i>				
4	AirHoseConnection	None	Indicates whether a air sock connection without Güntner Streamer is required as an accessory.	Int32	Options
	<i>0</i> <i>Indicates that the air sock connection is not necessarily needed.</i> <i>1</i> <i>Indicates that the air sock connection is definitely needed.</i>				
5	AirHoseConnectionInclStreamer	None	Indicates whether a air sock connection with Güntner Streamer is required as an accessory.	Int32	Options
	<i>0</i> <i>Indicates that the air sock connection is not necessarily needed.</i> <i>1</i> <i>Indicates that the air sock connection is definitely needed.</i>				

	Name	UsedUnit	InfoText	Datatype	Group
6	AirHumidityInputMode	None	Defines the input mode for the air humidity.	Int32	Thermodynamics
	<i>0</i> <i>1</i> <i>2</i>				
	<i>MODE_AUTO</i> Relative humidity will be calculated automatically <i>MODE_REL_HUMIDITY</i> AirRelHumidity must be set <i>MODE_WET_BULB_TEMP</i> AirWetBulbTemp must be set				
7	AirPressure	mbar	Defines the air pressure at the inlet.	Double	Thermodynamics
8	AirPressureInputMode	None	Defines the input mode for the air pressure. Accordingly, either the AirPressure or Altitude input parameter is relevant/used.	Int32	Thermodynamics
	<i>0</i> <i>1</i>				
	<i>to define the air pressure itself</i> <i>to define the geodetic height/altitude = height above sea level</i>				
9	AirRelHumidity	Percent	Defines the relative air humidity at the inlet.	Double	Thermodynamics
10	AirTemperature	Degree_C	Defines the air temperature. Which air temperature (inlet, room as average between inlet/outlet, room as LMTD) is defined, depends on the AirTemperatureMode.	Double	Thermodynamics
11	AirTemperatureMode	None	Defines the input mode for the air temperature.	Int32	Thermodynamics
	<i>0</i> <i>1</i> <i>2</i>				
	<i>to define the air inlet temperature.</i> <i>to define the room temperature of the air as mean value between inlet and outlet</i> <i>to define the room temperature of the air as LMTD, with room temperature (LMTD) = t_0 + LMTD (was only temporarily allowed for ProductCategory 1 for Guntner America and until April 2010) [???</i>				
12	AirVelocityClass	None	Defines the air velocity class (only relevant if UnitSelectionMode = 0 (unit search mode) and ProductCategory = 0,1,2 (evaporator or aircooler (brine))).	Int32	Options
	<i>0</i> <i>1</i> <i>2</i> <i>3</i>				
	<i>no restrictions (mapped to AIR_VELOCITY_CLASS_ALL)</i> <i>standard air velocity</i> <i>high air velocity (only suitable for low temperatures)</i> <i>low air velocity (e.g. used for processing rooms)</i>				
13	AirWetBulbTemp	Degree_C	Defines the wet bulb temperature = lowest temperature that can be achieved by evaporation	Double	Thermodynamics
14	Altitude	m	Defines the height above sea level = geodetic height/altitude.	Double	Thermodynamics

	Name	UsedUnit	InfoText	Datatype	Group
15	AxitopFans	None	Indicates whether a diffuser for the fans, also known as a Axitop, is required as an accessory.	Int32	Unknown
	0 Indicates that the diffuser is not necessarily needed. 1 Indicates that the diffuser is definitely needed.				
16	Ball_Valve_Half_For_Ventilation	None	Indicates whether a ball valve 1/2" for ventilation/drain is required as an accessory.	Int32	Options
	0 Indicates that the ball valve is not necessarily needed. 1 Indicates that the ball valve is definitely needed.				
17	BaseUnitFunction	None	Defines the needed product category	Int32	Startpage
	0 DX evaporator (Cold Indoor) 1 Flooded evaporator (Cold Indoor) 10 DX evaporator heat collector (Heat Collectors, Outdoor) 2 Flooded evaporator (Cold Indoor) 3 Condenser (Warm Outdoor) 4 Brine cooler (Warm Outdoor) 5 Sub cooler (Warm Outdoor) 6 Oil cooler (Warm Outdoor) 7 Gas cooler (Warm Outdoor) 8 One phase air cooler heat collector (Heat Collectors, Outdoor) 9 Flooded evaporator heat collector (Heat Collectors, Outdoor)				
18	BaseUnitID	None	Defines the BaseUnitID, which is needed only for the recalculation of KDB units (UnitSelectionMode = 1 = recalculation of existing unit). Has to be taken from the output of a given selection.	Int64	Recalculation
19	BrineDefrostConcentration	VolPercent	Defines the concentration of the warm brine defrost fluid.	Double	Unknown
20	BrineDefrostFluid	None	Defines the fluid used for the warm brine defrost accessory. Relevant only, if accessory "warm brine defrost" is selected.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
21	BrineDefrostPressuredrop	bar	Defines the pressure drop of the warm brine defrost fluid. Relevant only, if accessory "warm brine defrost" is selected.	Double	Unknown
22	CanvasSleeves	None	Indicates whether canvas sleeves are required as an accessory.	Int32	Unknown
	0		<i>Indicates that the canvas sleeves are not necessarily needed.</i>		
	1		<i>Indicates that the canvas sleeves are definitely needed.</i>		
23	CapacitySensibleHeatOnly	None	Additional flag for the thermal capacity, whether it defines only the sensible heat. Used only for America. Sensible heat refers to the thermal energy that is added to or removed from a system without a phase transition taking place. It is the heat that directly influences the temperature of a substance without changing its physical state. The formula ""Sensible heat = total power - heat of condensation"" shows how to calculate sensible heat by subtracting the total power of a system from the heat of condensation.	Boolean	Thermodynamics
	FALSE		<i>ThermalCapacity defines the completely needed thermal capacity.</i>		
	TRUE		<i>ThermalCapacity defines the sensible heat only.</i>		
24	CasingAndDoubleTray	None	Indicates whether a casing and a double tray made of stainless steel are required as an accessory.	Int32	Unknown
	0		<i>Indicates that they are not necessarily needed.</i>		
	1		<i>Indicates that they are definitely needed.</i>		
25	CasingAndFullCoverageDoubleTraySS	None	Indicates whether a casing and a full coverage double tray made of stainless steel are required as an accessory.	Int32	Unknown
	0		<i>Indicates that they are not necessarily needed.</i>		
	1		<i>Indicates that they are definitely needed.</i>		
26	CasingAndHygienicDoubleTraySS	None	Indicates whether a casing and a hygienic double tray made of stainless steel are required as an accessory.	Int32	Unknown
	0		<i>Indicates that they are not necessarily needed.</i>		
	1		<i>Indicates that they are definitely needed.</i>		

	Name	UsedUnit	InfoText	Datatype	Group
27	CasingAndSimplyTray	None	Indicates whether a casing and a simple tray made of stainless steel are required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i> Indicates that they are not necessarily needed. Indicates that they are definitely needed.				
28	ClimaCoilOption	None	Defines whether a climatization coil is selected, which is needed only for the recalculation of TDB units (UnitSelectionMode = 1 = recalculation of existing unit). Has to be taken from the output of a given selection.	Int32	Unknown
29	ClimatizationCoil	None	Indicates whether a climatization coil is required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i> Indicates that it is not necessarily needed. Indicates that it is definitely needed.				
30	Coil_Defender	None	Indicates whether a Coil Defender is required as an accessory, which means that the heat exchanger incl. connection system is fully powder-coated to extend the service life of the product thanks to optimum corrosion protection.	Int32	Unknown
	<i>0</i> <i>1</i> Indicates that it is not necessarily needed. Indicates that it is definitely needed.				
31	CoilDefrostType	None	Defines which specific type of coil defrost is selected, which is needed only for the recalculation of TDB units (UnitSelectionMode = 1 = recalculation of existing unit). Has to be taken from the output of a given selection.	Int64	Unknown
32	ConceptName	None	Defines the ConceptName of the unit, which is needed for the recalculation of KDB units (UnitSelectionMode = 1 = recalculation of existing unit). Has to be taken from the output of a given selection.	String	Recalculation
33	CondensatePump	None	Indicates whether a condensate pump is required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i> Indicates that it is not necessarily needed. Indicates that it is definitely needed.				
34	ConnectionAndBowCovering	None	Indicates whether a connection and bow covering is required as an accessory.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	0 1		<i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>		
35	ConnectionRoof	None	Indicates whether a header cover, also known as a connection roof, is required as an accessory.	Int32	Unknown
	0 1		<i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>		
36	ConnectionSystem	None	Indicates whether a thread or flange connection is required as an accessory.	Boolean	Unknown
	0 1		<i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>		
37	ConnectionType	None	Defines which type of thread or flange connection is required as an accessory, if it is required via ConnectionSystem = true.	Int32	Unknown
	3 4 5		<i>Lapped flanges</i> <i>Welding neck flanges</i> <i>Thread connection</i>		
38	ContainerTransportRail	None	Indicates whether guide rails for container transport are required as an accessory	Int32	Unknown
	0 1		<i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>		
39	ControllerAllocation	None	If a switch cabinet or terminal box is selected, this defines the allocation of the controller to the unit:	Int32	Unknown
	1 3 4 5		<i>Allocation is set automatically</i> <i>One controller per unit</i> <i>One controller per fluid circuit</i> <i>No controller selected</i>		
40	ControllerByPassObligato ry	None	Specifies if a bypass is required for the controller.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	0		<i>Bypass is not needed</i>		
	1		<i>Bypass is needed</i>		
41	ControllerInterface	None	Defines the required interface for the controller	Int32	Unknown
	1		<i>Undefined</i>		
	2		<i>No Interface needed</i>		
	3		<i>Modbus RTU</i>		
	4		<i>Profibus DP</i>		
	5		<i>Profinet</i>		
	6		<i>Bacnet IP</i>		
	7		<i>Bacnet MS/TP</i>		
42	ControllerType	None	Defines the needed controller type	Int32	Unknown
	10		<i>GMM EC with remote display (only for EC fans)</i>		
	2		<i>Controller type is selected automatically</i>		
	3		<i>Only continuous controllers (EC, sinus or phase cut controllers)</i>		
	4		<i>Phase cut (only for AC fans)</i>		
	6		<i>Step controller (only for AC fans)</i>		
	7		<i>GMM EC (only for EC fans)</i>		
	8		<i>GMM Sincon lite (only for AC fans)</i>		
	9		<i>GMM phase cut lite (only for AC fans)</i>		
43	CoreTubeMaterial	None	Defines the needed core tube material (without inner structure type). Only relevant if UnitSelectionMode = 0 (unit search mode).	Int32	Unknown
	0		<i>no restriction</i>		
	C		<i>Copper</i>		
	F		<i>Hot dip galvanized steel</i>		
	V		<i>Stainless steel type A (normal quality)</i>		
	W		<i>Stainless steel type B (higher quality)</i>		
	Z		<i>Galvanized steel</i>		

	Name	UsedUnit	InfoText	Datatype	Group
44	CorrosionProtectionClass	None	Defines the needed corrosion protection class	Int32	Unknown
	<i>0</i> <i>335</i> <i>336</i> <i>no special corrosion protection class needed</i> <i>corrosion protection class 4 needed</i> <i>corrosion protection class 5 needed</i>				
45	CountryID_HydroPad	None	Defines for which country, specified via an ID, the option hydroBLU, known also as HydroPad or evaporative cooling pad, (or the option hydroSPRAY???) the thermodynamics should be calculated, if it is selected.	Int32	Hydro
46	DefaultIndoorVarnishing	None	Indicates whether for a unit, which as standard is not varnished, the option “varnishing with the standard indoor color” [e.g. Europe: 9003] is required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i> <i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>				
47	DefaultOutdoorVarnishing	None	Indicates whether for a unit, which as standard is not varnished, the option “varnishing with the standard outdoor color” is required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i> <i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>				
48	DefrostFlap	None	Indicates whether a defrost flap with heated frame is required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i> <i>Indicates that it is not necessarily needed.</i> <i>Indicates that it is definitely needed.</i>				
49	Defrosting	None	Defines the needed standard defrosting.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	0 258 263 264 265 339 80		<i>No defrosting needed</i> <i>Electric defrost kit to be installed by customer</i> <i>Electric defrost mounted and wired at factory (meta option, no details for coil or tray).</i> <i>Hot gas defrost (meta option, no details for coil or tray).</i> <i>Warm brine defrost (meta option, no details for coil or tray).</i> <i>Electric defrost efficiency-optimized (meta option, no details for coil or tray).</i> <i>Air Defrost</i>		
50	DefrostingHotGasFeed	None	Defines explicitly the position of the feed of the hot gas defrost in coil. Currently this is only used, if a user defined defrosting is selected, and there a hot gas defrosting in coil or hot gas defrosting without connection is selected, and it's a unit for the Eurasian market.	Int32	Unknown
	0 1 2		<i>Feed at the top</i> <i>Feed at the bottom</i> <i>Feed at the center</i>		
51	DefrostingUserDefined	None	Defines the needed user defined defrosting. Empty list: no user defined defrosting. Otherwise: List of defrosting options, selected via their IDs.	List`1	Unknown
	11 12 13 14 23 261 262 264 312 338 340 73 74		<i>Electric defrost coil (standard)</i> <i>Electric defrost tray (standard)</i> <i>Hot gas defrost coil (standard)</i> <i>Hot gas defrost tray (standard)</i> <i>Electric defrost in coil and tray (combined).</i> <i>Warm brine defrost coil</i> <i>Warm brine defrost tray</i> <i>Hot gas defrost (meta option, no details for coil or tray).</i> <i>El. defrost coil light for t0>=-10°C</i> <i>Electric defrost in coil and tray efficiency-optimized (combined).</i> <i>Electric defrost kit to be installed by customer efficiency-optimized</i> <i>Electric defrost coil heavy for t0<=-40°C</i> <i>Electric defrost tray heavy for t0<=-40°C</i>		

	Name	UsedUnit	InfoText	Datatype	Group
52	DeliveryTimeFilter	WorkDays	Defines the delivery time filter type	Int32	Limitations
	-1 <i>Only available units</i> -2 <i>Only units that are in stock</i> 0 <i>No filter defined</i> 1 <i>Unit shipped within 1 business day</i> 2 <i>Unit shipped within 2 business days</i> 3 <i>Unit shipped within 3 business days</i> 4 <i>Unit shipped within 4 business days</i> 5 <i>Unit shipped within 5 business days</i> 6 <i>Unit shipped within 6 business days</i>				
53	DoubleFanPlates	None	Defines whether a set of double fan plates is required as an accessory:	Int32	Unknown
	0 <i>Indicates that it is not necessarily needed.</i> 1 <i>Indicates that it is definitely needed.</i>				
54	DoubleTrayInsulated	None	Defines whether an insulated double tray is required as an accessory.	Int32	Unknown
	0 <i>Indicates that it is not necessarily needed.</i> 1 <i>Indicates that it is definitely needed.</i>				
55	ECFanOption	None	Specifies whether the unit must have fans with EC motor technology.	Int32	Unknown
	0 <i>EC technology is not required.</i> 1 <i>EC technology is required.</i>				
56	ECJunctionBoxWithMainSwitch	None	If there is the controls accessory "EC junction box" selected (when SwitchCabinetType=8) then this value specifies whether the junction box must have a main switch.	Int32	Unknown
	0 <i>Main switch is not required</i> 1 <i>Main switch is required</i>				
57	EfficiencyClass	None	Specifies the at least required efficiency class of the found units.	String	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	<i>A</i> <i>A+</i> <i>A++</i> <i>B</i> <i>C</i> <i>D</i> <i>E</i>		<i>No filter defined { get; set; } All efficiency classes allowed</i> <i>Only units with efficiency class A or better should be found</i> <i>Only units with efficiency class A+ or better should be found</i> <i>Only units with efficiency class A++ or better should be found</i> <i>Only units with efficiency class B or better should be found</i> <i>Only units with efficiency class C or better should be found</i> <i>Only units with efficiency class D or better should be found</i> <i>Only units with efficiency class E or better should be found</i>		
58	EmptyCasing	None	Specifies whether an the accessory empty casing is required	Int32	Unknown
	<i>0</i> <i>1</i>		<i>an empty casing is not required</i> <i>an empty casing is required</i>		
59	EmptyCasingBottomSheet	None	If an empty casing is selected this value defines whether a bottom sheet must be included	Boolean	Unknown
	<i>0</i> <i>1</i>		<i>A bottom sheet is not required</i> <i>A bottom sheet is required</i>		
60	EmptyCasingHeight	mm	If an empty casing is selected this value defines the required height of the empty casing in mm	Int32	Unknown
61	EmptyCasingIsolation	None	If an empty casing is selected this value defines whether an isolation must be included	Boolean	Unknown
	<i>0</i> <i>1</i>		<i>An isolation is not required</i> <i>An isolation is required</i>		
62	EmptyCasingLength	mm	If an empty casing is selected this value defines the required length of the empty casing in mm	Int32	Unknown
63	EnableForMounting	None	If there is any switch cabinet or terminal box selected, then this value specifies whether it must be mountable.	Int32	Unknown
	<i>0</i> <i>1</i>		<i>AirHeater: The switch cabinet or terminal box does not have to be mountable. AirCooler: 0-10V signal not required.</i> <i>AirHeater: The switch cabinet or terminal box must be mountable. AirCooler: 0-10V signal required (only EC!)</i>		
64	Epoxy_Fins	None	Indicates whether epoxy fins are required.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
65	ErP_Compliant	mm	Filter to show only units that apply to EU's Energy-Related Products Directive (ErP Directive 2009/125/EC).	Boolean	Unknown
66	ESPMax	Pa	Upper limit for external static pressure. (Used in GPC.AM.)	Double	Options
67	ESPMin	Pa	Lower limit for external static pressure. (Used in GPC.AM.)	Double	Options
68	EspMinMaxDescription	None	String that can describe the lower and upper limit for external static pressure. (Used in GPC.AM.)	String	Options
69	ExhaustDuct	None	Indicates whether an exhaust duct is required as an accessory.	Int32	Unknown
70	ExtendedLegs	None	Defines the length of (extended) legs.	Int32	Unknown
	213 214 6 7 8		<i>Set of extended legs 1100 mm</i> <i>Set of extended legs 1200 mm</i> <i>Set of extended legs 600 mm</i> <i>Set of extended legs 800 mm</i> <i>Set of extended legs 1000 mm</i>		
71	ExternalPressing	Pa	External static pressing (ESP) for standard fans (only for KDB units).	Double	Options
72	FanFuseSpec	None	Defines the fan protection.	Int32	Unknown
	0 1 2 3 4 5 6 7		<i>Undefined</i> <i>Consider all types</i> <i>Best price</i> <i>High fail safe</i> <i>Fans individually fused</i> <i>Up to two fans per fuse</i> <i>Up to four fans per fuse</i> <i>Up to three fans per fuse</i>		
73	FanRingHeater	None	Indicates whether fan ring heaters are required as an accessory.	Int32	Unknown
74	FinConinID	None	Specifies the internal FinConinID.	Int32	Unknown
75	FinPitch0Max	mm	Max. fin pitch	Double	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
76	FinPitch0Min	mm	Min. fin pitch	Double	Unknown
77	FinPitchVariableOnly	None	Specifies whether there should only units with variable (staged) fin pitch (different fin pitch values within one unit)	Int32	Unknown
	0 1 No restriction for the fin pitch Only units with variable fin pitch should be found				
78	FinSpacingInputMode	None	Defines the mode how the fin spacing filter is specified in the input data	Int32	Unknown
	0 1 Minimum and maximum fin spacing is given (FinPitch0Min and FinPitch0Max must contain the minimum and maximum fin spacing values in mm) Minimum and maximum number of fins per inc is given (FinPitch0Min and FinPitch0Max must contain the minimum and maximum number of fins per inch)				
79	FluidID	None	Defines the ID number of the fluid, that is used in the heat exchanger's main or first circuit.	Int32	Thermodynamics
80	FluidID_2	None	Defines the ID number of the fluid, that is used in the heat exchanger's second circuit when multiple circuits option is selected.	Int32	Thermodynamics
81	FluidInputMode	None	Defines the input modes for the fluid that says, which input values for the fluid must be set. This value is needed when ProductCategory is 3, 5 or 6 (air cooler for coolant, fluid cooler, sub cooler). For ProductCategory 6 (sub cooler), only FluidInputMode 0 is allowed.	Int32	Thermodynamics
	0 1 2 3 4 5 6 FluidTempInlet and FluidTempOutlet must be set FluidTempInlet and FluidVolumeFlow must be set FluidTempOutlet and FluidVolumeFlow must be set FluidTempInlet and FluidPressureDropMax must be set FluidTempOutlet and FluidPressureDropMax must be set FluidTempInlet and FluidMassFlow must be set FluidTempOutlet and FluidMassFlow must be set				
82	FluidMassFlow	kg_per_h	Defines the mass flow of the fluid. This value is needed, when FluidInputMode is 5 (FluidTempInlet and FluidMassFlow) or 6 (FluidTempOutlet and FluidVolumeFlow)	Double	Thermodynamics
83	FluidPressure	mbar	Defines the pressure of the fluid. This value is needed for ProductCategory 0 (DX evaporator) or 10 (gas cooler).	Double	Thermodynamics

	Name	UsedUnit	InfoText	Datatype	Group
84	FluidPressureDropMax	K_TD	Defines the maximum allowed pressure drop of the fluid inside the heat exchanger. This value is considered for ProductCategory 3, 5 or 6 (air cooler for coolant, fluid cooler, sub cooler). For other product categories a valid value will be set internally. For other product categories a valid value will be set internally.	Double	Thermodynamics
85	FluidPumpMode	None	Defines, how the fluid is pumped through the flooded evaporator. Depending on the mode, different internal limit values are set, in particular the maximum pressure drop in the fluid. This value is needed for ProductCategory 1 (flooded evaporator).	Int32	Thermodynamics
	0 1 <i>Fluid circulation by a pump</i> <i>Fluid circulation by gravity or natural circulation</i>				
86	FluidPumpRate	None	Defines how often a fluid part must pass through the evaporator until it is completely evaporated. This value is needed for ProductCategory 1 (flooded evaporator).	Double	Thermodynamics
87	FluidSubCooling	K_TD	Subcooling of the fluid after condensation. Specification relative to the condensation temperature at the end of the condensation process. Note: If the fluid has a temperature glide or a pressure loss occurs during condensation, the condensation temperature at the end of the condensation process is lower than FluidTempCond. If ProductCategory = 3 (condenser), a fixed subcooling of 1 K is assumed internally. Rule: The resulting subcooling temperature must not be lower than the evaporation temperature.	Double	Thermodynamics
88	FluidSuperHeating	K_TD	Superheating of the fluid after evaporation. Specification relative to the evaporation temperature FluidTempEvap.	Double	Thermodynamics
89	FluidTempCond	Degree_C	Fluid condensation temperature at the inlet or in the middle of the first fluid circuit.	Double	Thermodynamics
90	FluidTempCond_2	Degree_C	Fluid condensation temperature at the inlet or in the middle of the second fluid circuit.	Double	Thermodynamics
91	FluidTempEvap	Degree_C	Fluid evaporation temperature at the inlet or in the middle. The dew popublic int must be specified for fluids with temperature glide.	Double	Thermodynamics
92	FluidTempInlet	Degree_C	Fluid temperature at inlet of the first circuit. If ProductCategory = 2, 4 or 5 (refrigerant air cooler, dry cooler, subcooler) and FluidInputMode = 0 or 1. If ProductCategory = 3 (condenser), the following must apply: Hot gas temperature >= condensing temperature. Specifies the hot gas temperature for condensers. Rule: The following must apply: FluidTempInlet >= -40.0 °C if it is used (FluidInputMode = 0 or 1).	Double	Thermodynamics

	Name	UsedUnit	InfoText	Datatype	Group
93	FluidTempInlet_2	Degree_C	Fluid temperature at inlet of the second circuit. If ProductCategory = 2, 4 or 5 (refrigerant air cooler, dry cooler, subcooler) and FluidInputMode = 0 or 1. If ProductCategory = 3 (condenser), the following must apply: Hot gas temperature >= condensing temperature. Specifies the hot gas temperature for condensers. Rule: The following must apply: FluidTempInlet >= -40.0 °C if it is used (FluidInputMode = 0 or 1).	Double	Thermodynamics
94	FluidTempOutlet	Degree_C	Fluid temperature at outlet. Rule for ProductCategory = 3 = refrigerant air cooler: The following must apply: FluidTempOutlet > FluidTempInlet if both are specified (FluidInputMode = 0). Rule for ProductCategory = 5/6 = drycooler/subcooler:The following must apply: FluidTempOutlet < FluidTempInlet,if both are specified (FluidInputMode = 0). Rule: The following must apply: FluidTempOutlet >= -40.0 °C if it is used (FluidInputMode = 0 or 2).	Double	Thermodynamics
95	FluidVolConcentration	VolPercent	Concentration of the fluid in volume-%. Only relevant if fluid allows a fluid concentration specification.	Double	Thermodynamics
96	FluidVolumeFlow	m3_per_h	Volume flow of the fluid. Only relevant if FluidInputMode = 1 or 2.	Double	Thermodynamics
97	ForEnergySavingController	None	For energy-saving applications, if a switch cabinet or terminal box is selected.	Int32	Unknown
98	ForNoiseUse	None	For noise-sensitive applications, if a switch cabinet or terminal box is selected.	Int32	Unknown
99	FrostedCoil	None	Flag for frost on the block with 0.01 in as the default value for the frost thickness. Only in GPC.AM!	Boolean	Thermodynamics
100	FrostThickness	m	Thickness of the frost layer to be considered in meters. Values greater than 0.0 are only permissible for evaporators and air coolers.	Double	Thermodynamics
101	FullCoverageDoubleTrayInsulated	None	Indicates whether a full coverage double tray with insulation is required as an accessory.	Int32	Unknown
	0 1		<i>Indicates that the full coverage double tray with insulation is not necessarily needed.</i> <i>Indicates that the full coverage double tray with insulation is definitely needed.</i>		
102	Geo_AirTemp_HydroPad	Degree_C	Air temperature from the selected location. Only relevant if HydroPad is selected.	Double	Hydro
103	Geo_Altitude_HydroPad	m	Defines the height above sea level = geodetic height/altitude from the selected location.	Double	Hydro
104	Geo_Length_HydroPad	DMS	Longitude coordinates from the selected location.	Double	Hydro

	Name	UsedUnit	InfoText	Datatype	Group
105	Geo_MaxAirTemp_HydroPad	m	Defines the maximum air temperature from the selected location. Only relevant if HydroPad is selected.	Double	Hydro
106	Geo_RelHumidity_HydroPad	Percent	Defines the relative air humidity at the inlet from the selected location.	Double	Hydro
107	Geo_Search_HydroPad	None	Flag, if nearest location to custom coordinates should be searched.	Boolean	Hydro
108	Geo_Width_HydroPad	DMS	Latitude coordinates from the selected location.	Double	Hydro
109	GuentnerStreamer	None	Indicates whether a Streamer (for an increased air throw) is required as an accessory.	Int32	Unknown
	0 1 Indicates that the streamer is not necessarily needed. Indicates that the streamer is definitely needed.				
110	HBLKValve	None	Indicates whether a HBLK valve is required as an accessory.	Int32	Unknown
111	HeatingStrapsAtAirOutlet	None	Indicates whether el. heating straps (at air outlet) are required as an accessory.	Int32	Unknown
112	HingedFanPlate	None	Indicates whether hinged fan plates are required as an option.	Int32	Unknown
113	HotGasInterConnectingTubing	None	Indicates whether hot gas interconnecting tubing is required as an accessory.	Int32	Unknown
	34 66 with check value without check value				
114	HydroPad	None	Indicates whether hydroBLU is required as an accessory.	Int32	Hydro
	234 hydroBLU is required as an accessory				
115	InletHood	None	Indicates whether an inlet hood is required as an accessory.	Int32	Unknown
116	InletNippleOuterDiameter	mm	Defines the diameter of nipple(s) at the inlet.	String	Unknown
117	InletPosLeft	None	Indicates whether connections in air flow direction left is required as an option.	Int32	Unknown
118	InletPosRight	None	Indicates whether connections in air flow direction right is required as an option.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
119	InletStateByTempAndPressure	None	Only relevant for CX evaporators! Normally, the pressure is calculated via the condensation temperature and subcooling. However, if you are in the supercritical range, this flag must be set! The inlet temperature and pressure must then be specified.	Boolean	Thermodynamics
120	InputModeCapacity	None	Capacity calculation mode	Int32	Unknown
	0 1 2 3 <i>The capacity is fixed, the area reserve is adapted to the capacity.</i> <i>The specified capacity is a target value, the actual capacity is optimized individually for each device or coil.</i> <i>The capacity is fixed indirectly via the air-side specifications; the area reserve is adapted to the capacity. Only possible for coils.</i> <i>The capacity is fixed, the condensing temperature is adapted to the capacity. Only possible for condenser coils.</i>				
121	InspectionCover	None	Indicates whether an inspection cover is required as an accessory.	Int32	Unknown
122	IoTModule	None	Indicates whether an aicore link (IoT-Module) is required as an accessory.	Int32	Unknown
123	IsAirRelHumidityAuto	None	Flag, if the relative air humidity at the inlet should be set automatically. Only available in GPC.AM.	Boolean	Thermodynamics
124	IsContainerTransport	None	Transport from the unit in a container.	Boolean	Limitations
	FALSE TRUE <i>Indicates no transport preference.</i> <i>Indicates that the device is to be transported in a container.</i>				
125	IsHotGasAuto	None	Flag, if hot gas temperature should be set automatically. Only relevant for condensers.	Boolean	Thermodynamics
126	IsMaxFluidPressureDropAuto	None	Flag, if max. fluid pressure drop should be set automatically.	Boolean	Thermodynamics
127	isSubcritic	None	Subcritical CO2 gas coolers operate below the critical point of carbon dioxide, where CO2 exists in a two-phase state as both a liquid and a gas. In these systems, CO2 gas is condensed into a liquid state through heat exchange with a cooler medium, such as air or water. This process relies on the properties of CO2 as it undergoes phase change, transitioning from a gas to a liquid.	Boolean	Thermodynamics
	FALSE TRUE <i>Indicates that the unit will not operate in subcritical mode.</i> <i>Indicates that the unit will operate in subcritical mode.</i>				

	Name	UsedUnit	InfoText	Datatype	Group
128	IsSubcriticMaxFluidPressureDropAuto	None	The max fluid pressre drop can be defined automatically.	Boolean	Extras
	<i>FALSE</i> <i>TRUE</i> <i>Indicates that the user must define the threshold.</i> <i>Indicates that Güntner decides for a fitting value.</i>				
129	isSupercritic	None	Supercritical CO2 gas coolers, on the other hand, operate above the critical point of carbon dioxide. In this state, CO2 behaves as a supercritical fluid, exhibiting properties of both a gas and a liquid. These coolers utilize the unique properties of supercritical CO2 to achieve efficient heat transfer, particularly in applications where high pressures and temperatures are involved. The cooling process involves heat exchange to transition the supercritical CO2 fluid into a subcritical state, where it exhibits more conventional refrigeration behavior.	Boolean	Thermodynamics
	<i>FALSE</i> <i>TRUE</i> <i>Indicates that the unit will not operate in supercritical mode.</i> <i>Indicates that the unit will operate in supercritical mode.</i>				
130	LastChangedKey	None	This parameter is not relevant for findunits but UI.	String	Unknown
131	LocationID_HydroPad	None	The ID of the place to use for Hydropad calculation	Int32	Hydro
132	LowEvapTempDesign	None	Indicates whether a the device must handle low temeratures.	Int32	Unknown
133	ManualSpeedController	None	Indicates whether a manual speed controller is required as an accessory.	Int32	Unknown
134	Market	None	Selects the market the device will be delivered to	Int32	Startpage
	<i>101</i> <i>201</i> <i>401</i> <i>Europa (EU)</i> <i>Asia, Pacific and Oceania (APO)</i> <i>North and Latin America (NLA)</i>				
135	MaxNumberOfHits	None	Maximum number of results.	Int32	Unknown
136	MaxOperatingPressure	bar	Indicates the maximum fluid pressure of the device.	Int32	Unknown
137	MaxSoundInputMode	None	Selects the mode the sound is filtered.	Int32	Limitations
138	MaxSoundTolerance	dBA	Specifies how loud a unit may be.	Double	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
139	MiniumRequiredSubcooling	K_TD	If a subcooler is selected, how big is the temerature difference between the primary and secondard circuit.	Double	Unknown
140	MotorTechnology	None	This parameter defines the fan motor technology, or fan motor type of the unit.	Int32	Options
141	MountedAndWired	None	Specifies if the fans have to be mounted and wired or delivered seperately.	Int32	Unknown
142	MountedLegs	None	Indicates whether legs will be attached to the device so it can stand. If not included, the device has to be mounted.	Int32	Unknown
143	MountedLegsGS	None	When MountedLegs are included, these are in galvanized steel and therefore have no corrosion protection.	Int32	Unknown
144	MountedLegsSS	None	When MountedLegs are included, these are made of stainless steel and therefore have a corrosion protection.	Int32	Unknown
145	MultipleCircuits	None	Indicates if the device can have multiple circuits.	Int32	Unknown
146	NippleTubeMaterial	None	Indicates whether a different material should be used for NippleTube	Int32	Options
147	NoInletNipples	None	Defines the number of nipples at the inlet.	String	Unknown
148	NoOfCircuitsThermo	None	Number of required thermo circuits.	Int32	Unknown
149	NoOfDevices	None	Number of required units.	Int32	Limitations
150	NoOfFans	None	Number of required fans.	Int32	Limitations
151	NoOfPasses	None	Number of required passes.	Int32	Unknown
152	NoOutletNipples	None	Defines the number of nipples at the outlet.	String	Unknown
153	OnlyStockUnits	None	Only products that are ready to ship.	Boolean	Limitations
154	OutletNippleOuterDiameter	mm	Defines the diameter of nipple(s) at the outlet.	String	Unknown
155	OverpressureFlap	None	Indicates whether an OverpressureFlap is required as accessory.	Int32	Unknown
156	PadTypes_HydroPad	None	Specifies Pad Type ID.	Int32	Hydro
157	PassNumberConstraint	None	Constraints for the number of passes	Int32	Extras

	Name	UsedUnit	InfoText	Datatype	Group
	0		All numbers between <i>nNumberOfPassesMin</i> and <i>nNumberOfPassesMax</i>		
	1		Only even number of passes between <i>nNumberOfPassesMin</i> and <i>nNumberOfPassesMax</i>		
	2		Discrete values must be given in <i>DiscreteNumberOfPasses</i>		
158	PowerSupply	None	Specification of the voltage supply network for which the unit should be suitable.	Int32	Options
	0		no constraint		
	10		400V 3~ 60Hz		
	11		460V 1~ 60Hz		
	12		460V 3~ 60Hz		
	13		575V 3~ 60Hz		
	14		230V 3~ 50Hz		
	15		230V 3~ 60Hz		
	16		230V 1~ 60Hz		
	18		110V 1~ 50Hz		
	19		110V 1~ 60Hz		
	3		115V 1~ 60Hz		
	4		208-230V 1~ 60Hz		
	5		208-230V 3~ 60Hz		
	6		230V 1~ 50Hz		
	7		380V 1~ 50Hz		
	8		380V 3~ 60Hz		
	9		400V 3~ 50Hz		
159	PreSelection	None	This parameter is not relevant for findunits but UI.	Int32	Unknown
160	PressureSensor	None	Indicates whether a pressure sensor is required as an accessory.	Int32	Unknown
161	PreviousChangedValue	None	This parameter is not relevant for findunits but UI.	String	Unknown
162	ProductCategory	None	Defines the product category	Int32	Startpage

	Name	UsedUnit	InfoText	Datatype	Group
	<i>0</i> <i>1</i> <i>10</i> <i>2</i> <i>3</i> <i>4</i> <i>5</i> <i>6</i>		<i>DX evaporator (Cold Indoor)</i> <i>Flooded evaporator (Cold Indoor)</i> <i>Gas Cooler</i> <i>One phase air cooler (Cold Indoor)</i> <i>Condenser (Warm Outdoor)</i> <i>Brine cooler (Warm Outdoor)</i> <i>Sub cooler (Warm Outdoor)</i> <i>Oil cooler (Warm Outdoor)</i>		
163	RalNumber	None	Definer RAL number for special varnishing.	Int32	Unknown
164	ReducedLegs	None	Indicates whether reduced legs are required as an accessory.	Int32	Unknown
165	RepairSwitch	None	Indicates whether a repair switch is required as an accessory.	Int32	Unknown
	<i>0</i> <i>233</i>		<i>No Repair switch</i> <i>Repair switch selected</i>		
166	RepairSwitchPosition	None	Defines position of repair switch.	Int32	Unknown
	<i>0</i> <i>1</i> <i>2</i> <i>3</i>		<i>Undefined</i> <i>Mounted close to the fan</i> <i>Mounted at the front</i> <i>Standard</i>		
167	RepairSwitchType	None	Defines type of repair switch.	Int32	Unknown
	<i>0</i> <i>1</i> <i>2</i>		<i>Undefined</i> <i>Two-turn (star/delta switchable) (9-pole)</i> <i>Single-speed (7-pole)</i>		
168	RepairSwitchWiring	None	Defines wiring type for repair switch.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	0		Undefined		
	1		Preferably individually wired, i.e. one rep. switch per fan		
	2		Single wired, i.e. one rep. switch per fan		
	3		Preferably wired in pairs, i.e. two fans are switched with one rep. switch		
	4		Wired in pairs, i.e. two fans are switched with one repair switch		
	5		Preferably a single repair switch for all fans		
	6		A single repair switch for all fans		
169	SeparationSheetWithHeater	None	Indicates whether a separation sheet with heater is required as an accessory.	Int32	Unknown
170	Shutup	None	Indicates whether a defrost hose is required as an accessory.	Int32	Unknown
171	SoundAbsorber	None	Indicates whether a sound absorber is required as an accessory.	Int32	Unknown
172	SoundPressureDistance	m	Distance for which the sound pressure level is to be calculated [m]. Only relevant if - ProductCategory = 4 to 6 (condenser, drycooler or subcooler) - For ProductCategory 1 to 3 (evaporator and refrigerant air cooler), this input parameter is ignored and set internally to 3 m - Distance specification according to enveloping surface method EN 13487, i.e. distance between appliance and the enveloping surface that is placed around the appliance. - Value range: >= 0 m	Double	Limitations
173	SoundPressureMax	dBA	Only relevant if - UnitSelectionMode = 0 ('unit search mode'). - The limit value applies to a distance corresponding to SoundPressureDistance. - The sound pressure level is calculated using the enveloping surface method in accordance with EN 13487. - If the sound pressure level is not to be limited, it is advisable to specify a high value(e.g. 99.0 dB(A)). In the selection program, the specified maximum sound pressure level is eventually increased internally by an additional 4 dB(A) tolerance.	Double	Limitations
	0		Max. sound power		
	1		Max. sound pressure		
174	SpecialVarnishing	None	Indicates whether special varnishing is required as an option.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
175	Subcooler	None	Indicates whether a subcooler is required as an option.	Int32	Unknown
176	SubcriticAirRelHumidity	Percent	This parameter defines the subcritical air absolute humidity in %, for CO2 gas coolers.	Double	Unknown
177	SubcriticAirTemperature	Degree_C	This parameter defines the subcritical air dry bulb temperature in °C, for CO2 gas coolers.	Double	Unknown
178	SubcriticAirWetBulbTemp	Degree_C	This parameter defines the subcritical air wet bulb temperature in °C, for CO2 gas coolers.	Double	Unknown
179	SubcriticFluidPressureDropMax	K	This parameter defines the maximum allowable subcritical pressure drop in K for CO2 gas coolers.	Double	Unknown
180	SubcriticFluidTempCond	Degree_C	This parameter defines the subcritical condensing temperature in °C, for CO2 gas coolers	Double	Unknown
181	SubcriticFluidTempInlet	Degree_C	This parameter defines the subcritical inlet temperature, aka the hot gas temperature in °C, for CO2 gas coolers.	Double	Unknown
182	SubcriticIsHotGasAuto	None	This parameter defines whether the subcritical inlet temperature, aka hot gas temperature should be set automatically or set using the subcriticFluidTempInlet input.	Boolean	Unknown
	<i>FALSE</i> <i>TRUE</i>		<i>The subcritical inlet temperature is defined using the subcriticFluidTempInlet input</i> <i>The subcritical inlet temperature is set automatically</i>		
183	SubcriticThermalCapacity	W	This parameter defines the target subcritical capacity in W for CO2 gas coolers.	Double	Thermodynamics
184	SwitchCabinet	None	Indicates whether a switch cabinet is required as an accessory.	Int32	Unknown
	<i>0</i> <i>1</i>		<i>Indicates that the switch cabinet is not necessarily needed.</i> <i>Indicates that the switch cabinet is definitely needed.</i>		
185	SwitchCabinetAllocation	None	This parameter defines the allocation type for the switch cabinet. Either the allocation is automatically set, or it is set to one switch cabinet per unit.	Int32	Unknown
	<i>1</i> <i>3</i> <i>4</i> <i>5</i>		<i>The allocation is automatic</i> <i>There is one switch cabinet or terminal box allocated per unit</i> <i>There is one switch cabinet or terminal box allocated per fluid circuit</i> <i>There is no switch cabinet or terminal box selected</i>		
186	SwitchCabinetMotorTechnology	None	This parameter defines the fan motor technology, or fan motor type, for the switch cabinet.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	-1 -2 -3 1 2		<i>All fan motor technologies are considered</i> <i>The fan motor technology is energy optimized</i> <i>The fan motor technology is cost optimized</i> <i>The motor technology is AC</i> <i>The motor technology is EC (electronically commutated)</i>		
187	SwitchCabinetType	None	This parameter defines the type of the switch cabinet.	Int32	Unknown
	0 1 10 11 12 13 2 3 4 5 6 7 8 9		<i>Undefined</i> <i>Consider all types</i> <i>Switch cabinet with stand cabinet</i> <i>Switch cabinet with terminal box</i> <i>Switch cabinet with 0 to 10V terminal box</i> <i>Modbus Daisy Chain</i> <i>Set the switch cabinet automatically</i> <i>Small switch cabinet</i> <i>GIS-type switch cabinet</i> <i>GWS-type switch cabinet</i> <i>GSS-type switch cabinet</i> <i>GKS-type switch cabinet</i> <i>Switch cabinet with EC junction box</i> <i>Switch cabinet with a panel</i>		
188	SwivelingFans	None	Indicates whether a swiveling fans, aka hinged fans, is required as an accessory.	Int32	Unknown
	0 329 68		<i>Indicates that the swiveling fans accessory is not necessarily needed.</i> <i>Indicates that the swiveling fan plate accessory is definitely needed.</i> <i>Indicates that the swiveling fans accessory is definitely needed.</i>		
189	TC_Tolerance_H	Percent	This parameters specifies the upper limit for the surface reserve tolerance.	Double	Extras
190	TC_Tolerance_L	Percent	This parameters specifies the lower limit for the surface reserve tolerance.	Double	Extras

	Name	UsedUnit	InfoText	Datatype	Group
191	TCondInputMode	None	This parameters defines the convention for defining where the condensing temperature of the input fluid is defined. This is required for refrigerants that have a significant temperature glide.. If the refrigerant considered doesn't have a glide, then this parameter is not relevant.	Int32	Unknown
	0		<i>The input condensing temperature is defined at the fluid's dew point, aka at the condenser's inlet</i>		
	1		<i>The input condensing temperature is defined as a mean, at vapor quality of 0.5s inlet</i>		
	2		<i>The input condensing temperature is defined at the fluid's bubble point, aka at the condenser's outlet</i>		
192	TelescopicLegs	None	Indicates whether telescopic legs, are required as an accessory.	Int32	Unknown
	0		<i>Indicates that the telescopic legs accessory is not necessarily needed.</i>		
	1		<i>Indicates that the telescopic legs accessory is definitely needed.</i>		
193	TerminalBoxType	None	Defines the fan wiring type.	Int32	Unknown
	1		<i>AUTO</i>		
	2		<i>All fans grouped together to form a group.</i>		
	4		<i>Fans not grouped and individually connected.</i>		
194	ThermalCapacity	W	This parameters sets the target thermal capacity, in W, for the main circuit of the heat exchanger.	Double	Thermodynamics
195	ThermalCapacity_2	W	This parameters sets the target thermal capacity, in W, for the secondary circuit of the heat exchanger.	Double	Thermodynamics
196	ThermoContactType	None	This parameter defines the type of the thermo contact cabinet.	Int32	Unknown
	0		<i>Undefined</i>		
	1		<i>Consider all types</i>		
	2		<i>Set the thermo contact automatically</i>		
	3		<i>Set the thermo contact to manual reset</i>		
	4		<i>Set the thermo contact to remote reset</i>		
197	ThermosiphonOilCooling	None	Only available for NH3 condenser. This checkbox has an effect on the max. pressure drop in coil.	Int32	Thermodynamics

	Name	UsedUnit	InfoText	Datatype	Group
	0 1		<i>AUTO max. pressure drop in coil equals 5.0 K.</i> <i>AUTO max. pressure drop in coil equals 0.3 K.</i>		
198	ThreadConnectionMaterial	None	This parameter defines the material of the connection if a thread connection is selected as a connection type.	Int32	Unknown
	0 1 2 3 4 5 6		<i>Undefined</i> <i>Set the thread connection material automatically</i> <i>Consider all materials</i> <i>Set the thread connection material to steel</i> <i>Set the thread connection material to red brass</i> <i>Set the thread connection material to stainless steel 304L</i> <i>Set the thread connection material to stainless steel 316L</i>		
199	Tubing_Of_Integrated_Subcooler_With_Syphon	None	Indicates whether tubing of integrated subcooler with syphon required as an accessory (only if subcooler is already selected as an accessory)	Int32	Unknown
	0 1		<i>Indicates that the tubing of integrated subcooler with syphon accessory is not necessarily needed.</i> <i>Indicates that the tubing of integrated subcooler with syphon accessory is definitely needed.</i>		
200	UnitFilterList	None	Specifies the filter a list of single units that should be calculated/validated.	List`1	Unknown
201	UnitHeightMax	m	This parameters sets the maximum height in meters that should be considered for the units returned during a unit search.	Double	Limitations
202	UnitLengthMax	m	This parameters sets the maximum length in meters that should be considered for the units returned during a unit search.	Double	Limitations
	0 68 87		<i>no constraint</i> <i>high-strength copper (D)</i> <i>stainl. steel (W)</i>		
203	UnitModelID_MRNameExternal	None	For recalculation (KDB): Model type name external.	String	Recalculation

	Name	UsedUnit	InfoText	Datatype	Group
204	UnitModelID_MRNameInternal	None	For recalculation (TDB): Model range name internal.	String	Recalculation
205	UnitModelID_MTNameExternal	None	For recalculation (TDB): Model type name external.	String	Recalculation
206	UnitModelID_MTNameInternal	None	For recalculation (TDB): Model type name internal.	String	Recalculation
207	Units	None	Specification of the model ranges.	List`1	UnitSelection
208	UnitSelectionMode	None	Selection mode of the unit calculation.	Int32	UnitSelection
	0 1 unit search recalculation of a defined individual unit { get; set; } some other parameters are then ignored				
209	UnitWidthMax	m	This parameters sets the maximum width in meters that should be considered for the units returned during a unit search.	Double	Limitations
210	UVC_Lamp	None	Indicates whether UVC lamp is required as an accessory,	Int32	Unknown
	0 1 Indicates that the UVC lamp accessory is not necessarily needed. Indicates that the UVC lamp accessory is definitely needed.				
211	VersionNumber	None	Version number of the Guentner API	Int32	Unknown
212	VibrationDampers	None	Indicates whether Vibration dampers are required as an accessory.	Int32	Unknown
	0 1 Indicates that the Vibration dampers accessory is not necessarily needed. Indicates that the Vibration dampers accessory is definitely needed.				
213	WallSuspension	None	Indicates whether Wall suspension is required as an accessory.	Int32	Unknown
	0 1 Indicates that the Wall suspension accessory is not necessarily needed. Indicates that the Wall suspension accessory is definitely needed.				
214	WaterConsumptionCalculation_HydroPad	None	The parameter defines whether or not a water consumption calculation is required to be perfumed for the unit selected, and output to the data sheet	Boolean	Hydro

	Name	UsedUnit	InfoText	Datatype	Group
	0 1		<i>Indicates that the water consumption calculation should not be performed</i> <i>Indicates that the water consumption calculation should be performed</i>		
215	WaterConsumptionCalculation_Mode_HydroPad	None	This parameter defines the way the water consumption calculation should be performed for units with the HydroSpray option, if the water calculation is requested.	Int32	Hydro
	0 1		<i>The wetting duration is set, and the switch point is then calculated (this is the default setting for the calculation mode)</i> <i>The switch point is set, and the wetting duration is then calculated</i>		
216	WaterConsumptionCalculation_SwitchPoint_HydroPad	None	If the water calculation mode for a unit with a hydroSpray option is set to calculation of the wetting duration with a set switch point, this parameter sets the wetting duration to be used.	Double	Hydro
217	WaterConsumptionCalculation_WettingDuration_HydroPad	None	If the water calculation mode for a unit with a hydroSpray option is set to calculation of the switch point with a set wetting duration, this parameter sets the wetting duration to be used.	Double	Hydro
218	Watering_HydroPad	None	For a unit with the hydroBLU option selected, this parameter defines the operation mode for the watering system:	Int32	Hydro
	0 1 2		<i>The unit is operating in wet mode, with pads installed and water fed to the pads</i> <i>The unit is operating dry (no water fed for the pads), but with the pads installed on the unit</i> <i>The unit is operating dry with the pads uninstalled on the unit</i>		
219	WateringRate_HydroPad	None	This parameter sets the watering rate for the hydroBLU system. The available values are 1.2, 1.6, 2.0 and 2.8 (default of 2.)	Double	Hydro
220	WeldingNeckFlangeNominalPressure	None	This parameter defines the nominal pressure rating for flanges (lapped flanges or welding neck flanges):	Int32	Unknown
	3 4 5 7		<i>PN16 B1 (DIN EN 1092-1) (only available for welding neck flanges)</i> <i>PN40 B1 (DIN EN 1092-1) (only available for welding neck flanges)</i> <i>PN40 D+C (DIN EN 1092-1) (only available for welding neck flanges)</i> <i>PN10 (only available for lapped flanges, with brazing neck)</i>		
221	Wiring_To_Junction_Box_At_Side	None	Indicates whether Wiring to the terminal box is required as an accessory only for the old TDB series.	Int32	Unknown

	Name	UsedUnit	InfoText	Datatype	Group
	0		<i>Indicates that the Wiring to the terminal box accessory is not necessarily needed.</i>		
	1		<i>Indicates that the Wiring to the terminal box accessory is definitely needed.</i>		
222	Wiring_To_Terminal_Box	None	Indicates whether Wiring to the terminal box is required as an accessory for the newer KDB series.	Int32	Unknown
	0		<i>Indicates that the Wiring to the terminal box accessory is not necessarily needed.</i>		
	1		<i>Indicates that the Wiring to the terminal box accessory is definitely needed.</i>		